

This Owner's Manual is provided and hosted by [Appliance Factory Parts](#).



# WINDCHASER HUMIDIPEN Owner's Manual

[Shop genuine replacement parts for WINDCHASER  
HUMIDIPEN](#)



[Find Your WINDCHASER Humidifier Parts - Select From 16 Models](#)

----- Manual continues below -----

PLEASE READ BEFORE USE

# humid

ULTRASONIC HUMIDIFIER



INNOVATIVE PRODUCTS FOR LIVING



**WindChaser Products, Inc.**

4130 Del Rey Avenue, Marina del Rey, CA 90292

Phone: 310-827-8615 Fax: 310-827-8566

**Toll Free: 1-800-405-2943**

**[www.windchaserproducts.com](http://www.windchaserproducts.com)**



©2007 WindChaser Products, Inc.

## LIMITED WARRANTY

### One (1) Year Limited Warranty

Thank you for choosing WindChaser® Products. Please read all instructions before assembly and use. Please empty all items from carton and save carton for future use. If you have any questions or require assistance, please contact WindChaser customer service at: **custserv@windchaserproducts.com or 1-800-405-2943.**

This warranty applies to repair or replacement of defective material or workmanship. This warranty does not cover damage resulting from commercial, abuse, or supplemental damage. Defects as a result of use shall not be considered manufacturing defects unless specified in the instruction manual before attempting to use the product. WindChaser Products, Inc. is not liable for incidental or consequential damages. Any implied warranty of merchantability on this product is limited in duration to the extent that state laws do not allow the exclusion or limitation of damages or limitations on how long an implied warranty may last. Limitations or exclusions may not apply to certain states due to specific legal rights, and you also may be subject to state to state. This warranty applies only to the original product. WindChaser Products, Inc. will not be held responsible if it is found to be defective in material and workmanship. The product should be returned to the place of purchase. Thereafter, while within the warranty period, the product may be returned to WindChaser Products, Inc. for repair or replacement. Damage resulting from unauthorized alterations or modifications in accordance with its manual. Return the product to WindChaser Products, Inc., 4130 Del Rey Avenue, San Diego, CA 92108. Customer Service, freight prepaid with return shipping, handling, return packing and shipping charges. Please include name, address, and daytime phone number on the return. Regarding design changes, the actual product may differ from the packaging. This warranty is valid only in the United States.

**BEFORE RETURNING PRODUCT,  
CONTACT CUSTOMER SERVICE  
E-MAIL (custserv@windchaserproducts.com)  
OR PHONE (1-800-405-2943)**

**WindChaser Products, Inc.**  
4130 Del Rey Avenue, Mission Viejo, CA 92690  
Phone: 310-827-8615  
**Toll Free: 1-800-405-2943**  
**www.windchaserproducts.com**

## TROUBLESHOOTING


Problem	Cause	Solution
Power light is off.	The unit is not plugged in or power is off.	Plug into an available outlet and operate normally.
Powerlight is on, air is present, but no mist.	No water in the tank. The float switch has malfunctioned.	Fill the water tank with water.
The mist has a odor.	Unit is new, and smell will pass or water is not clean.	Open the water tank and place it in a shady spot for 12 hours. Wash the tank or change the water.
The power light is on, no air or mist.	The water level is too high.	Pour some of the water out from the water tank inlet and replace the tank.
Very little mist when on.	Ultrasonic plate has scale build-up, water is not clean, or water has not been changed.	Wash the ultrasonic plate and change water.
Water level is the same as when filled.	The water-inlet is blocked.	Clean the water-inlet.

## CONTENTS

# humid

## ULTRASONIC HUMIDIFIER

MODEL  
humidipen™



- Before Initial
- For Your Safe
- Cautions
- Parts & Prepa
- Intelligent Hu
- Operating Ins
- Specifications
- Cleaning and
- Troubleshoot
- Limited Warran



## BEFORE INITIAL USE

Read this entire instruction manual before use.

Attach your purchase receipt here.

PLEASE KEEP YOUR RECEIPT.

YOUR RECEIPT IS YOUR PROOF OF  
PURCHASE AND IS NECESSARY FOR  
WARRANTY SERVICE.

### For your reference:

Serial No. \_\_\_\_\_ Date of Purchase \_\_\_\_\_

Name and Address of Dealer \_\_\_\_\_  
\_\_\_\_\_  
\_\_\_\_\_

## SPECIFIC

VOLTAGE

POWER CONSUMPTION

APPLICABLE AREA

WATER TANK CAPACITY

WATER OUTPUT CAPACITY

DIMENSIONS (WxDxH)

WEIGHT

## CLEANING AND

1. Turn the control to "OFF" and unplug the unit.
2. Never use a detergent or any cleaning agent on the unit. Detergent dissolved in the water will be mist output.
3. If water tank is extremely dirty, soak with detergent and rinse clean. Never use detergent on the exterior.
4. Wipe the exterior of the body with a damp cloth.
5. Do not spray water or any liquid onto the exterior.
6. Never immerse the base in water or let it get wet. Do not clean other openings on the exterior.
7. Clean and rinse the water tank and mist output frequently to avoid mineral build up, especially the mist output.
8. Keep the ultrasonic plate and water sensor clean. Clean the water tank and empty the reservoir. Clean the ultrasonic plate with a soft brush (old toothbrush). Do not clean the ultrasonic sensor and do not clean with tools that can scratch the sensor.
9. Letting water sit in the tank for more than 24 hours will cause mold growth. Always empty the tank if plan to store the unit.

**NOTE: If a problem is experienced, contact the service center at the place of the original purchase or service center. Do not open the unit to avoid electric shock, do not open the unit to replace user-serviceable parts inside. Any repair work by a qualified technician appointed by the manufacturer is required. Opening the unit housing may void the warranty and cause personal injury.**

## INTELLIGENT HUMIDIFICATION


- It is best to keep the overall room humidity level between 30-50 percent.
- The comfort level of humidity will vary from room to room and with changing room conditions.
- In cold weather, windows and even some walls may fog or develop frost from excessive indoor humidity. If this occurs, reduce the mist intensity setting to avoid damage from condensed water dripping on windowsills and walls.
- Too much humidity in the room may allow moisture to accumulate on surfaces where bacteria and fungi can grow. Moisture that gathers may also damage furniture, walls and wallpaper.
- To eliminate excessive humidity, especially in smaller rooms, leave the room door open and adjust the mist intensity control accordingly.

## OPERATING INSTRUCTIONS

Plug the unit into an available 120V ~ 60Hz outlet.

**NOTE: Indicator light will illuminate when unit is plugged in to show that power is going to the unit.**

Turn the control knob clockwise to the desired misting level. To turn the unit off, turn the control knob counter-clockwise to the OFF position.



**NOTE: Unit will automatically shut off when the water tank is empty.**

## FOR YOUR

## IMPORTANT INSTR

Read and save these important safety instructions for using electrical appliances, basic safety instructions, including the following:

- 1) Use this unit only as described in this manual. Misuse may cause fire or electric shock.
- 2) This product is intended for household use only. Do not use for industrial or outside use.
- 3) To protect against electrical shock, do not touch the plug or cord in water, or spray with liquid.
- 4) Close supervision is necessary when used by children or physically disabled people.
- 5) Unplug the unit from the outlet when not in use. Move the location to another and before cleaning.
- 6) Do not operate the unit in the presence of flammable vapors.
- 7) Do not place the unit or any parts near a heating appliance.
- 8) Do not operate the unit with a damaged cord or plug, if dropped or damaged in any manner.
- 9) Avoid contact with ultrasonic misting particles when unit is in operation.
- 10) To disconnect, grip the plug and pull straight out. Do not pull the cord.
- 11) The use of attachments is not recommended.
- 12) Always use on a dry level surface.
- 13) Do not operate if the unit housing is cracked or damaged.
- 14) FOR INDOOR USE ONLY.

THIS PRODUCT IS EQUIPPED WITH A POLARIZED PLUG — a plug having one prong wider than the other. It can be inserted into a power outlet only one way. This is the safe way to use the plug. If the plug does not fit the outlet, try reversing it. If it still does not fit, contact an electrician to replace the outlet. FOR SAFETY PURPOSE OF THIS POLARIZED PLUG.

**WARNING: To reduce the risk of fire or electric shock, do not use this unit with any solid state speed controllers.**


## SAVE THESE INSTR

## CAUTIONS



NOTE: Please be sure to use the correct voltage when operating the unit.  
Input: 120VAC / 60Hz

1. Do not operate and store at temperatures below 32°F (0°C) or above 113°F (45°C). Extreme temperatures may deform or damage the outer body.
2. Do not touch or bend the Ultrasonic Vibration Plate. Doing so may cause the unit to mist improperly. **WHEN CLEANING THE VIBRATION PLATE USE A SOFT BRISTLED BRUSH (OLD TOOTH BRUSH WILL WORK).**
3. Do not use hot water, unfiltered tap water or liquid chemicals in the unit. Use only purified water (i.e. bottled water or filtered tap water) to prevent clogging and damage to the vibration plate.
4. Do not add any fragrant oils or liquids to the water in the unit. Doing so may damage the vibrating plate.
5. Do not operate unit in a dusty environment. Doing so may clog and damage the vibration plate.
6. Always turn unit to the "OFF" position when not in use.
7. Keep the misting spout free from obstruction by such materials as clothing, plastic bags or papers.
8. If the unit is properly connected and no power is flowing, please refer to the TROUBLESHOOTING section of this manual.
9. Always keep the unit at an up-right position to avoid water leakage.
10. NEVER LEAVE UNIT ON WHILE UNATTENDED.

## PAR



## PREPAR



### TO FILL T

1. Remove the water tank cap from the top of the water tank. You will see the water tank cap.
2. Turn the power switch to the "OFF" position and remove the water tank cap from the counter.
3. Fill the water tank with purified water and secure the water tank cap by turning it clockwise. Refer to the recommended water level.
4. Place the humidifier on a flat surface and place the humidifier on the water tank.