

PARTS LIST

for

KitchenAid®

3-SPEED HAND MIXER

MODELS:

**KHM3WH5 (White)
4KHM3WH5 (White)**




FOR CUSTOMER SATISFACTION ALWAYS USE
FACTORY SPECIFICATION PARTS



UNIT PARTS

Variations of Models: KHM3__5, 4KHM3__5



Illus. No.	Part No.	DESCRIPTION
1	8212344	Literature Use & Care Guide (Trilingual)
	8212053	Repair Parts List
2	8212342	Knob, Speed Cntrl Gloss Grey Nimbus
3	◆	Mixer, Complete
4	8212348	Beaters, Turbo (Incl. Rt & Lt)

◆ **Note:**
 Parts not sold separately.
 Must be purchased as a complete unit.

**OPTIONAL PARTS
 NOT ILLUSTRATED**

- 8212351 Hooks, Dough (Incl. Rt & Lt)
- 8212341 Rod, Blending
- 8212340 Whisk

FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST