

# PARTS LIST

for

# **KitchenAid®**

## **6 QT. STAND MIXER**

### **CUSTOM BOWL LIFT**

#### **MODELS**

**KD2661XMC3 (Metallic Chrome)**  
**4KD2661XMC3 (Metallic Chrome)**




FOR CUSTOMER SATISFACTION ALWAYS USE  
FACTORY SPECIFICATION PARTS



# COLOR VARIATION PARTS

For Model: KD2661X\_3, 4KD2661X\_3



FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

# COLOR VARIATION PARTS

For Model: KD2661X\_\_3, 4KD2661X\_\_3


<b>Illus.</b>	<b>Part</b>
<b>No.</b>	<b>No. DESCRIPTION</b>

Availability of All Colors  
Subject to Change.  
Any Color Not Listed is  
No Longer Available.  
If Additional Colors Are Added,  
This Page Will Be Updated.

1	Motor Housing
9703433	Metallic Chrome
2	Trim Band
9703640	Silver/Gray
3	Planetary
9708175	Metallic Chrome
4	Bowl Support
9703397	Metallic Chrome
5	Lower Gearcase
9706306	Metallic Chrome
6	Column
9703349	Metallic Chrome
7	Base & Foot
	Assembly
9703346	Metallic Chrome

# CASE, GEARING AND PLANETARY UNIT

For Model: KD2661X\_3, 4KD2661X\_3



FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

# CASE, GEARING AND PLANETARY UNIT


For Model: KD2661X\_\_3, 4KD2661X\_\_3

Illus. No.	Part No.	DESCRIPTION	Illus. No.	Part No.	DESCRIPTION	Illus. No.	Part No.	DESCRIPTION
1	**	Gearcase Motor Housing	13	9703438	Retaining Clip	28		Bearing
2	9707507	Motor (10 Tooth)	14	9708191	Agitator Shaft		9703560	Front
3		Cap, Attachment Hub	15	**	Planetary Assembly		9703570	Rear
	9703315	Chrome	16	16897	Bearing, Lower Center	29	9703445	Thrust Bearing
4		Thumb Screw	17	9709231	Worm Gear	30	67500-55	"O" Ring
	240374	Black	18	9707223	Retaining Pin	31	9707425	Gasket, Transmission Cover
5	**	Band, Trim	19	9706529	Gear, Worm Follower	32	9706036	Lead, Motor To Control
6		Power Cord	20	9703338	Gear, Attachment Hub Bevel	33	9706247	Seal, Motor Shaft
	9706552	Black	21	9703337	Gear, Bevel	34	9703339	Gear, Internal
7	9703671	Transmission Housing	22	3400617	Screw, 6-32 x 1/4	35	9704677	Pin, Groove
8		Control Assembly	23	3400814	Screw (13), 8-32 X 5/8			
	9706648	Black Knob	24	**	Lower Gear Case			**Refer To Page 3 Color Variation Parts
9	9703312	Sensor, Hall Effect	25	9703680	Retaining Clip			
10	9706090	Washer	27	3400200	Screw (3) 1/4 - 20 x 3/4			
11	9703434	Washer, Fiber						
12	9703340	Gear, Pinion						

FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

# BASE AND PEDESTAL UNIT

For Model: KD2661X\_\_3, 4KD2661X\_\_3



Illus. No.	Part No.	DESCRIPTION
1		Literature Parts Use & Care Guide
	9707946	U.S.
	9706164	Canada
	8211766	Repair Parts List
2	9708649	Foot, Rubber (5)
3	**	Column Assembly
4	**	Bowl Support
5	9703474	Latch, Bowl Spring
6	9706885	Arm, Bowl Lift
7	9706787	Rod, Bowl Lift
8	**	Base And Foot Supports
9	9703439	Washer
10	9237	Spring
11	4159092	Nut
12	9706788	Handle, Bowl Lift
13	3400863	Screw
14	9703687	Bowl (6 Qt)
15	9708610	Beater, Flat
16	9708833	Dough Hook
17	9703491	Wire Whip
18	9703534	Pouring Spout
19	9703533	Pouring Shield
20	9703426	Cam, Adjusting
21	3400200	Screw (3), 1/4-20 x 3/4
22	3400018	Screw, 10-24 x 1/2
23	9703307	Clip
24	4162028	Pin, Bowl Locating
25	9703698	Handle

\*\*Refer To Page 3  
Color Variation Parts

FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

# ACCESSORY PARTS

For Model: KD2661X\_\_3, 4KD2661X\_\_3

Illus. No.	Part No.	DESCRIPTION
	4164778	Mixer Attachment Pak (Includes Food Grinder (FG-A), Food Strainer (FVSP), And Vegetable Slicer, (RVS-A) (FPP-A)
	4164749	Food Grinder (FG-A)
	4164751	Grain Mill (GM-A)
	4164768	Pasta Maker And Food Grinder (Includes SNP Pasta Maker Plates) (SN/FG-A)
	4164775	Fruit/Vegetable Strainer Parts (Use With FG-A Model Only) (FVSP)
	4164750	Rotor Slicer/Shredder (With 4 Standard Cones) Fine Shredder, Coarse Shredder, Thick Slicer, And Thin Slicer (RVS-A)
	4164824	Pasta Maker Plates (SNP-A)
	4164774	Fruit/Vegetable Strainer And Food Grinder (FVS/FG-A)
	4162838	Food Tray (FT)
	4164748	Juicer (JE)
	4164747	Can Opener (CO)
	4164803	Sausage Stuffer Kit (SSA)
	4160588	Grease, Planetary