


UPPER HOUSING AND FLANGE PARTS

DISPOSER

For Model: GC2000XE2, GC2000PE2




| Illus. No. | Part No. | DESCRIPTION |
|------------|----------|-------------------|
| 1 | 4211300 | Stopper Assembly |
| 2 | 8174328 | Mounting Assembly |
| 8 | 4211615 | Gasket, Mounting |
| 14 | 8174354 | Bolt, Thru |

FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

LOWER HOUSING AND MOTOR PARTS



For Model: GC2000XE2, GC2000PE2



| Illus. No. | Part No. | DESCRIPTION |
|------------|----------|-----------------------------------|
| 1 | | Enclosure Assy, (not serviceable) |
| 6 | 4211322 | Actuator Assembly Centrifugal |
| 7 | 8174322 | Stator Assembly |
| 8 | 8174312 | Switch Assembly, Start |
| 9 | 882726 | Protector, Overload |
| 10 | 8174345 | End Frame Assembly, Lower |
| 12 | 8174355 | Kit, Installation |
| 15 | 4211472 | Plug & Cord (GC2000PE2 only) |
| 16 | 4211351 | Shield, Wire |
| 17 | 8174329 | Bushing (GC2000PE2 only) |
| 18 | 4211351 | Cover, Terminal |
| 20 | 8174310 | Wrench, Emergency |

Following Parts Not Illustrated

8174356 Guide, Use And Care



FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST