




UPPER HOUSING AND FLANGE PARTS

For Model: GC400XE



DISPOSER



1	4211621	Stopper Assembly
2	4211333	Gasket, Stopper
3	4211605	Flange, Strainer
4	4211606	Seal, Sink Flange
5	4211303	Flange, Backup
6	4211304	Flange, Mounting
7	4211306	Ring, Retaining
8	4211334	Gasket, Mounting
9	4211308	Flange, Body
10	4211554	Container, Body Assembly
11	4211335	Screw
12	4211337	O-Ring
13	4211622	Trim, Shell Assembly
14	4211305	Screw, Backup
15	4211339	Clip, Shell Trim
16	4211444	Insulation, Top
17	4211302	Seal, Sink Flange

UPPER HOUSING AND MOTOR PARTS

For Model: GC4000XE



1	4211578	Kit, Sleeve And Seal (Includes Plug, Bolt, Washer, Slinger And Sleeve)
2	4211341	Plug
3	4211623	End Bell Assembly (Upper)
4	4211582	Rotor And Shaft Assembly
5	4211321	Washer
6	4211322	Centrifugal Actuator Assembly
7	4211619	Stator Assembly
8	4211515	End Frame Assembly (Lower)
9	4211348	Bolt, Thru
10	4211342	Shredder
11	4211344	Gasket, Tailpipe
12	4211317	Tailpipe
13	4211345	Flange, Tailpipe
14	4211346	Screw, Tailpipe
15	4211324	Switch Assembly Start
16	4211549	Protect, Overload
17	4211326	Shield, Wire
18	4211611	Cover, Terminal
19	4211612	Screw, Terminal Cover
20	4211330	Screw, Tailpipe
21	4211435	Wrench, Emergency
22	4211396	Adapter, Sink
23	4211565	Kit, Installation (Includes # 11, 12, 13 14, 21, Instructions, and Use and Care Guide)

LITERATURE PARTS

LIT4211613	Guide, Use And Care
LIT4211624	Instructions, Installation