

This Owner's Manual is provided and hosted by [Appliance Factory Parts](#).



# BIONAIRE BAP1525RCW-U Owner's Manual

[Shop genuine replacement parts for BIONAIRE  
BAP1525RCW-U](#)



[Find Your BIONAIRE Air Cleaner Parts - Select From 119 Models](#)

----- Manual continues below -----

## CLEANING AND MAINTENANCE

### CLEANING THE PERMAtech™ FILTER

The PERMAtech™ filter is designed to never need replacement. However, we recommend regular cleaning for optimal performance.

- Every few weeks, check the condition of the filter.
- After approximately 3 months of operation, a Filter Clean Indicator will alert you to clean the filter before further use.

#### TO CLEAN THE FILTER:

1. Turn off and unplug the air cleaner.
2. Remove the air inlet grill.
3. Remove and examine the foam pre-filter. If it has collected dust or lint, remove and wash it in warm soapy water. Rinse and drip dry thoroughly before placing it back into the grill inlet.
4. Check the condition of the PERMAtech™ filters and remove if dirty.
5. Clean the PERMAtech™ filter.

- Using your vacuum cleaner, run the brush attachment along both sides of the filter and clean between the pleated layers (Figure 2).




Figure 2

**IMPORTANT:** Do not use water, household cleaners or detergents to clean the PERMAtech™ filter.

### REINSTALLING THE PERMAtech™ FILTER AFTER CLEANING

**NOTE:** A hang tab and filter clips ensure the filter attaches properly.

1. Make sure the hang tab is securely in place. Align the clip on the top of the PERMAtech™ filter with the rails on the inside of the unit. Gently slide the filter onto the rail (see Figures 3 and 4).
2. Place air inlet grill back onto unit securely.




Figure 3




Figure 4

3. Reset the Filter Clean indicator by pressing the power button for 2 seconds.

Should the filter become damaged during cleaning, replacements are available by calling 1-800-253-2764.

## TIPS AND TROUBLESHOOTING

ISSUE	SOLUTION
Unit will not operate	<ul style="list-style-type: none"> <li>• Make sure the unit is plugged in and outlet is energized.</li> <li>• Make sure unit turned ON.</li> </ul>
Decreased airflow	<ul style="list-style-type: none"> <li>• Make sure nothing is blocking air inlet and filtered air outlets.</li> <li>• Remove all plastic bags from filters.</li> <li>• Check condition of filters and clean if necessary.</li> </ul>
PERMAtech™ filter appears dirty, even after vacuuming clean	<ul style="list-style-type: none"> <li>• This is normal and does not affect performance in any way. A new filter is not necessary.</li> </ul>
Excessive noise	<ul style="list-style-type: none"> <li>• Remove plastic bag(s) from filter(s).</li> <li>• Make sure parts are firmly positioned in place.</li> </ul>

## LEARNING MORE

For a wealth of information about your air cleaner and other Bonaire® products, visit our web site at [www.bonaire.com](http://www.bonaire.com).

## SERVICE & WARRANTY INFORMATION

### 5 YEAR LIMITED WARRANTY

Sunbeam Products, Inc. doing business as Jarden Consumer Solutions or if in Canada, Sunbeam Corporation (Canada) Limited doing business as Jarden Consumer Solutions (collectively "JCS") warrants that for a period of five years from the date of purchase, this product will be free from defects in material and workmanship. JCS, at its option, will repair or replace this product or any component of the product found to be defective during the warranty period. Replacement will be made with a new or remanufactured product or component. If the product is no longer available, replacement may be made with a similar product of equal or greater value. This is your exclusive warranty. Do NOT attempt to repair or adjust any electrical or mechanical functions on this product.

## AIR CLEANER SAFETY

# IMPORTANT SAFEGUARDS

When using electrical appliances, basic safety precautions should always be followed to reduce the risk of fire, electric shock, and injury to persons. These precautions include:


- Read all instructions before using the appliance.
- To avoid fire or shock hazard, plug the appliance directly into a 120V AC electrical outlet.
- If the filter is covered by a bag when shipped: Remove plastic bag before use.
- Keep the cord out of heavy traffic areas. To avoid fire hazard, NEVER put the cord under rugs, near heat registers, radiators, stoves, or heaters.
- To protect against electrical hazards, DO NOT immerse in water or other liquids. Do not use near water.
- Close supervision is necessary when any appliance is used by or near children, or disabled persons.
- Always unplug the air cleaner before moving or cleaning the unit, opening the grill, changing the filters and whenever the unit is not in use. To disconnect the unit, be sure to pull the plug and not the cord.
- NEVER drop or insert any objects into the openings of the unit.
- Do not operate any appliance with a damaged cord or plug. If the motor fan fails to operate or the unit has been dropped or damaged in any manner, return appliance to manufacturer for examination and/or repair.
- Use appliance only for intended household use as described in this manual. Any other use not recommended by the manufacturer may cause fire, electric shock, or injury to persons. The use of attachments not recommended or sold by Jarden Consumer Solutions may cause hazards.
- DO NOT use outdoors.
- NEVER place on a soft surface such as a bed or sofa as this could cause the unit to tip over and block the air inlet or outlet grills.
- Keep unit away from heated surfaces and open flames.
- DO NOT place anything on top of unit.
- DO NOT attempt to repair or adjust any electrical or mechanical functions on this unit. Doing so will void your warranty. The inside of the unit contains no user serviceable parts. All servicing should be performed by

Jarden Consumer Solutions or an authorized Jarden Consumer Solutions Service Center.

- **WARNING:** To reduce the risk of fire or electric shock, DO NOT use this air cleaner with any solid-state speed control device.
- Always turn the appliance off before unplugging it.
- NEVER use detergents, gasoline, glass cleaner, furniture polish, paint thinner or other household solvents to clean any part of the air cleaner.
- The ionizer may cause a static charge to build up on the air output grill. A static charge may be felt if the unit is not properly grounded. To avoid a static charge, plug the unit's three-prong plug into a grounded outlet, or properly install a ground adaptor (see PLUG SAFETY). The static charge will not occur if the ionizer is off.
- The ionizer in this appliance produces less ozone than the UL established limits of 50ppb. However, in high concentrations, ozone can be harmful to birds and small pets. To prevent ozone buildup, we suggest using the ionizer in well ventilated areas with the fan on.
- This appliance should only be used in a room with temperatures between 40° F and 110° F.

## PLEASE SAVE THESE INSTRUCTIONS

### PLUG SAFETY



To reduce the risk of electric shock, THIS PRODUCT IS EQUIPPED WITH A 3-PRONG PLUG, a grounding type plug that has a third (grounding) pin.

The cord has a plug (A) as shown. An adapter (C) can be purchased for connecting three-blade grounding-type plugs to two-slot receptacles (B).

The green grounding wire or lug extending from the adapter must be connected to a permanent ground such as a properly grounded outlet box. The adapter should not be used if a three-slot grounded receptacle is available.

This plug will only fit into a grounding type power outlet. If the plug does not fit into the outlet, contact qualified personnel to install the proper outlet.

This product is for use on 120 volts. DO NOT ALTER THE PLUG IN ANY WAY.

### CORD SAFETY

- The length of cord used on this appliance was selected to reduce tangling and tripping hazards.