

This Owner's Manual is provided and hosted by [Appliance Factory Parts](#).



SUNBEAM 645 Owner's Manual

[Shop genuine replacement parts for SUNBEAM 645](#)



[Find Your SUNBEAM Humidifier Parts - Select From 199 Models](#)

----- Manual continues below -----

TROUBLESHOOTING

TROUBLE	PROBABLE CAUSE	SOLUTION
Mist output minimal to none.	Impeller stem clogged.	Turn unit off and unplug from electrical outlet. Wait 30 minutes and then follow maintenance instructions.
	Top assembly dirty.	
	Moisture outlet blocked.	Keep moisture outlet clean and clear of any objects.
Water leaks from reservoir.	Top assembly is not locked on to reservoir.	Resnap top assembly to reservoir.
	Reservoir cracked.	Call customer services 1-888-264-9669.
Film on reservoir.	Mineral deposits cause film on tank to buildup.	Use Cleanse Clean® solution (S1710), to order call 1-888-264-9669.
Water cloudy.	Using warm water to refill tank.	Only use care products suggested by Sunbeam and cool water to refill tank.

© 2008 Sunbeam Products, Inc. doing business as Jarden Consumer Solutions. All Rights Reserved.
Distributed by Sunbeam Products, Inc. doing business as Jarden Consumer Solutions, Boca Raton, Florida 33431.

Printed In China

DIAGNOSTICO DE PROBLEMAS

PROBLEMA	POSIBLE CAUSA	SOLUCIÓN
Salida de vapor mínima o nula.	Vástago del impelente obstruido.	Apague y desconecte del tomacorriente. Espere 30 minutos y luego siga las instrucciones de mantenimiento.
	Conjunto superior sucio.	
	Salida de humedad bloqueada.	Mantenga la salida de humedad limpia y despejada.
Fuga de agua del depósito.	Conjunto superior no está ajustado en el depósito.	Vuelva a encajar el conjunto superior al depósito.
	Depósito agrietado.	Llame a servicio al consumidor al 1-888-264-9669.
Película en depósito.	La acumulación de depósitos minerales forman una película en el tanque.	Use solución Cleanse Clean® (S1710), para ordenar 1-888-264-9669.
Agua turbia.	Usó agua tibia para llenar el tanque.	Utilice únicamente los productos de cuidado sugeridos por Sunbeam y

WARRANTY

1 YEAR LI

Sunbeam Products, Inc. doing business as Jarden Consumer Solutions Limited doing business as Jarden Consumer Solutions, the date of purchase, this product will be free from defect or replace this product or any component of the product. Replacement will be made with a new or remanufactured replacement may be made with a similar product of equal or better quality. We will attempt to repair or adjust any electrical or mechanical defect. This warranty is valid for the original retail purchaser. Keep the original sales receipt. Proof of purchase is required. Retail centers, or retail stores selling JCS products do not have authority to void conditions of this warranty.

This warranty does not cover normal wear of parts or damage due to misuse of the product, use on improper voltage or current, or repair or alteration by anyone other than JCS or an authorized service center. Acts of God, such as fire, flood, hurricanes and

What are the limits on JCS's Liability?

JCS shall not be liable for any incidental or consequential damages, statutory warranty or condition.

Except to the extent prohibited by applicable law, any warranty for a particular purpose is limited in duration to the duration of the product. JCS disclaims all other warranties, conditions or representations. JCS shall not be liable for any damages of any kind, including incidental, special, consequential or punitive damages, the product including incidental, special, consequential or punitive damages, contract, fundamental or otherwise, or for any claim or damages. Some provinces, states or jurisdictions do not allow the exclusion or limitations on how long an implied warranty lasts, or the limitation of remedies. This warranty gives you specific legal rights, and you may vary from state to state or jurisdiction to jurisdiction.

How to Obtain Warranty Service

In the U.S.A.

If you have any question regarding this warranty or need assistance, call 1-888-264-9669 and a convenient service center address.

In Canada

If you have any question regarding this warranty or need assistance, call 1-888-264-9669 and a convenient service center address.

In the U.S.A., this warranty is offered by Sunbeam Products, Inc. in Boca Raton, Florida 33431. In Canada, this warranty is offered by Sunbeam Products, Inc. doing business as Jarden Consumer Solutions, located at 2000 West Beaver Creek Road, Richmond Hill, Ontario L4B 1N2. For any other problem or claim in connection with this product, please contact your local service center. **DO NOT RETURN THIS PRODUCT TO ANY OF OUR SERVICE CENTERS.**

INFORMACION

GARANTÍA

Sunbeam Products, Inc. operando bajo el nombre de Sunbeam Products, Inc. (Canada) Limited operando bajo el nombre de Jarden Consumer Solutions Limited, la fecha de compra, este producto estará libre de defectos o se reemplazará este producto o cualquier componente del producto. El reemplazo será hecho con un nuevo o reemplazado con un producto similar de igual o mejor calidad. Intentaremos reparar o ajustar cualquier defecto eléctrico o mecánico. Esta garantía es válida para el comprador minorista original. Mantenga el recibo de compra original. La prueba de compra es necesaria. Los centros de venta minorista que venden productos JCS no tienen autoridad para anular las condiciones de esta garantía.

Esta garantía no cubre el desgaste normal de las piezas, daño debido al uso incorrecto del producto, uso de voltaje incorrecto, o reparación o alteración por parte de alguien que no es un centro de servicio autorizado por JCS. Asimismo, la garantía no cubre actos fortuitos o daños causados por incendios, inundaciones, huracanes y otros fenómenos naturales.


¿Cuál es el límite de responsabilidad de JCS?
JCS no será responsable de daños incidentales o emergentes, incluidos los daños a la propiedad. Esta garantía expresa, implícita o legal.

Excepto en la medida en que lo prohíba la ley aplicable, JCS no se compromete a ningún límite de responsabilidad por daños incidentales o emergentes.

PLEASE READ AND SAVE THESE IMPORTANT SAFETY INSTRUCTIONS

When using electrical appliances, basic safety precautions should always be followed to reduce the risk of fire, electric shock, and injury to persons, including the following:

1. Read all instructions prior to use.
2. Always place unit on a flat, level surface AWAY from direct sunlight or computers or other sensitive electronic equipment. A waterproof pan, tray, mat or drop cloth is recommended: exposure to excess water or moisture can cause damage to some surfaces.
3. DO NOT place the appliance near heating devices. Keep cord away from heavy traffic areas and DO NOT place cord under rugs or allow cord to hang over a countertop or table where it can be pulled on or tripped over.
4. Supervision is recommended when a humidifier is used near children, invalids or pets.
5. Position the unit so mist stream is aimed away from children, walls and furniture.
6. DO NOT use outdoors.
7. Use only 120V AC outlet. Be sure unit is plugged in firmly and completely. As with any electrical device, plug and unplug unit with dry hands only.
8. To avoid the risk of fire, shock or personal injury, do not use an extension cord.
WARNING: Never operate unit with a damaged cord or plug.
9. Fill water tank to the bottom of the fill line. DO NOT OVERFILL. DO NOT block moisture outlet. This will damage the humidifier.



THIS APPLIANCE HAS A POLARIZED PLUG (one blade is wider than the other). To reduce the risk of electric shock, this plug is intended to fit in a polarized outlet only one way. If the plug does not fit fully in the outlet, reverse the plug. If it still does not fit, contact a qualified electrician to install the proper outlet.

DO NOT ATTEMPT TO MODIFY THIS PLUG OR DEFEAT THIS SAFETY FEATURE IN ANY WAY.

10. DO NOT add medication of any type into the moisture outlet or water container. Do not cover or place anything over any opening. Never drop or insert any object into any openings.
11. **WARNING:** Turn the humidifier off by unplugging the unit when not in use, before moving, filling or cleaning. NEVER tilt, move or attempt to empty the tank while unit is operating. Failure to heed this warning may cause personal injury.
12. Always unplug humidifier when not in use.
13. Use this appliance only for its intended household use as described in this manual. Any other use not recommended by the manufacturer may cause fire, electric shock or injury to persons and property damage.
14. **DANGER:** To guard against electric shock, NEVER immerse the humidifier motor (upper housing) in water or other liquids.
15. Regular cleaning of the unit is needed. Please refer to the CLEANING section in this manual.

PLEASE READ AND SAVE THESE IMPORTANT SAFETY INSTRUCTIONS

OPERATING

Consumer Safety Information

NOTE: This is an electrical appliance and requires attention when in use.

NOTE: If moisture forms on the walls or windows of room, turn off the humidifier. The room already has plenty of humidity and additional moisture may cause damage.

Cord and Plug Installation Safety Instructions

The length of cord used on this appliance was selected to reduce the hazards of becoming tangled in, or tripping over a longer cord. If a longer cord is necessary an approved extension cord may be used. The electrical rating of the extension cord must be equal to or greater than the rating of the humidifier (refer to the rating information placed on the humidifier). Care must be taken to arrange the extension cord so that it will not drape over the countertop or tabletop where it can be pulled on by children or accidentally tripped over.

OPERATING INSTRUCTIONS

WARNING: To protect against electrical shock, always unplug your humidifier when not in use, before cleaning, rinsing, filling or moving. When in use, the motor assembly must be positioned on the water container for proper operation.

1. To remove the motor assembly, lift it directly up from the water container (See Figure 1). Always rinse and empty the water container before filling and after use.
2. Fill water container.
 - Always unplug the unit, lift top of unit and place upside down to avoid damage to the impeller stem (See Figure 3).

LEA Y CONSERVE ESTAS IMPORTANTES INSTRUCCIONES DE SEGURIDAD

Debe tomar precauciones básicas de seguridad siempre que utilice artefactos eléctricos para reducir el riesgo de incendio, descarga eléctrica y daños personales, incluyendo lo siguiente:

1. Lea todas las instrucciones antes de usar.
2. Ponga siempre la unidad sobre una superficie plana, nivelada LEJOS de la luz directa del sol o de las computadoras o de otros equipos electrónicos delicados. Se recomienda una cacerola a prueba de agua, bandeja, estera o paño; la exposición a un exceso de agua o de humedad puede causar daño a algunas superficies.
3. NO coloque el artefacto cerca de los aparatos de la calefacción. Mantenga el cordón alejado de las áreas de circulación y NO coloque el cordón debajo de alfombras ni permita que el cordón cuelgue sobre una repisa o una mesa desde donde pueda ser jalada o pueda enredarse.
4. Se recomienda la supervisión cuando un humectador se utilice cerca de niños, de inválidos o de mascotas.
5. Coloque la unidad de modo que la corriente de niebla esté dirigida lejos de los niños, de las paredes

10. No agregue medicación de ningún tipo dentro del orificio de salida de humedad, ni del envase del agua. No cubra ni ponga ningún objeto sobre ninguna abertura. Nunca deje caer o inserte ningún objeto dentro de ninguna de las aberturas.
11. **ADVERTENCIA:** Apague el humectador desenchufando la unidad cuando no esté en uso, antes de moverlo, de llenarlo o de limpiarlo. NUNCA la incline, ni la mueva ni intente vaciar el tanque mientras la unidad está operando. La falta de prestar atención a esta advertencia puede causar lesión personal.
12. Desenchufe siempre el humectador cuando no esté en uso.
13. Utilice este artefacto solamente para su uso previsto en la casa según lo descrito en este manual. Cualquier otro uso no recomendado por el fabricante puede causar incendios, descargas eléctricas o lesión a las personas y daño a la propiedad.
14. **PELIGRO:** Para cuidarse contra choque eléctrico, NUNCA sumerja el motor del humectador (alojamiento superior) en agua ni en otros líquidos

CARACTERÍSTICAS

Información de Seguridad para el Consumidor

NOTA: Este es un artefacto eléctrico y requiere ser usado con cuidado.

NOTA: Si se acumula humedad en las paredes o ventanas del cuarto, apague el humidificador. El cuarto ya tiene demasiada humedad y la humedad adicional puede causar daños.

Instrucciones de Seguridad en la Instalación del Cable y el Enchufe

La longitud del cable de este artefacto fue seleccionada para reducir el riesgo de enredarse o tropezarse con cable más largo. Si necesita usar un cable más largo, puede utilizar un cable de extensión aprobado. La capacidad eléctrica del cable de extensión debe ser igual o mayor que la capacidad del humidificador (consulte la información de capacidad que aparece en el humidificador). No debe permitir que el cable de extensión cuelgue de la mesada o mesa de tal forma que pueda ser jalado por niños o causar que alguien se tropiece.