

This Owner's Manual is provided and hosted by [Appliance Factory Parts](http://www.appliancefactoryparts.com).



SUNBEAM 1388-800 Owner's Manual

**[Shop genuine replacement parts for SUNBEAM
1388-800](#)**



[Find Your SUNBEAM Humidifier Parts - Select From 199 Models](#)

----- Manual continues below -----

TROUBLE SHOOTING


TROUBLE SHOOTING

No steam / Too little steam

Low mineral content in water, dissolve 1/8 teaspoon of salt (no more) per gallon of water (First Use Only)

Clogged water inlet hole. See Cleaning and Maintenance section


Electrical outlet doesn't work. Test a working appliance



Too little steam

Too much steam, spitting, loud boiling, hot cord


High mineral content in water. Dilute water with distilled, de-mineralized or rain water



Too much steam

Mineral deposits build-up

Clean debris from inlet hole



Mineral deposits

© 2008 Sunbeam Products, Inc. doing business as Jarden Consumer Solutions. All Rights Reserved.

Distributed by Sunbeam Products, Inc. doing business as Jarden Consumer Solutions, Boca Raton, Florida 33431.

Printed in china

WARRANTY

1 YEAR

Sunbeam Products, Inc. doing business as Jarden Consumer Solutions Limited doing business as Jarden Consumer Solutions. From the date of purchase, this product will be free of charge or replace this product or any component of the product. Replacement will be made with a new or remanufactured replacement may be made with a similar product. We will attempt to repair or adjust any electrical or mechanical problem. This warranty is valid for the original retail purchaser. Keep the original sales receipt. Proof of purchase may be obtained at retail centers, or retail stores selling JCS products do not honor the conditions of this warranty.

This warranty does not cover normal wear of product, misuse of the product, use on improper voltage, or repair or alteration by anyone other than JCS or its authorized cover: Acts of God, such as fire, flood, hurricane, etc.

What are the limits on JCS's Liability

JCS shall not be liable for any incidental or consequential damages, statutory warranty or condition.

Except to the extent prohibited by applicable law, the warranty for a particular purpose is limited in duration to the duration of the JCS disclaims all other warranties, conditions or representations. JCS shall not be liable for any damages of any kind, including incidental, special, consequential, fundamental or otherwise, or for any loss of time.

Some provinces, states or jurisdictions do not allow the exclusion or limitations on how long an implied warranty lasts.

This warranty gives you specific legal rights, and these rights may vary from state to state or jurisdiction to jurisdiction.

How to Obtain Warranty Service

In the U.S.A.

If you have any question regarding this warranty, call 1-888-264-9669 and a convenient service center.

In Canada

If you have any question regarding this warranty, call 1-888-264-9669 and a convenient service center.

In the U.S.A., this warranty is offered by Sunbeam Products, Inc. doing business as Jarden Consumer Solutions, located in Boca Raton, Florida 33431. In Canada, this warranty is offered by Sunbeam Products, Inc. doing business as Jarden Consumer Solutions, located in Boca Raton, Florida 33431.

DO NOT RETURN THIS PRODUCT TO ANY SERVICE CENTER

DIAGNOSTICO DE PROBLEMAS


SOLUCION DE FALLAS

No hay vapor / Muy poco vapor

Bajo contenido mineral en el agua, disuelva 1/8 cucharilla de sal (no más) por galón de agua (primero únicamente)

Orificio de agua obstruido. Ver sección de Limpieza y Mantenimiento

El tomacorrientes no trabaja. Pruebe un artefacto que trabaje



Muy poco vapor

Demasiado vapor, salpicando, ruidoso, hirviendo, cordón caliente

Alto contenido mineral en el agua. Diluya el agua con agua destilada, desmineralizada o agua de lluvia



INFORMACION

GARAN

Sunbeam Products, Inc. operando bajo el nombre de Sunbeam Products, Inc. (Canada) Limited operando bajo el nombre de Sunbeam Products, Inc. (Canada) Limited. Esta garantía es válida para el comprador minorista. La garantía es transferible. Conserve el recibo de compra original. Esta garantía no cubre el desgaste normal de la máquina. Esta garantía no cubre el uso negligente o mal uso del producto, uso de voltaje incorrecto, desarme, reparación o alteración por JCS. Asimismo, la garantía no cubre actos de fuerza mayor.

La garantía es válida para el comprador minorista. Conserve el recibo de compra original. Esta garantía no cubre el desgaste normal de la máquina. Esta garantía no cubre el uso negligente o mal uso del producto, uso de voltaje incorrecto, desarme, reparación o alteración por JCS. Asimismo, la garantía no cubre actos de fuerza mayor.

Esta garantía no cubre el desgaste normal de la máquina. Esta garantía no cubre el uso negligente o mal uso del producto, uso de voltaje incorrecto, desarme, reparación o alteración por JCS. Asimismo, la garantía no cubre actos de fuerza mayor.

Esta garantía no cubre el desgaste normal de la máquina. Esta garantía no cubre el uso negligente o mal uso del producto, uso de voltaje incorrecto, desarme, reparación o alteración por JCS. Asimismo, la garantía no cubre actos de fuerza mayor.

Esta garantía no cubre el desgaste normal de la máquina. Esta garantía no cubre el uso negligente o mal uso del producto, uso de voltaje incorrecto, desarme, reparación o alteración por JCS. Asimismo, la garantía no cubre actos de fuerza mayor.

Esta garantía no cubre el desgaste normal de la máquina. Esta garantía no cubre el uso negligente o mal uso del producto, uso de voltaje incorrecto, desarme, reparación o alteración por JCS. Asimismo, la garantía no cubre actos de fuerza mayor.

PLEASE READ AND SAVE THESE IMPORTANT SAFETY INSTRUCTIONS

When using electrical appliances, basic safety precautions should always be followed. Failure to follow these safety precautions may result in personal injury, property damage, fire or shock.


1. Read all instructions prior to use.
2. Always place unit of a flat, level surface AWAY from direct sunlight or computers or other sensitive electronic equipment. A waterproof pan, tray, mat or drop cloth is recommended: exposure to excess water or moisture can cause damage to some surfaces.
3. DO NOT place the appliance near heating devices. Keep cord away from heavy traffic areas and DO NOT place cord under rugs or allow cord to hang over a countertop or table where it can be pulled on or tripped over.
4. NEVER place a vaporizer where it is accessible to children.
5. CAUTION: To reduce risk of burns, supervision is recommended when a vaporizer is used near children, invalids or pets.
6. Position the unit so mist stream is aimed away from children, walls and furniture.
7. DO NOT use outdoors.
8. Use only 120V AC outlet. Be sure unit is plugged in firmly and completely. As with any electrical device, plug and unplug unit with dry hands only.
9. To avoid the risk of fire, shock or personal injury, do not use an extension cord. **WARNING:** Never operate unit with a damaged cord or plug.
10. Fill water tank to the bottom of the fill line. DO NOT OVERFILL. DO NOT block moisture outlet. This will damage the vaporizer.
11. DO NOT add medication of any type into the moisture outlet or water container. Do not cover or place anything over any opening. Never drop or insert any object into any openings.
12. Turn the vaporizer off by unplugging the unit when not in use, before moving, filling or cleaning. NEVER tilt, move or attempt to empty the tank while unit is operating. Wait 15 minutes (or until cool) after unit is turned off and unplugged before attempting to refill water tank.
13. DO NOT touch unit or steam vapor during use. Steam is hot and burns can occur.
14. Use this appliance only for its intended household use as described in this manual. Any other use not recommended by the manufacturer may cause fire, electric shock or injury to persons and property damage.
15. **DANGER:** To guard against electric shock, NEVER immerse the vaporizer head (upper housing) in water or other liquids.
16. Regular cleaning of the unit is needed. Please refer to the CLEANING section in this manual.

PLEASE READ AND SAVE THESE IMPORTANT SAFETY INSTRUCTIONS

Consumer Safety Information

NOTE: This is an electrical appliance and requires attention when in use.

NOTE: If moisture forms on the walls or windows of the room, turn off the humidifier. The room already has plenty of humidity and additional moisture may cause damage.



THIS APPLIANCE HAS A POLARIZED PLUG (one blade is wider than the other). To reduce the risk of electric shock, this plug is intended to fit in a polarized outlet only one way. If the plug does not fit fully in the outlet, reverse the plug. If it still does not fit, contact a qualified electrician to install the proper outlet.

DO NOT ATTEMPT TO MODIFY THIS PLUG OR DEFEAT THIS SAFETY FEATURE IN ANY WAY.

LEA Y CONSERVE ESTAS IMPORTANTES INSTRUCCIONES DE SEGURIDAD

Al usar artefactos eléctricos, siempre deben seguirse las medidas de seguridad básicas. La falla de seguir estas medidas de seguridad puede dar lugar a lesión personal, daño de la propiedad, incendio o electro-choque.

1. Lea todas las instrucciones antes de usar.
2. Ponga siempre la unidad sobre una superficie plana, nivelada LEJOS de la luz directa del sol o de las computadoras o de otros equipos electrónicos delicados. Se recomienda una cacerola a prueba de agua, bandeja, estera o paño; la exposición a un exceso de agua o de humedad puede causar daño a algunas superficies.
3. NO coloque el artefacto cerca de los aparatos de la calefacción. Mantenga el cordón alejado de las áreas de circulación y NO coloque el cordón debajo de alfombras ni permita que el cordón cuelgue sobre una repisa o una mesa desde donde pueda ser jalada o pueda enredarse.
4. NUNCA coloque un vaporizador donde sea accesible a los niños.
5. CUIDADO: Para reducir el riesgo de quemaduras, se recomienda supervisar cuando se utilice un vaporizador
11. No agregue medicación de ningún tipo dentro del orificio de salida de humedad, ni del envase del agua. No cubra ni ponga ningún objeto sobre ninguna abertura. Nunca deje caer o inserte ningún objeto dentro de ninguna de las aberturas.
12. Apague el vaporizador desenchufando la unidad cuando no esté en uso, antes de moverlo, de llenarlo o de limpiarlo. NUNCA la incline, ni la mueva ni intente vaciar el tanque mientras la unidad está ope 15 minutos (o hasta que enfrie) después que la unidad se apaga y se desenchufa antes de intentar rellenar el tanque de agua.
13. NO toque la unidad ni el vapor de agua durante el uso. El vapor está caliente y le pueden ocurrir quemaduras.
14. Utilice este artefacto solamente para su uso previsto en la casa según lo descrito en este manual. Cualquier otro uso no recomendado por el fabricante puede causar incendios, descargas eléctricas o lesión a las personas y daño a la propiedad.
15. **PELIGRO:** Para cuidarse contra choque eléctrico, NUNCA

OPERATING INSTRUCTIONS

Cord and Plug Installation Safety Instructions


The length of cord used on this appliance was selected to reduce the hazards of becoming tangled in, or tripping over a longer cord. If a longer cord is necessary, an approved extension cord may be used. The electrical rating of the extension cord must be equal to or greater than the rating of the humidifier (refer to the information placed on the humidifier). Care must be taken to arrange the extension cord so that it will not drape over the countertop or tabletop where it could be pulled on by children or accidentally tripped over.

OPERATING INSTRUCTIONS

WARNING: To protect against electrical shock, unplug your vaporizer when not in use, before rinsing, filling or moving. When in use, the vaporizer head must be positioned on the water container for proper operation.

1. To remove the vaporizing head, turn counter-clockwise and lift up (See Figure 1). Always rinse and refill the water container before filling and after use.

Figure 1



2. Fill water container.
 - Always unplug vaporizer when inserting water. Always remove the vaporizing head.
 - Fill water container with cool tap water to the "Top Full" line (See Figure 2).
 - DO NOT fill the container higher than the "Top Full" line.

CARACTERÍSTICAS

Información de Seguridad para el Consumo

NOTA: Este es un artefacto eléctrico y requiere ser usado con cuidado.

NOTA: Si se acumula humedad en las paredes o en las ventanas del cuarto, apague el humidificador. Si el cuarto ya tiene demasiada humedad y la humedad adicional puede causar daños.

Instrucciones de seguridad en la instalación del cable y el enchufe

La longitud del cable de este artefacto fue seleccionada para reducir el riesgo de enredarse o tropezarse con un cable más largo. Si necesita usar un cable más largo, puede utilizar un cable de extensión aprobado. La capacidad eléctrica del cable de extensión debe ser igual o mayor que la capacidad del humidificador (consulte la información de capacidad que aparece en el humidificador). No debe permitir que el cable de extensión cuelgue sobre una mesada o mesa de tal forma que pueda ser jalado por niños o causar que alguien se tropiece.