

This Owner's Manual is provided and hosted by [Appliance Factory Parts](#).



CUISINART 7BSR-28 Owner's Manual

**[Shop genuine replacement parts for CUISINART
7BSR-28](#)**



[Find Your CUISINART Small Appliance Parts - Select From 213 Models](#)

----- Manual continues below -----

■ TO BREAK A VACUUM SEAL

The uniquely designed rims and covers form a perfect fit to reduce the evaporation of liquids. If you leave the cover on after turning the heat down or off, a partial vacuum may form that will seal the lid to the pan. To break the seal, turn on the heat for a few moments, and the cover will come off easily. If you don't want the lid to seal to the pan, remove the cover or set it slightly ajar before turning off the heat.

■ CONVENIENT STORAGE

Store in original box or in cupboard with ample space for convenient, safe storage.

LIMITED LIFETIME WARRANTY

Your Cuisinart® Buffet Server is warranted to be free of defects in material and workmanship under normal home use from the date of original purchase throughout the original purchaser's lifetime. If your cookware should prove to be defective within your lifetime, we will repair it or, if we think it necessary, replace it. To obtain warranty service, please call our Consumer Service Center toll-free at 1-800-726-0190, or write to Consumer Service Center, Cuisinart, 150 Milford Road, East Windsor, NJ 08520.

To facilitate the speed and accuracy of your return, please also enclose \$7.00 for shipping and handling of the product. Please also be sure to include a return address, phone number, description of the product problem, and any other information pertinent to the product's return. Please pay by check or money order.


This warranty excludes damage caused by accident, misuse or abuse, including damage caused by overheating, and it does not apply to scratches, stains, discoloration or other damage to external or internal surfaces which does not impair the functional utility of the cookware.

This warranty also expressly excludes all incidental or consequential damages. Some states do not allow the exclusion or limitation of incidental or consequential damages, so the foregoing limitation or exclusion may not apply to you.

This warranty gives you specific legal rights, and you may also have other rights which vary from state to state.

CALIFORNIA RESIDENTS ONLY

California residents need only supply proof of purchase and should call 1-800-726-0190 for shipping instructions. California law provides that for In-Warranty Service, California residents have the option of returning a nonconforming product (a) to the store where it was purchased or (b) to another retail store which sells Cuisinart® products of the same type. The retail store shall then, according to its preference, either repair the product, refer the consumer to an independent repair facility, replace the product, or refund the purchase price less the amount directly attributable to the consumer's prior usage of the product. If either of the above two options does not result in the appropriate relief to the consumer, the consumer may then take the product to an independent repair facility if service or repair can be economically accomplished. Cuisinart, and not the consumer, will be responsible for the reasonable cost of such service, repair, replacement or refund for nonconforming products under warranty. California residents may also, according to their preference, return nonconforming products directly to Cuisinart for repair, or if necessary, replacement, by calling our Customer Service Center toll-free at 1-800-726-0190.



Buffet Servers

Use and Care Guide

© 2005 Cuisinart®
Cuisinart® is a registered trademark of Cuisinart.
150 Milford Road, East Windsor, NJ 08520
Printed in China 05CU26479

*Any trademark or service marks of third parties used herein are the trademarks or service marks of their respective owners.

IB-6340

Cuisinart® worth every or in the oven stand to eleg aluminum and even be properly can years of ser this booklet

■ **ESSENT**
Never use will burn. cookware h distribution most cooki leave your hot burner stovetop. N the oven. cooked. It warm and to Use War buffet pan

■ **BEFORE**
Wash your dishwashing time. Rinse dish towel.

■ **HOW TO**
The warmi already coo candles, pla will be serv smokeless, cup holders before use. on warmi They can l brand. DO KEEP OU AREA WH CURTAIN finish ser the server l ***IMPORT** tea light ca be used. D ANY OTH SCENTED

****CAUTIO**
buffet serv may create

■ **CARBON**
Carbon spe pan after u cleaned off sprinkle wi dishwashin ***NOTE:** D different a

■ **EASY M**
Immediate dishwashin