



1 Items to Assemble

- 1 Long Leg Assembly
- 1 Short Leg Assembly
- 8 Screws




CAUTION: Ends of screws have sharp points




2 Items to Assemble

- 2 U-Nuts
- 1 U-Nut
- 1 Cylinder Thumbscrew
- 2 Wheels
- 1 Axle Rod
- 2 Flat Washers
- 1 Hitch Pin





3 Items to Assemble

- 4 Balls (all identical)
- 10 Screws




4 Items to Assemble

- 1 Front Panel
- 2 Push Pins




5 Items to Assemble

- 1 Compartment Basket
- 1 Push Pin




6 Items to Assemble

- 2 U-Nuts




1 Items to Assemble

- 1 Long Leg Assembly
- 1 Short Leg Assembly
- 8 Screws




CAUTION: Ends of screws have sharp points




2 Items to Assemble

- 2 U-Extenders
- 1 U-Nut
- 1 Cylinder Thumbscrew
- 2 Wheels
- 1 Axle Rod
- 2 Flat Washers
- 1 Hitch Pin





3 Items to Assemble

- 4 Balls (all identical)
- 10 Screws




4 Items to Assemble

- 1 Front Panel
- 2 Push Pins




5 Items to Assemble

- 1 Compartment Basket
- 1 Push Pin




6 Items to Assemble

- 2 U-Nuts



Parts List - Model 463453207

Key	Qty.	Description	Part #	Key	Qty.	Description	Part #
A	1	Bottom Shelf	7000506	AA	1	Electrode	7000047
B	4	Rails	7000285	BB	1	Ignition Button	7000161
C	1	Top Casting	7001019	CC	1	Sticumer Body	7000516
D	1	Lego Plate Assy	4157147	DD	1	Frame Insert	7001184
E	1	Temperature Gauge w/Temp Nul	4157171	EE	1	Wing Nul	4080063
F	1	Temperature Gauge Bezel	4157169	FF	1	Sticumer Handle	7000059
G	1	Bottom Casting	7000510	GG	2	Washer Head Hex Nuts	7000271
H	4	Burners	7000039	HH	1	'S' Hook Knobholder	7000346
I	1	Carry-Over Tube	7000280	II	1	Sticumer Lid	7000303
J	2	Pat Nuts	7000132	JJ	1	Rod Hinge	7000384
K	1	'U' Nul	7001640	KK	1	Sticumer Lid Handle	7000385
L	2	Casting Bumpers	7000184	LL	1	Shelf	7000517
M	1	Handle Assy	7000178	MM	1	Front Panel	7000518
N	1	Condiment Basket	7000370	NN	1	Warning Hack	7000187
O	2	Wheels	7000262	OO	1	Cook Grid, 8x15	7001107
P	1	Axle Rod	7001149	PP	2	Cook Grids, 12x15	7000026
Q	4	Vaporizer Tents	7000381	QQ	1	Sticumer Grid	7000304
R	1	Grease Tray Assy	7000043	RR	4	10x3/8 Self-Tap Screw	7001017
S	1	Grease Pan	7000046	SS	1	Veveh Hose/Regulator	7000089
T	1	Sticumer Burner	7001244	TT	1	Control Panel	7000752
U	2	'U' Nuts	7001659	UU	1	Ignition Module	7000944
V	1	Fascia, Right	7000672	VV	1	24" Igniter Wire	7000894
W	1	Fascia, Left	7000748	WW	1	Leg Assembly Long	7000522
X	2	Leg Extenders	7000230	XX	1	Leg Assembly Short	7000353
Y	5	Control Knobs	7000689	YY	1	Thumbcrew	7000525
Z	5	Bezels	7000912	ZZ	1	Hardware Bag	7001657



Char-Broil

PERFORMANCE SERIES™

KEEPSERS OF THE FLAME

ASSEMBLY MANUAL
463453207

THIS GRILL IS FOR
OUTDOOR USE ONLY

CAUTION: Read and follow all safety statements, assembly instructions and use and care directions before attempting to assemble and cook.

INSTALLER/ASSEMBLER: Leave these instructions with consumer.

WARNING: Failure to follow all manufacturer's instructions could result in serious personal injury and/or property damage.

CAUTION: Some parts may contain sharp edges - especially as noted in the manual. Wear protective gloves if necessary.

If you have any questions or need assistance during assembly, please call: 1-800-241-7548.
Visit us on the Web: www.charbroil.com

PRECISION GRILLING TECHNOLOGY