


EXPLODED VIEW

DOOR PARTS


Model: SCB2000FWW
SCB2000FBB
SCB2000FCC
SCB2001FSS
SCB2001KSS



P/No.:3828W5S4719

OVEN CAVITY PARTS


Model: SCB2000FWW
SCB2000FBB
SCB2000FCC
SCB2001FSS
SCB2001KSS




LATCH BOARD PARTS

Model: SCB2000FWW
SCB2000FBB
SCB2000FCC
SCB2001FSS
SCB2001KSS

¥ LEFT




¥ RIGHT



INTERIOR PARTS (I)


Model: SCB2000FWW
SCB2000FBB
SCB2000FCC
SCB2001FSS
SCB2001KSS



INTERIOR PARTS (II-I)

Model: SCB2000FBB 02
SCB2000FCC 02
SCB2000FWW 02
SCB2001FSS 02
SCB2001KSS 01

Check the rating label of Model and order SVC parts according to the Model No.



INTERIOR PARTS (II-II)

Model: SCB2000FBB 03
SCB2000FCC 03
SCB2000FWW 03
SCB2001KSS 02

Check the rating label of Model and order SVC parts according to the Model No.

