



# EXPLODED VIEW

## DOOR PARTS

For Model :  
JVM1540DMWW  
JVM1540DMBB  
JVM1540DMCC  
JNM1541DMWW  
JNM1541DMBB  
JNM1541DMCC  
HVM1540DMWW  
HVM1540DMBB



For Model :  
JVM1540SMSS  
JVM1540LMCS  
JNM1541SMSS  
HVM1540LMCS  
HVM1540SMSS




For Model:  
JVM1540LMCS only  
HVM1540LMCS

# CONTROLLER PARTS


For Model :  
 JVM1540MWW  
 JVM1540DMBB  
 JVM1540DMCC  
 JNM1541DMWW  
 JNM1541DMBB  
 JNM1541DMCC  
 HVM1540MWW  
 HVM1540DMBB

For Model:  
 JVM1540DMBB  
 JNM1541DMBB  
 HVM1540DMBB  
 (WTT027)

For Model:  
 JVM1540MWW  
 JVM1540DMCC  
 JNM1541DMWW  
 JNM1541DMCC  
 HVM1540MWW  
 (WTT029)




For Model :  
 JVM1540SMSS  
 JVM1540LMCS  
 JNM1541SMSS  
 HVM1540LMCS  
 HVM1540SMSS






# LATCH BOARD PARTS







# INTERIOR PARTS (II)



# INSTALLATION PARTS



For Model :  
JVM1540DMWW  
JVM1540DMBB  
JVM1540DMCC  
JVM1540SMSS  
JVM1540LMCS  
HVM1540DMWW  
HVM1540DMBB  
HVM1540LMCS  
HVM1540SMSS



OWNERS  
MANUAL

\*01

INSTALLATION  
MANUAL

\*04

COOKING  
GUIDE  
LABEL

\*05

TEMPLATE

\*06