



EXPLODED VIEW

DOOR PARTS

For Model :
JVM1540DMWW
JVM1540DMBB
JVM1540DMCC
JNM1541DMWW
JNM1541DMBB
JNM1541DMCC
HVM1540DMWW
HVM1540DMBB



For Model :
JVM1540SMSS
JVM1540LMCS
JNM1541SMSS
HVM1540LMCS
HVM1540SMSS




P/No: MFL32357701

CONTROLLER PARTS


For Model :
JVM1540MWW
JVM1540DMBB
JVM1540DMCC
JNM1541DMWW
JNM1541DMBB
JNM1541DMCC
HVM1540MWW
HVM1540DMBB

For Model:
JVM1540DMBB
JNM1541DMBB
HVM1540DMBB
WTT027

For Model:
JVM1540MWW
JVM1540DMCC
JNM1541DMWW
JNM1541DMCC
HVM1540MWW
WTT029




For Model :
JVM1540SMSS
JVM1540LMCS
JNM1541SMSS
HVM1540LMCS
HVM1540SMSS




OVEN CAVITY PARTS

For Model :
 JVM1540SMSS
 JVM1540LMCS
 JNM1541SMSS
 HVM1540LMCS
 HVM1540SMSS



33531A

For Model :
 JVM1540DMWW
 JVM1540DMBB
 JVM1540DMCC
 JNM1541DMWW
 JNM1541DMBB
 JNM1541DMCC
 HVM1540DMWW
 HVM1540DMBB



33530A

For Model:
 JVM1540DMWW
 JVM1540DMCC
 JNM1541DMWW
 JNM1541DMCC
 HVM1540DMWW

WTT029



For Model:
 JVM1540DMBB
 JNM1541DMBB
 HVM1540DMBB
 JVM1540SMSS
 JVM1540LMCS
 JNM1541SMSS
 HVM1540LMCS
 HVM1540SMSS

WTT027

WTT028

34960A

WTT028




34021A

WTT029

WTT027


34810Q

33112U



34930R


33052A



35026G

63303A


368771




33550L

56804A

63302A




36912C



35230A

WTT010

WTT047




34890C

WTT010


WTT020

34810T


LATCH BOARD PARTS




INTERIOR PARTS (I)




INTERIOR PARTS (II)



INSTALLATION PARTS



For Model :
JVM1540DMWW
JVM1540DMBB
JVM1540DMCC
JVM1540SMSS
JVM1540LMCS
HVM1540DMWW
HVM1540DMBB
HVM1540LMCS
HVM1540SMSS



OWNERS
MANUAL

*01

INSTALLATION
MANUAL

*04

COOKING
GUIDE
LABEL

*05

TEMPLATE

*06