


EXPLODED VIEW

DOOR PARTS


MODEL: ZSC1000KBB
ZSC1001KSS



DOOR JIG



9382




HARDWARE BAG

P/NO: 3828W5S6165


CONTROLLER PARTS

MODEL: ZSC1000KBB
ZSC1001KSS



INTERIOR PARTS

MODEL: ZSC1000KBB
ZSC1001KSS



- Use & Care — MFL1
- Cook Book — MAX1
- Installation Manual — MFL3
- Cooking Guide Label — MEZ1
- Mini Manual — MBM2

