


PROheat™

25A3 Series



**PROheat™****25A3 Series**

1	B-203-7197	Upper Handle Assy - Black	28	B-203-0216	Autoload Receiver
2	B-203-0242	Cord Wrap - Black	29	B-203-6728	Spray Tip
3	B-203-7200	Push Rod	30	B-203-0132	Base w/ Edge Brush
4	B-203-6718	Heater Switch	31	B-203-7325	Brush Assembly w/Pivot Arms - 6 row
5	B-203-6651	3" Tough Stain Tool	32	B-203-0134	Edge Brush (1 pk)
6	B-203-7198	Hose Wrap - Upper	33	B-203-0127	Clip Pack - Brush - Belt Side
7	B-203-7203	Hose Assembly 7 ft	34	B-015-0621	Brush Belt
8	B-203-7199	Hose Wrap - Lower	35	B-210-7181	Pump
9	B-203-0122	Wheels (2 pk) - includes axles & e-rings	36	B-215-0628	Pump Belt
10	B-203-0123	Axle & E-ring	37	B-203-0104	Tank Assembly
11	B-203-0140	Hose Duct Gasket	38	B-203-0103	Tank Handle
12	B-203-0139	Upper Nozzle Gasket	39	B-203-0100	Tank Lid
13	B-203-0131	Diverter	40	B-203-0105	Tank Filter
14	B-203-0217	Nozzle Seal	41	B-203-0106	Tank Float & Baffle
15	B-203-0124	Front Nozzle	42	B-203-0107	Tank Baffle
16	B-203-0138	Upper Nozzle w/ Diverter	43	B-203-0101	Tank Bladder
17	B-203-7243	Main Housing - Black	44	B-203-0102	Tank Bottom
18	B-203-7244	Belt Cover - Black	45	B-203-0108	Autoload Assy
19	B-203-0136	Motor Cover	46	B-203-6655	Crevice Tool
20	B-210-4050	Duct Gasket	47	B-203-0149	Bare Floor Tool
21	B-203-0150	Motor Duct	48	B-210-4513	Heater Assembly
22	B-210-4051	Motor Intake Gasket	49	B-203-7201	Hose Duct Assembly
23	B-017-5972	Motor	50	B-203-0148	Valve - Trigger
24	B-203-0144	Elevator Arms - Left & Right			
25	B-210-4056	Motor Gasket	xx	B-203-7202	Cord - 30'
26	B-203-5554	Power Switch Pedal	xx	1204043	User's Guide
27	B-203-0112	Detent Pedal	xx	2037252	Screw Pack