


CIRRUS/PROGRADE Original & Replacement

Model VC248



Original & Replacement **CIRRUS/PROGRADE**

Model VC248

| KEY | PART NO | DESCRIPTION | KEY | PART NO. | DESCRIPTION |
|-----|---------|-------------------------------|-----|----------|-----------------|
| 1 | C-75030 | Front Cover Panel | 53 | C-40248 | Hose |
| 2 | C-76035 | Seal | 54 | C-50248 | Telescopic Wand |
| 3 | C-76050 | Gasket | 55 | C-57025 | Tool Holder |
| 4 | C-75032 | Front Cover | 56 | C-53024 | Upholstery Tool |
| 5 | C-75220 | Cord Rewind Actuator | 57 | C-55248 | Rug/Floor Tool |
| 6 | C-75021 | Motor Cover | 58 | C-54248 | Crevice Tool |
| 7 | C-75200 | Front Cover Lock Spring | | | |
| 8 | C-75202 | Front Cover Lock | | | |
| 9 | C-75204 | Bag Door Lockout Lever | | | |
| 11 | C-75206 | Bag Door Lockout Lever Spring | | | |
| 12 | C-75208 | Suction Inlet | | | |
| 13 | C-75210 | Dirt Seal | | | |
| 14 | C-18020 | Motor Filter | | | |
| 15 | C-18520 | Motor Filter Frame | | | |
| 16 | C-76045 | Front Cover Seal | | | |
| 17 | C-14020 | Paper Bag 6 PK | | | |
| 18 | C-16024 | Bag Holder Lock | | | |
| 19 | C-16022 | Bag Holder Lock Spring | | | |
| 20 | C-16020 | Bag Holder | | | |
| 21 | C-75020 | Bag Door Cover Release Lever | | | |
| 22 | C-71025 | Wheel Caster | | | |
| 23 | C-71022 | Front Wheel | | | |
| 24 | C-71020 | Rear Wheel | | | |
| 25 | C-75022 | Main Body | | | |
| 26 | C-75212 | Cord Outlet | | | |
| 27 | C-75214 | Cord Rewind Roller | | | |
| 28 | C-75216 | Cord Insert | | | |
| 29 | C-30020 | Cord Reel | | | |
| 30 | C-62520 | Motor Ring | | | |
| 31 | C-60020 | Motor Ass'y | | | |
| 32 | C-62522 | Motor Holder | | | |
| 33 | C-62521 | Motor Holder Socket | | | |
| 34 | C-34400 | PCB | | | |
| 35 | C-76040 | Motor Housing Gasket | | | |
| 36 | C-34020 | Switch | | | |
| 37 | C-70024 | Handle Cover | | | |
| 38 | C-70020 | Handle | | | |
| 39 | C-75031 | Rear Base Top | | | |
| 40 | C-75034 | Rear Base Top Cover | | | |
| 41 | C-18021 | Exhaust Filter | | | |
| 42 | C-77072 | Switch Pedal Spring | | | |
| 43 | C-75023 | Switch Pedal | | | |
| 44 | C-74020 | Exhaust Filter Frame | | | |
| 45 | C-75026 | Speed Control Knob | | | |
| 46 | C-77070 | Cord Rewind Pedal Spring | | | |
| 47 | C-75024 | Cord Rewind Pedal | | | |
| 48 | C-75218 | Full Bag Indicator Assembly | | | |