


BOSCH Original & Replacement

PREMIUM Model BSG81396



Original & Replacement **BOSCH****PREMIUM Model BSG81380**

KEY	PART NO.	DESCRIPTION	KEY	PART NO.	DESCRIPTION
1	BO-435851	Lid, Complete Metallic	27	BO-18006	Secondary Filter
2	BO-14010	Paper Bag, Type P Micro W/Filters 5 Pk	28	BO-187821	Secondary Filter Frame
2	BOR-1446	Paper Bag Type P Envirocare 5 Pk	29	BO-188291	Castor
3	BO-488195	Cable Supply Cord	30	BO-490965	Pivot Neck Complete Elbow, Power Nozzle
4	BO-188577	Holder	31	BO-491495	Housing Cover, Power Nozzle
5	BO-18010	Secondary Filter, HEPA	32	BO-420994	Drive Belt, Power Nozzle
6	BO-18011	Filter, Exhaust Micro Charcoal	33	BO-420996	Motor Mounting Set, Power Nozzle
7	BO-435850	Rear Lid	34	BO-490968	Motor, Power Nozzle
8	BO-389595	Rear Housing	35	BO-490973	Complete Brushroll Power Nozzle
9	BO-483347	Housing Seal	36	BO-490989	Lower Housing Base, Power Nozzle
10	BO-483782	Lid Holder, Housing	37	BO-420998	Rear Wheel, W/Clip Power Nozzle
11	BO-483345	Lid Lock	38	BO-420997	Front Wheel, Power Nozzle
12	BO-187823	Lid Spring	39	BO-421003	Corner Brush, Power Nozzle
13	BO-389593	Motor Housing	40	BO-421002	Control Module, Power Nozzle
14	BO-416454	Holder Bag	41	BO-421005	Power Nozzle Includes Indicator Light
15	BO-187820	Bag Holder Spring	42	BO-143337	Motor Complete
16	BO-188578	Lid Clamp	43	BO-483709	Holder
17	BO-187808	On & Off Knob	44	BO-491440	Control Module
18	BO-188559	Display	45	BO-30780	Cord Reel Complete
19	BO-434388	Top Housing, Cover	46	BO-421003	Tube
20	BO-385489	Bumper Strip	47	BO-421002	Spindle
21	BO-389598	Case Housing, Bottom	48	BO-421005	Lever
22	BO-187808	Variable Speed Slide	49	BO-143337	Insert
23	BO-55010	Hard Wood Floor Brush 12"	50	BO-421002	Spindle
24	BO-50005	Electric Telescopic Wand	51	BO-421002	Adapter
25	BO-40010	Hose Ass'y Complete			
26	BO-483339	4 in 1 Tool			