

This Owner's Manual is provided and hosted by [Appliance Factory Parts](#).



Bissell 7350 Owner's Manual

[Shop genuine replacement parts for Bissell 7350](#)




[Find Your Bissell Vacuum Cleaner Parts - Select From 377 Models](#)

----- Manual continues below -----

BISSELL Original & Replacement

PRO DRY MODELS 7350, 8350



Original & Replacement **BISSELL**

PRO DRY MODELS 7350, 8350

KEY	PART NO.	DESCRIPTION
1	B-203-7230	Hose Assembly
2	B-203-7233	Upper Handle Assembly
3	B-203-7234	Trigger, Handle
4	B-203-7236	Cord Wrap
5	B-203-6719	Power Switch
6	B-203-7239	Sliding Crevice Tool
7	B-203-7238	3" Upholstery Tool
8	B-203-7232	Hose Wrap, Upper
9	B-203-7241	Cap, Oxygen II Power Tool
10	B-203-7240	Oxygen II Power Tool
11	B-203-7204	Dirty Tank Assembly w/Cap - Blue
11	B-203-7205	Dirty Tank Assembly w/Cap - Purple
12	B-203-7206	Dirty Tank Cap
13	B-203-7207	Clean Tank - Blue
13	B-203-7208	Clean Tank - Purple
14	B-203-6677	Cap & Insert - Clean Tank
15	B-203-7212	Transfer Case w/Gaskets
16	B-203-7214	Motor Duct, Filter Gasket
17	B-203-7217	Vac Motor Assembly
18	B-203-7210	Spray Tip Cover
19	B-203-7211	Spray Tip
20	B-203-7213	Cover - Main
21	B-203-7221	Sole Plate
22	B-203-7220	Pump w/Connector
23	B-203-7228	Elevator Arms Assembly L&R
24	B-203-7224	Pivot Arms, L&R
25	B-203-7225	Roller Axle
26	B-203-7223	Roller Assembly w/Axle
27	B-203-7226	Brush Belt
28	B-203-7229	Wheels w/Axles L&R
29	B-203-7215	Receiver Valve w/o Umbrella Valve
30	B-203-7216	Detent Lever Assembly
31	B-203-7218	Circuit Board
32	B-203-7227	Brush Pulley & E-Clip
33	B-203-7231	Hose Wrap, Lower
XX	B-203-7237	Power Cord - 25 ft
XX	B-203-7235	Cord Clip
XX	B-120-4033	User's Guide - Bilingual
XX	B-203-7222	Screw Pack