



This Owner's Manual is provided and hosted by [Appliance Factory Parts](#).



# Bissell 1653 Owner's Manual

[Shop genuine replacement parts for Bissell 1653](#)



[Find Your Bissell Vacuum Cleaner Parts - Select From 377 Models](#)

----- Manual continues below -----

# BISSELL Original & Replacement

LITTLE GREEN CLEAN MACHINE Model 1650, 1653

KEY	PART NO.	DESCRIPTION
1	B-803-8844	Switch
2	NLA	Cover, Grip Ass'y
3	NLA	Bottle
4	NLA	Bottle Insert Ass'y Without Plunger
4	NLA	Bottle Insert Ass'y With Plunger
5	NLA	Connector, Bottle
6	B-010-9452	Tube (Bottle to Pump)
7	NLA	Connector, Pump
8	NLA	Pump Ass'y
9	B-880-7054	Screws, Pump
10	NLA	Rectifier (Order B-803-9166)
11	NLA	Wires (Order B-803-9166)
12	NLA	Transformer
13	B-880-7031	Screws, Transformer
14	NLA	Motor, Vac Scroll Ass'y
15	B-880-7038	Screws, Vac Motor
16	B-803-7391	Collar Ass'y, Vac Hose
17	B-880-7037	Screws, Collar
18	NLA	Flexible Hose Without Solution Tube
19	B-010-4703	Hose Guard
20	NLA	Tube (Grip to Pump)
21	NLA	Window Ass'y, Spray Grip (Order B-803-4929)
22	NLA	Cover, Spray Grip (Order B-803-4929)
23	B-880-7031	Screws, Spray Grip
24	NLA	Brush Strip
25	B-803-8458	Valve Ass'y
26	NLA	Spring, Trigger Leaf (Order B-803-4929)
27	NLA	Button, Trigger (Order E# -92929)
28	NLA	Tip, Spray (Order B-8039)
29	B-803-2472	Lock, Hose
30	NLA	Tube, Long (for Handle)
31	NLA	Tube, Short (for Handle)
32	B-803-2605	Connector, Barbed
33	NLA	Sponge, Anti-Splash
34	NLA	Tank, Recovery
35	B-803-4803	Housing, Base
36	B-880-7031	Screws, Housing
37	B-803-3302	Housing, Side
38	NLA	Cord 3 Wire Power
39	B-010-1271	Cord Restraint
40	B-010-2652	Wire Nut
41	B-010-1511	Cable Tie
42	B-803-4929	Upholstery Tool Ass'y

NLA = No Longer Available

