


This Owner's Manual is provided and hosted by [Appliance Factory Parts](#).



Bissell 1672A Owner's Manual

[Shop genuine replacement parts for Bissell 1672A](#)



[Find Your Bissell Vacuum Cleaner Parts - Select From 377 Models](#)

----- Manual continues below part list -----

Available Replacement Parts for Bissell 1672A

[SVR-1800](#)

Filter, Foam Sleeve

Original & Replacement **BISSELL**


BIG GREEN CLEAN MACHINE

Models 1671G, 1671W, 1671X, 1671Y, 1672, 1672A, 1672G, 1672W

KEY	PART NO.	DESCRIPTION
1	B-010-8873*	Switch, Vac
2	B-010-8873*	Switch, Pump
3	NLA	Cover, Motor with Switches
4	B-880-7038	Screw, #8 x 3/4
5	B-014-4717	Motor Housing
6	B-010-8310	Seal, Motor
7	B-010-5952	Two Stage Motor 1671 Series
7	B-010-8012	One Stage Motor 1672 Series
8	B-010-2839	Cord Set
9	B-010-2653	Connector Nut
10	B-010-2661	Connector 1/2-20 Thread
11	B-010-2486	Spring Clamp
12	B-010-8403	Spring - Tube Support
13	B-010-9488	Tube, 5 1/2"
14	B-010-2863	Connector
15	B-010-7182	Pump
16	B-013-9490	Tube, 3 1/4"
17	B-013-2685	Connector Inlet Female
18	B-880-7013	Screw, #8 x 1/2
19	B-014-2925	Tank Cover
20	NLA	Ball Cage
21	B-010-0329	Ball
22	B-010-3529	Motor Filter
23	B-010-3531	Filter Bag
23	SVR-1800	Filter, Foam Sleeve
24	B-013-4463	Handle
25	B-013-3001	Measuring Cup
26	B-803-2867	Siphon Tube Ass'y
27	B-015-9098	Tank Ass'y
28	B-010-2282	Castor With Sleeve
29	B-013-1523	Storage Rack
30	B-015-9151	Upholstery Tool
31	B-010-9156	Crevice Tool
32	B-010-8055	Small Vacuum Nozzle
33	B-013-9152	Sink Clean Out Tool
34	B-010-1187	Dusting Brush
35	B-010-4744	Dry Floor Nozzle
36	B-013-0469	Bare Floor Attachment

* Switches are not available for 1671G

NLA = No Longer Available



BISSELL Original & Replacement

POWER STEAMER Extraction Wand

Figure C

KEY	PART NO.	DESCRIPTION
	B-603-1659	Valve Cap Ass'y, W/O-Ring & Washer
28	NLA	O-Ring (Order B-603-1659)
29	NLA	Cap - Valve (Order B-603-1659)
30	NLA	Washer (Order B-603-1659)
	B-016-4181	Grip & Trigger Ass'y
31	NLA	Shaft - Valve (Order B-016-4181)
32	NLA	Spring (Order B-016-4181)
33	NLA	Button - Lock (Order B-016-4181)
34	NLA	Screw #8 x 3/4" (Order B-016-4181)
35	NLA	Cap, Grip End (Order B-016-4181)
36	NLA	Grip, Wand R.H. (Order B-016-4181)
37	NLA	Grip, Wand L.H. (Order B-016-4181)
38	NLA	Grip (Order B-016-4181)
39	NLA	Hose - Flexible
40	NLA	Trigger (Order B-016-4181)
41	NLA	Collar
42	NLA	Cap Swivel & Short Hose Ass'y
43	NLA	Stem Hose
44	NLA	O-Ring (Order B-016-4181)
45	NLA	Retainer - Spring (Order B-016-4181)
46		Washer
47		Screen - Filter
48	NLA	Stem - Faucet
49		Nut Hose
50		Clamp
51	NLA	Hose 2 1/2"
52	NLA	Shroud 1-Piece Ass'y
53	NLA	Injector Ass'y Without Shroud
54	NLA	Hose Only 50 ft.
	NLA	Hose & Injector Ass'y 50'
55	NLA	Shroud (one piece)
56	B-880-7026	Screw
57	NLA	Cap - Check Valve
58	NLA	Ball Valve
59	NLA	O-Ring
60	NLA	Orifice - Metering
61	NLA	Tube
62	B-010-3526	Filter
63	B-010-9672	Wand
64	NLA	Tube Transfer (Order B-015-9151)
65	NLA	Gasket (Order B-015-9151)
66	NLA	Spray Tip (Order B-015-9151)
67	B-015-9151	Upholstery Nozzle Ass'y
68	B-010-7387	Nut - Retainer
69	NLA	Plate (Order B-016-6965)
70	NLA	Nozzle (Order B-016-6965)
71	B-015-6150	Nozzle - Spray
72	B-880-7007	Screw #8 x 5/8"
73	NLA	Tool Clean-Out
75	B-013-2453	Clip - Hose
76	B-010-9464	Tube
77	B-010-1181	Brush Ass'y
78	B-880-7026	Screw #8 x 1/2"
79	B-013-0469	Bare Floor Ass'y
80	NLA	Brush (Order B-013-0469)
81	NLA	Squeegee (Order B-013-0469)
82	B-016-6965	Nozzle Ass'y, Complete

NLA = No Longer Available

Figure C

