


This Owner's Manual is provided and hosted by Appliance Factory Parts.
















Bissell 1960W Owner's Manual

[Shop genuine replacement parts for Bissell 1960W](#)



[Find Your Bissell Vacuum Cleaner Parts - Select From 377 Models](#)

----- Manual continues below -----



KEY	PART NO	DESCRIPTION
1	2035601	HANDLE ASSY W/ CORD WRAP
2	2041107	CORD WRAP
3	2041104	HANDLE - RT SIDE
4	2041103	TRIGGER
5	2041108	HANDLE - LT SIDE
6	2041106	PUSH ROD - UPPER
7	6037806	TUBING
8	2035616	HANDLE SCREW KIT (2+1)
9	2041106	UPPER PUSH ROD
10	2041126	RECEIVER ASSY
11	2035614	PUSH ROD - LOWER
13	2041128	ON/OFF SWITCH
14	6037816	DIRTY WATER TANK - TEAL
14	2035604	DIRTY WATER TANK w/ PANEL & FILTER - DUSK
15	6037823	EXHAUST VENT PANEL W/ FILTER - TEAL
15	2035609	EXHAUST VENT PANEL W/ FILTER - DUSK
16	6037824	FOAM FILTER
17	2041125	REAR COVER
18	6037813	CLEAN WATER TANK - WHITE - 19603
18	2035603	CLEAN WATER TANK - DUSK - 1960W
19	2041112	FORMULA MEASURING CUP
20	2041111	CAP AND INSERT
21	6037820	TANK LATCHES - TWO
23	2041114	DETENT LEVER
24	0106357	REAR MOTOR SUPPORT
25	2041122	MOTOR INTAKE GASKET
26	6037825	MOTOR OUTLET (T DOWN)
27	6037807	COMPLETE MOTOR ASSY
28	2041115	METAL DETENT DOWEL
29	2035602	BRUSH - CROSS ACTION - ORANGE/WHITE
30	6037800	FRONT NOZZLE ASSY
31	2035615	SPRAY BAR - ORANGE
34	6037802	WHEEL
36	2041113	MOTOR COVER
37	6037803	POWER CORD
xx	2035600	USER'S GUIDE