




# BARE FLOOR CLEANER

## CatchAll Models 3107, 3107B



issued: 3/03

**BARE FLOOR CLEANER**  
CatchAll™ Models 3107, 3107B



BISSELL		
KEY	PART NO	DESCRIPTION
1	2032520	Rechargeable Battery Pack
2	2032528	Cloth Grippers (Set of 4)
3	2032523	Dirt Cup
4	2032529	Access Plate Assy w/ Screws
5	2032519	Belt (2-pack)
6	2032524	Rotating Brush
7	2032526	Brush End Caps w/ O-Rings
8	2032536	DUST BLADE
xx	2032530	Handle Grip
xx	2032521	Charging Base
xx	2032522	Handle Assembly (4 sections)
xx	2032518	Filter (2-pack)
xx	2032539	User's Guide
xx	2036500	Electrostatic Cloths (12-pack)