


This Owner's Manual is provided and hosted by Appliance Factory Parts.



Bissell 35962 Owner's Manual

[Shop genuine replacement parts for Bissell 35962](#)




[Find Your Bissell Vacuum Cleaner Parts - Select From 376 Models](#)

----- Manual continues below -----

CLEANVIEW® REVOLUTION

Series 3595, 35952, 35962



CleanView® Revolution

Models 3595, 35952, 35962



KEY	PART NO	DESCRIPTION
1	B-203-6742	Handle Assy - Purple Slate
1	B-203-6743	Handle Assy - Midnight Blue
1	B-203-6790	Handle Assy - Tango Blue Paint
2	B-203-6734	Cyclone Assy - Clear/Yellow w/ Filter Clean
3	B-203-1085	Foam Filter
4	B-203-6739	Separation Flange Frame - Yellow
5	B-203-6727	Dirt Cup Screen (2pk) - Yellow
6	B-203-6737	Dirt Cup - Clear
7	B-203-1073	Pre Motor Filter
8	B-203-2058	Pre Motor Filter Grille
9	B-203-1119	Lock n' Seal Lever
10	B-203-1018	Cord Wrap
11	B-203-1067	Cord
12	B-203-1035	Switch
13	B-203-1076	Tool Caddy
14	B-223-1047	Post Motor Filter
15	B-203-1011	Post Motor Filter Grille
16	B-203-1297	Light Bulb - 12V
17	B-203-1008	Lens
18	B-203-1034	Wire Harness
19	B-203-1218	Motor Cushion - Large
20	B-203-2211	Vacuum Motor
21	B-203-1217	Motor Support
22	B-203-1107	Motor Cushion - Small
23	B-203-1332	Case Drum Assy
24	B-203-2547	Axle
25	B-203-6746	Rear Wheel
26	B-203-2548	E-Ring
27	B-203-6751	Top Cover - Purple Slate
27	B-203-6752	Top Cover - Midnight Blue
27	B-203-6791	Top Cover - Tango Blue Paint
28	B-203-1040	Neck Brush - Right
29	B-203-1039	Neck Brush - Left
30	B-203-6748	Detent Lever
31	B-203-2556	Front Wheel Assy
32	B-203-1122	Height Adjustment Knob
33	B-203-6729	Brush Roll - Yellow
34	B-203-1185	Access Plate
35	B-203-1093	Belt
36	B-203-2035	Upholstery Hose
37	B-203-1128	Twist n' Snap Collar
38	B-203-1084	Extension Wand
39	B-203-1063	Crevice Tool
40	B-203-1228	Upholstery Tool
41	B-203-6730	TurboBrush - Yellow
		Purple Slate = 3595
		Midnight Blue = 35952
		Tango Blue Paint = 35962
xx	6036725	User's Guide - Canada
xx	2036720	User's Guide - United States