


This Owner's Manual is provided and hosted by [Appliance Factory Parts](http://www.appliancefactoryparts.com).




# Bissell 50C9 Owner's Manual

[Shop genuine replacement parts for Bissell 50C9](#)



[Find Your Bissell Vacuum Cleaner Parts - Select From 376 Models](#)

----- Manual continues below -----



**Heavy Duty Vacuum™**

50C9 Model



KEY	PART NO	DESCRIPTION
1	B-203-1442	Handle Assembly w/ Cord - Black
2	B-203-1316	Switch - Power
3	B-203-1317	Switch - Brush
4	B-203-1315	Cord Wrap
5	B-203-1378	UV Reflector
6	B-203-1308	Cyclone Gasket
7	B-203-1374	Pre Motor Filter
8	B-203-1352	Pre Motor Filter Tray
9	B-203-1377	Light Bulb
10	B-203-1354	Headlight Lens
11	B-203-1360	Vacuum Motor w/ Gasket & Isolator
12	B-203-1443	Lower Wand Support
13	B-203-1444	Upper Wand Support
14	B-203-1315	Cord Wrap
15	B-203-1445	Hose Clip
16	B-203-1379	Rope Gasket - Diverter Cover
17	B-203-1361	Diverter Cover
18	B-203-1446	Hose Guide
19	B-3282	HEPA Exhaust Filter - 6/CS
20	B-203-1447	Filter Door
21	B-203-1448	Upper Cyclone Assembly
22	B-203-1449	Cyclone Latches & Springs
23	B-203-1450	Dirt Bin & Debris Door Assembly
24	B-203-1299	Debris Door >07018
25	B-203-1320	Height Adjustment Knob
26	B-203-1348	Hose Assembly - Foot
27	B-203-1451	Top Cover
28	B-203-1452	Brush Window
29	B-203-1328	Brush w/Felt Gaskets
30	B-203-1329	Belt
31	B-203-1350	Brush Motor
32	B-203-1349	Circuit Board
33	B-203-1340	Detent Pedal
34	B-203-1347	Microswitch
35	B-203-1346	Body Pivot Clamp w/ Screw
36	B-203-1319	Front Wheel Assembly
37	B-203-1341	Rear Wheel
38	B-203-1345	Axle w/ E-Ring
39	B-203-1359	Hose Assembly - Foot
40	B-203-1318	Cord
41	B-203-1363	Crevice Tool
42	B-203-1364	Telescoping Wand - Plastic
42	B-203-1373	Telescoping Wand - Metal
43	B-203-1434	Combo Upholstery Tool
44	B-203-1362	Turbobrush
XX	B-203-1372	Turbobrush w/Microban
XX	B-203-1367	Pet Wide Turbobrush
XX	B-203-1366	Flexible Crevice Tool
XX	B-203-1382	Contour Tool
XX	B-203-1376	Handle Screw pack
XX	1104073	User's Guide