


CIRRUS/PROGRADE Original & Replacement

Model CR88




Original & Replacement **CIRRUS/PROGRADE**

Model CR88

KEY	PART NO	DESCRIPTION	KEY	PART NO	DESCRIPTION
1	C-75010	Dust Compartment (Blue)	48	C-75890	Filter Cover Fitting
2	C-32002	Rubber Boot (Gray)	49	C-75895	Filter Cover Knob Fitting
3	C-36401	Vacuum Sensor & Full Bag Indicator	50	C-75896	Filter Cover Knob (Gray)
4	C-70590	Handle Fitting (Rear)	51	C-40003	Stretch Hose Complete (Gray)
5	C-77023	Switch Activator Spring	52	C-40052	Stretch Hose
6	C-75092	Switch Mounting Plate	53	C-75057	Suction Inlet Lid (Gray)
7	C-36000	Switch	54	C-76020	Suction Inlet Lid Seal
8	C-34520	Switch Activator	55	C-77031	Suction Inlet Lid Spring
9	C-77024	Plastic Washer	56	C-75055	Suction Inlet (Gray)
10	C-77025	Screw	57	C-76080	Suction Inlet Seal (Large)
11	C-76900	Dust Compartment Side Seals	58	C-76081	Suction Inlet Seal (Small)
12	C-14000	Paper Bag 6 Pk	59	C-45000	Hose Cuff (Gray)
13	C-77003	Screw	60	C-70251	Handle Grip (Gray)
14	C-77032	Screw	61	C-34500	Handle Lever Rod
15	C-70591	Handle Fitting (Front)	62	C-34505	Switch Knob
16	C-75090	Printed Circuit Board Holder	63	C-34511	Switch Window (Gray)
17	C-32002	Cord Holder (Black)	64	C-70506	Upper Cord Hook (Gray)
18	C-18402	Filter Supporter Screen	65	C-77014	Spring Washer
19	C-18005	Secondary Filter	66	C-77012	Screw
20	C-18422	Bag Support (Red)	67	C-77000	Screw
21	C-75700	LED Light Window (Clear)	68	C-77000	Screw
22	C-75906	Switch Housing Cover (Blue)	69	C-77019	Screw
23	C-76902	Dust Cover Seal	70	C-70750	Handle Grip Bushing (Gray)
24	C-75590	Slide Knob (Gray)	71	C-30005	Power Cord 33' 17/2 (Gray)
25	C-77026	Screw	72	C-70005	Handle Tube
26	C-76022	Motor Compartment Seals	73	C-77020	Screw
27	C-75899	Motor Exhaust Housing W/Gasket	74	C-77005	Washer
29	C-77030	Handle Screw	75	C-77010	Cord Hook Spring
30	C-70000	Screw	76	C-70505	Lower Cord Hook (Gray)
31	C-75804	Latch Bracket (Gray)	77	C-77021	Screw
32	C-75027	Cover Latch (Gray)	78	C-70705	Stretch Hose Holder (Gray)
33	C-77027	Cover Latch Spring (Gray)	79	C-77022	Nut
34	C-75504	Dust Compartment Cover (Blue)	80	C-60010	Lamb Motor Twin Fan
35	C-70000	Screw	81	C-63000	Carbon Brush
36	C-75038	Motor Cover Assembly (Blue)	82	C-62010	Motor Mount (Front)
37	C-76010	Motor Cover Seal	83	C-32600	Cord Clip Rubber
38	C-71505	Cap Nut	84	C-62020	Motor Support Cover (Black)
39	C-71001	Rear Wheel (Black)	85	C-76030	Motor Support Cover Foam
40	C-77033	Washer	86	C-62025	Motor Mount (Rear)
41	C-71003	Rear Wheel Shaft	87	C-62033	Motor Support Housing (Black)
42	C-77034	Screw	88	C-76033	Motor Support Housing Foam
43	C-75824	Filter Cover (Blue)	89	C-70000	Screw
44	C-77035	Screw	90	C-36050	Printed Circuit Board
45	C-75828	Filter Holder (Blue)	91	C-32090	Cord Protector
46	C-18054	HEPA Filter			
47	C-77035	Screw			

CIRRUS/PROGRADE Original & Replacement

Model CR88




Original & Replacement **CIRRUS/PROGRADE**

Model CR88

KEY	PART NO.	DESCRIPTION	KEY	PART NO.	DESCRIPTION
1	C-73004	Nozzle Housing (Blue)	53	C-36908	Lead Wire (Black)
2	C-73400	Plastic Bushing (Black)	54	C-36005	Thermal Switch
3	C-73630	Clutch Pedal Pivot (Gray)	55	C-77005	Washer
4	C-73632	Carpet/Floor Pedal (Gray)	56	C-77047	Screw
5	C-73634	Clutch Pedal Ring Holder (Black)	57	C-32003	Cord Clip
6	C-77039	Bottom Plate Lock Screw	58	SS-3270	Wire Nut
7	C-73410	Clear Lens	59	C-36906	Lead Wire Black
8	C-73480	Nozzle Housing Felt Packing	60	C-36904	Lead Wire White
9	C-73484	Vented Support Felt Packing	61	C-36902	Lead Wire White
10	C-73482	Vented Support Fitting	62	C-36914	Wire Bushing
11	C-73432	Nozzle Inlet (Gray)	63	C-73412	Reflector
12	C-77040	Screw	64	C-77046	Screw
13	C-77048	Clutch Crank Rod Spring	65	C-77045	Spring Washer
14	C-73635	Upper Clutch Pedal Ring (Black)	66	C-70000	Screw
15	C-73636	Lower Clutch Pedal Ring (Black)	67	C-73414	Bulb Socket
16	C-73637	Clutch Pedal Ring Pin	68	FA-3515	Light Bulb
17	C-73638	Clutch Crank Rod Pin	69	C-76100	Bottom Plate Assembly
18	C-73647	Clutch Crank Rod Ass'y (Includes Items 16-23, 30)	70	C-76001	Bottom Plate Seal
19	C-77049	E-Clip	71	C-71010	Front Plate Wheel Pin
20	C-77050	Washer	72	C-71011	Front Wheel (Black)
21	C-77051	E-Clip	73	C-77015	Push-On Nut
22	NLA	Clutch Crank Rod Pin Holder (Order	74	C-77016	Screw
23	C-73641	Pedal Frame Holder	75	C-77017	Bottom Plate Latch Washer
24	C-73642	Foot Pedal Complete (Gray)	76	C-76101	Bottom Plate
25	C-73643	Foot Pedal (Gray)	77	C-77018	Bottom Plate Latch Spring
26	C-73782	Foot Pedal Shaft	78	C-76400	Bottom Plate Latch (Black)
27	C-73792	Rear Belt Cover (Gray)	79	C-20002	Agitator Assembly
28	C-77052	Foot Pedal Spring	80	C-20500	Agitator Core
29	C-73646	Pedal Frame	81	C-20510	Rubber End Cover (Black)
30	C-77046	Screw	82	C-20512	End Cap
31	C-77043	Screw	83	C-77036	Agitator Felt Washer
32	C-77052	Screw	84	C-77037	Washer
33	C-77032	Screw	85	C-62000	Agitator Bearing
34	C-73500	Clutch Crank Rod Frame Complete	86	C-20514	Agitator Bearing Holder
35	C-73502	Clutch Crank Rod	87	C-22000	Brush Strip
36	C-73504	Clutch Crank Rod Frame	88	C-20524	Clutch Pulley (Large) Complete
37	NLA	Clutch Lever Boot (Order C-73500)	89	C-20525	Clutch Pulley (Large)
38	C-77053	E-Clip	90	C-77028	E-Clip
39	C-73508	Clutch Lever	91	C-77038	Washer
40	C-77054	Clutch Crank Rod Spring	92	C-20526	Clutch Pulley (Small) Complete
41	C-73501	Clutch Crank Rod Frame Shaft	93	C-20528	Clutch Pulley (Small) Cover
42	C-77055	Washer	94	C-20527	Clutch Pulley (Small)
43	C-77056	Rod Frame Shaft Spring	95	C-20522	Agitator Shaft
44	C-77037	Washer			
45	C-73512	Clutch Crank Rod			
46	C-77057	Spring Pin			
47	C-73514	Clutch Crank Rod Pin			
48	C-77032	Screw			
49	C-10000	Belt 2 Pk			
50	C-74102	Furniture Guard (Gray)			
51	C-77044	Washer			
52	C-77000	Screw			

CIRRUS/PROGRADE Original & Replacement

Models CR78, CR88



KEY	PART NO.	DESCRIPTION
1	C-50000	Wand Assembly Complete (Gray)
2	C-50002	Hose Wand (Gray)
3	C-50500	Wand Lock
4	C-45010	Cuff (Large) (Gray)
5	C-50004	Center Wand (Gray)
6	C-45012	Cuff (Small) (Gray)
7	C-50006	Tool Wand (Gray)
8	C-16000	Check Bag Lever (Red)
9	C-16010	Check Bag Lever Holder (Red)
10	C-77000	Screw
11	C-34050	Switch
12	C-75100	Check Bag Round Knob
13	C-77058	Check Bag Spring
14	C-75102	Check Bag Crank

KEY	PART NO.	DESCRIPTION
15	C-75104	Check Bag Cover (Green) CR78
15	C-75106	Check Bag Cover (Blue) CR88
16	C-75080	Tool Clip (Gray)
17	C-75078	Stretch Hose Clip (Gray)
18	C-75076	Upholstery Tool Clip (Gray)
19	C-75074	Wand Retainer Clip (Gray)
20	C-77000	Screw
21	C-74000	Warning Label
22	C-75082	Motor Cord Cover (Green) CR78
22	C-75084	Motor Cord Cover (Blue) CR88
23	C-75072	Upper Wand Clip (Gray)
24	C-75070	Lower Wand Clip (Gray)
25	C-53000	Dusting Brush (Gray)
26	C-52000	Upholstery Tool (Gray)
27	C-54000	Crevice Tool (Gray)