


This Owner's Manual is provided and hosted by [Appliance Factory Parts](#).



CIRRUS CR79 Owner's Manual

[Shop genuine replacement parts for CIRRUS CR79](#)




[Find Your CIRRUS Vacuum Cleaner Parts - Select From 13 Models](#)

----- Manual continues below -----

CIRRUS/PROGRADE Original & Replacement

Model CR79




Original & Replacement **CIRRUS/PROGRADE**

Model CR79

KEY	PART NO	DESCRIPTION	KEY	PART NO.	DESCRIPTION
1	C-75005	Dust Compartment (Green)	46	C-77035	Screw
2	C-32002	Rubber Boot (Gray)	47	C-75890	Filter Cover Fitting
3	C-36400	Vacuum Sensor & Fullbag Indicator	48	C-75895	Filter Cover Knob Fitting
4	C-70590	Handle Fitting (Rear)	49	C-75898	Filter Cover Knob (Gray)
5	C-77023	Switch Activator Spring	50	C-40006	Stretch Hose Complete (Gray)
6	C-75092	Switch Mounting Plate	51	C-75055	Suction Inlet (Gray)
7	C-36000	Switch	52	C-77031	Suction Inlet Lid Spring
8	C-34520	Switch Activator	53	C-75054	Suction Inlet Lid (Gray)
9	C-77024	Plastic Washer	54	C-75056	Suction Control Slide (Gray)
10	C-77025	Screw	55	C-76080	Suction Inlet (Large)
11	C-70591	Handle Fitting (Front)	56	C-76081	Suction Inlet (Small)
12	C-32002	Cord Holder (Black)	57	C-40052	Stretch Hose (36cm)
13	C-77032	Screw	58	C-45001	Hose Cuff (Gray)
14	C-75090	P.C. Board Holder	59	C-76020	Suction Inlet Cover Seal
15	C-77003	Screw	60	C-70251	Handle Grip Set (Gray)
16	C-76900	Dust Compartment Side Seals	61	C-34500	Handle Lever Switch Rod
17	C-14000	HEPA Type Paper Bag 6 Pk	62	C-34505	Switch Knob
17	C-14005	Paper Bag Micro Filtration 12 Pk	63	C-34511	Switch Window (Gray)
18	C-18420	Filter Support Screen	64	C-77000	Screw
19	C-18007	Secondary Carbon Filter	65	C-77003	Screw
20	C-18422	Bag Supporter (Red)	66	C-70521	Handle Side Clip (Gray)
21	C-76902	Dust Cover Seal	67	C-77005	Washer
22	C-75904	Switch Housing Cover (Green)	68	C-77010	Cord Hook Spring
23	C-77026	Screw	69	C-70505	Upper Cord Hook (Gray)
24	C-76022	Motor Compartment Seals	70	C-70002	Handle Tube
25	C-75899	Motor Exhaust Housing W/Gasket	71	C-77012	Screw
27	C-77030	Handle Screw	72	C-77014	Spring Washer
28	C-77000	Screw	73	C-70506	Lower Cord Hook (Gray)
29	C-75804	Release Button Cover (Gray)	74	C-30005	Power Cord 33' 17/2 (Gray)
30	C-75027	Cover Release Button (Gray)	75	C-32090	Cord Protector
31	C-77027	Cover Release Button Spring	76	C-60005	Lamb Motor
32	C-75502	Dust Compartment Cover (Green)	77	C-63005	Carbon Brush
33	C-77000	Screw	78	C-62010	Motor Mount (Front)
34	C-79037	Motor Cover (Green)	79	C-32600	Cord Clip Rubber
35	C-76010	Motor Cover Seal	80	C-62020	Motor Support Cover (Black)
36	C-71505	Cap Nut	81	C-76030	Motor Support Cover Foam
37	C-71001	Rear Wheel (Black)	82	C-62025	Motor Mount (Rear)
38	C-77033	Washer	83	C-62030	Motor Bushing
39	C-71003	Rear Wheel Shaft	84	C-62033	Motor Support Housing (Blac
40	C-77034	Screw	85	C-70000	Screw
41	C-18052	Electrostatic Filter	86	C-76033	Motor Support Housing Foam
42	C-77035	Screw	87	C-45002	Long Hose Cuff
43	C-75822	Filter Cover (Green)	88	C-75063	Hose Rack
44	C-75826	Filter Holder (Green)	89	C-77034	Screw
45	C-75827	Electrostatic Filter Holder Assembly			

CIRRUS/PROGRADE Original & Replacement

Model CR79



Original & Replacement **CIRRUS/PROGRADE**


Model CR79

KEY	PART NO	DESCRIPTION	KEY	PART NO.	DESCRIPTION
1	C-73002	Nozzle Housing (Green)	53	C-76100	Bottom Plate Assembly
2	C-73400	Plastic Bushing (Black)	54	C-76001	Bottom Plate Seal
3	C-73630	Clutch Pedal Pivot (Gray)	55	C-71010	Front Wheel Pin
4	C-73632	Carpet/Floor Pedal (Gray)	56	C-71011	Front Wheel (Black)
5	C-73634	Clutch Pedal Ring Holder (Black)	57	C-77015	Push-On Nut
6	C-77039	Bottom Plate Lock Screw	58	C-77016	Screw
7	C-73410	Clear Lens	59	C-77017	Bottom Plate Latch Washer
8	C-73480	Nozzle Housing Felt Packing	60	C-76101	Bottom Plate
9	C-73484	Vented Support Felt Packing	61	C-77018	Bottom Plate Latch Spring
10	C-73482	Vented Support Fitting	62	C-76400	Bottom Plate Latch (Black)
11	C-40007	Nozzle Hose	63	C-36908	Lead Wire (Black)
12	C-73430	Nozzle Inlet	64	C-36005	Thermal Switch
13	C-77048	Clutch Crank Rod Spring	65	C-77005	Washer
14	C-73635	Upper Clutch Pedal Ring (Black)	66	C-77047	Screw
15	C-73636	Lower Clutch Pedal Ring (Black)	67	C-32003	Cord Clip
16	C-73637	Clutch Pedal Ring Pin	68	SS-3270	Wire Nut
17	C-73638	Clutch Crank Rod Pin	69	C-36908	Vacuum Sensor Cord
18	C-73647	Clutch Crank Rod Ass'y (Includes Items 16-23, 30)	70	C-36910	Lead Wire Red
19	C-77049	E-Clip	71	C-36912	Lead Wire White
20	C-77050	Washer	72	C-36914	Wire Bushing
21	C-77051	E-Clip	73	C-73412	Reflector
22	NLA	Clutch Crank Rod Pin Holder (Order C-73647)	74	C-77046	Screw
23	C-73641	Pedal Frame Holder	75	C-77045	Spring Washer
24	C-73642	Foot Pedal Complete (Gray)	76	C-70000	Screw
25	C-73643	Foot Pedal (Gray)	77	C-73414	Bulb Socket
26	C-73782	Foot Pedal Shaft	78	FA-3515	Light Bulb
27	C-73792	Rear Belt Cover (Gray)	79	C-36902	Lead Wire (White)
28	C-77042	Foot Pedal Spring	80	C-36900	Lead Wire (Black)
29	C-73646	Pedal Frame	81	C-20002	Agitator Assembly
30	C-77046	Screw	82	C-20500	Agitator Core
31	C-77043	Screw	83	C-20510	Rubber End Cover (Black)
32	C-77052	Screw	84	C-20512	End Cap
33	C-77032	Screw	85	C-77036	Agitator Felt Washer
34	C-73500	Clutch Crank Rod Frame Complete	86	C-77037	Washer
35	C-73502	Clutch Crank Rod	87	C-62000	Agitator Bearing
36	C-73504	Clutch Crank Rod Frame	88	C-20514	Agitator Bearing Holder
37	NLA	Clutch Lever Boot (Order C-73500)	89	C-22000	Brush Strip
38	C-77053	E-Clip	90	C-20524	Clutch Pulley (Large) Complete
39	C-73508	Clutch Lever	91	C-20525	Clutch Pulley (Large)
40	C-77054	Clutch Crank Rod Spring	92	C-77028	E-Clip
41	C-73510	Clutch Crank Rod Frame Shaft	93	C-77038	Washer
42	C-77055	Washer	94	C-20526	Clutch Pulley (Small) Complete
43	C-77056	Rod Frame Shaft Spring	95	C-20528	Clutch Pulley (Small) Cover
44	C-77037	Washer	96	C-20527	Clutch Pulley (Small)
45	C-73512	Clutch Crank Rod	97	C-20522	Agitator Shaft
46	C-77057	Spring Pin	98	C-77040	Screw
47	C-73514	Clutch Crank Rod Pin			
48	C-77032	Screw			
49	C-10000	Belt 2 Pk			
50	C-74102	Furniture Guard (Gray)			
51	C-77044	Washer			
52	C-77000	Screw			

NLA = NO LONGER AVAILABLE

CIRRUS/PROGRADE Original & Replacement

Models CR79, CR89, CR99



KEY	PART NO	DESCRIPTION	KEY	PART NO.	DESCRIPTION
1	C-50008	Telescopic Wand Complete Metal	15	C-75104	Check Bag Cover (Green) CR79
2	C-53000	Dusting Brush (Gray)	15	C-75106	Check Bag Cover (Blue) CR89
3	C-52000	Upholstery Tool (Gray)	16	C-75080	Tool Clip (Gray)
4	C-54000	Crevice Tool (Gray)	17	C-75082	Motor Cord Cover (Green) CR79
5	C-75061	Wand Retainer CR79 Green	17	C-75084	Motor Cord Cover (Blue) CR89, CR99
5	C-75062	Wand Retainer CR89 Blue	18	C-75076	Upholstery Tool Clip (Gray)
6	C-77000	Screw	19	C-75074	Wand Retainer Clip (Gray)
7	C-77005	Washer	20	C-77000	Screw
8	C-16000	Check Bag Lever (Red)	21	C-74000	Warning Label
9	C-16010	Check Bag Lever Holder (Red)	22	C-75072	Upper Wand Clip (Gray)
10	C-77000	Screw	23	C-75070	Loer Wand Clip (Gray)
11	C-34050	Switch	24	C-50009	Plastic Extension Wand
12	C-75100	Check Bag Round Knob	25	FA-5716	Air-Driven Upholstery Nozzle CR99
13	C-77058	Check Bag Spring		RO-UTT020	Belt For Air-Driven Upholstery Tool CR99
14	C-75102	Check Bag Crank			