


CIRRUS

Original & Replacement

Model CR358



Original & Replacement

CIRRUS


Model CR358

KEY	PART NO.	DESCRIPTION	KEY	PART NO.	DESCRIPTION
1	C-358001	Attachment Cover	42	C-358042	Dirt Cup Separator
2	C-358002	Exhaust Air Grill	43	C-358043	Dirt Cup Cover
3	C-358003	Exhaust Filter - HEPA	44	C-358044	Dirt Cup Filter
4	C-358004	Exhaust Filter Frame	45	C-358045	Dust Cover Latch
5	C-358005	Cord Rewind Pedal	46	C-358046	Dust Cover Latch Spring
6	C-358006	Bag Indicator Lens	47	C-358047	Dust Compartment Cover
7	C-358007	Variable Speed Knob	48	C-358048	Dust Bag Gasket
8	C-358008	Cover - Variable Speed Switch	49	C-358049	Inlet Tube
9	C-358009	Switch Pedal	50	C-358050	Hose Inlet Gasket
10	C-358010	Switch Cover	51	C-358051	Hose Inlet Trim Ring
11	C-358011	Switch	52	C-358052	Upholstery Tool
12	C-358012	Printed Circuit Board & Speed Control	53	C-358053	Crevice Tool
13	C-358013	Rubber Support	54	C-358054	Upholstery Brush
14	C-358014	Upper Motor Cover	55	C-358055	Latch Spring
15	C-358015	Motor Ring	56	C-358056	Attachment Compartment Latch
16	C-358016	Shock Absorber	57	C-358057	Switch Pedal Spring
17	C-358017	Lamb Motor	58	C-358058	Sensor
18	C-358018	Lower Motor Cover	59	C-358059	Rug Nozzle Hook
19	C-358019	Rubber Support	60	C-358060	Exhaust Filter Cage Gasket
20	C-358020	Wheel Cover	61	C-358061	Top Motor Housing
21	C-358021	Secondary Filter	62	C-358062	Bag Compartment Support
22	C-358022	Secondary Filter Frame	63	C-358059	Cord Rewind
23	C-358023	Gasket - Dust Compartment	64	C-358067	Cord Outlet Idler Wheel
24	C-358024	Hook For Rug Nozzle	63	C-358069	Cord Outlet
25	C-358025	Swivel Support - Front Wheel	66	C-358066	Cord Outlet Wheel
26	C-358026	Swivel - Front Wheel	67	C-358067	Cord Outlet Wheel Support
27	C-358027	Front Wheel	68	C-358068	Motor Seal Ring
28	C-358028	Wheel Axle	69	C-358069	Bag Holder Latch Spring
29	C-358029	Safety Valve Cover	70	C-358070	Bag Holder Latch
30	C-358030	Safety Valve Salve	71	C-358071	Bag Holder Latch Bracket
31	C-358031	Safety Valve Falv	72	C-358072	Bottom Housing
32	C-358032	Safety Valve	73	C-358073	Cover Plate
33	C-358033	Handle Cover	74	C-358074	Large Rear Wheel
34	C-14010	Paper Bag 5 Pk	75	C-358075	Cover Spring
35	C-358035	Paper Bag Holder	76	C-358076	Cover Spring Axle
36	C-358036	Dirt Cup Lock Spring	77	C-358077	Cover Hinge Pin
37	C-358037	Dirt Cup Lock Plate	78	C-358078	Pin Retainer
38	C-358038	Dirt Cup Bottom	79	C-358079	Tube For Sensor
39	C-358039	Dirt Cup Handle	80	C-358080	Rubber Seal - Sensor Tube
40	C-358040	Dirt Cup Body			
41	C-358041	Cyclonic Dirt Cup (Includes 36, 37, 38, 39, 40, 42, 43)			

CIRRUS

Original & Replacement

Model CR358



Original & Replacement **CIRRUS**

Model CR358

<u>KEY</u>	<u>PART NO</u>	<u>DESCRIPTION</u>	<u>KEY</u>	<u>PART NO.</u>	<u>DESCRIPTION</u>
1	C-3581101	Nozzle Hood	20	C-3581120	Lead Wire To Switch
2	C-3581102	Clear Window	22	C-3581122	Switch Housing
3	C-3581103	Light Lens	23	C-3581123	Base Housing
4	C-3581104	Gasket	24	C-3581124	Dust Seal
5	C-3581105	Air Duct Cover	25	C-3581125	Cord Grommet
6	C-3581106	Screw	26	C-3581126	Cord
7	C-3581107	Gasket	27	C-3581127	Fuse Link
8	C-3581108	Furniture Guard	28	C-10500	Belt 2 Pk
9	C-20300	Agitator Ass'y	29	C-3581129	Belt Guide Metal
10	C-3581110	Rear Wheel	30	C-3581130	Motor
11	C-3581111	Brush Strip	31	C-3581131	Washer
12	C-3581112	Light Bulb	32	C-3581132	Light Reflector Metal
13	C-3581113	Light Socket Ass'y	33	C-3581133	Elbow Retainer Left
14	C-3581114	Screw	34	C-3581134	Pivot Elbow
15	C-3581115	Front Wheel Axle	35	N/A	Warning Label
16	C-3581116	Front Wheel	36	C-3581136	Felt Gasket - Agitator Housing
17	C-3581117	Front Wheel Rubber	37	C-3581137	Elbow Retainer Right
18	C-3581118	Switch Pedal	38	C-50015	Wand
19	C-3581119	Switch	39	C-40015	Electric Hose

N/A - Not Available