


# CIRRUS/PROGRADE Original & Replacement

Model CR89, CR99




Original & Replacement **CIRRUS/PROGRADE**

Model CR89, CR99

KEY	PART NO	DESCRIPTION	KEY	PART NO	DESCRIPTION
1	C-75010	Dust Compartment (Blue)	48	C-75890	Filter Cover Fitting
2	C-32002	Rubber Boot (Gray)	49	C-75895	Filter Cover Knob Fitting
3	C-36401	Vacuum Sensor & Full Bag Indicator	50	C-75898	Filter Cover Knob (Gray)
4	C-70590	Handle Fitting (Rear)	51	C-40006	Stretch Hose Complete (Gray)
5	C-77023	Switch Activator Spring	52	C-40052	Stretch Hose
6	C-75092	Switch Mounting Plate	53	C-75057	Suction Inlet Lid (Gray)
7	C-36000	Switch	54	C-76020	Suction Inlet Lid Seal
8	C-34520	Switch Activator	55	C-77031	Suction Inlet Lid Spring
9	C-77024	Plastic Washer	56	C-75055	Suction Inlet (Gray)
10	C-77025	Screw	57	C-76080	Suction Inlet Seal (Large)
11	C-76900	Dust Compartment Side Seals	58	C-76081	Suction Inlet Seal (Small)
12	C-14000	HEPA Type Paper Bag 6 Pk	59	C-45001	Hose Cuff (Gray)
12	C-14005	Micro Filtration Paper Bag 12 Pk	60	C-70251	Handle Grip (Gray)
13	C-77003	Screw	61	C-34500	Handle Lever Rod
14	C-77032	Screw	62	C-34505	Switch Knob
15	C-70591	Handle Fitting (Front)	63	C-34511	Switch Window (Gray)
16	C-75090	Printed Circuit Board Holder	64	C-70505	Upper Cord Hook (Gray)
17	C-32002	Cord Holder (Black)	65	C-77005	Spring Washer
18	C-18402	Filter Supporter Screen	66	C-77003	Screw
19	C-18007	Secondary Carbon Filter	67	C-77000	Screw
20	C-18422	Bag Support (Red)	68	C-77003	Screw
21	C-75700	LED Light Window (Clear)	69	C-77012	Screw
22	C-75906	Switch Housing Cover (Blue)	70	C-70521	Handle Cord Clip
23	C-76902	Dust Cover Seal	71	C-30005	Power Cord 33' 17/2 (Gray)
24	C-75590	Slide Knob (Gray)	72	C-70002	Handle Tube
25	C-77026	Screw	73	C-77034	Screw
26	C-76022	Motor Compartment Seals	74	C-77014	Washer
27	C-75899	Motor Exhaust Housing W/Gasket	75	C-77010	Cord Hook Spring
29	C-77030	Handle Screw	76	C-70506	Lower Cord Hook (Gray)
30	C-70000	Screw	78	C-70763	Stretch Hose Holder (Gray)
31	C-75804	Latch Bracket (Gray)	79	C-45002	Long Hose Cuff
32	C-75027	Cover Latch (Gray)	80	C-60010	Lamb Motor Twin Fan
33	C-77027	Cover Latch Spring (Gray)	81	C-63000	Carbon Brush
34	C-75504	Dust Compartment Cover CR89	82	C-62010	Motor Mount (Front)
34	C-75505	Dust Compartment Cover CR99	83	C-32600	Cord Clip Rubber
35	C-70000	Screw	84	C-62020	Motor Support Cover (Black)
36	C-75038	Motor Cover Assembly (Blue)	85	C-76030	Motor Support Cover Foam
37	C-76010	Motor Cover Seal	86	C-62025	Motor Mount (Rear)
38	C-71505	Cap Nut	87	C-62033	Motor Support Housing (Black)
39	C-71001	Rear Wheel (Black)	88	C-76033	Motor Support Housing Foam
40	C-77033	Washer	89	C-70000	Screw
41	C-71003	Rear Wheel Shaft	90	C-36050	Printed Circuit Board
42	C-77034	Screw	91	C-32090	Cord Protector
43	C-75824	Filter Cover (Blue)			
44	C-77035	Screw			
45	C-75828	Filter Holder (Blue)			
46	C-18054	HEPA Filter			
47	C-77035	Screw			

# CIRRUS/PROGRADE Original & Replacement

Model CR89, CR99




# Original & Replacement **CIRRUS/PROGRADE**

Model CR89, CR99

KEY	PART NO.	DESCRIPTION	KEY	PART NO.	DESCRIPTION
1	C-73004	Nozzle Housing CR89	53	C-36908	Lead Wire (Black)
1	C-73005	Nozzle Housing CR99	54	C-36005	Thermal Switch
2	C-73400	Plastic Bushing (Black)	55	C-77005	Washer
3	C-73630	Clutch Pedal Pivot (Gray)	56	C-77047	Screw
4	C-73632	Carpet/Floor Pedal (Gray)	57	C-32003	Cord Clip
5	C-73634	Clutch Pedal Ring Holder (Black)	58	SS-3270	Wire Nut
6	C-77039	Bottom Plate Lock Screw	59	C-36906	Lead Wire Black
7	C-73410	Clear Lens	60	C-36904	Lead Wire White
8	C-73480	Nozzle Housing Felt Packing	61	C-36902	Lead Wire White
9	C-73484	Vented Support Felt Packing	62	C-36914	Wire Bushing
10	C-73482	Vented Support Fitting	63	C-73412	Reflector
11	C-40007	Nozzle Hose	64	C-77046	Screw
12	C-77040	Screw	65	C-77045	Spring Washer
13	C-77048	Clutch Crank Rod Spring	66	C-70000	Screw
14	C-73635	Upper Clutch Pedal Ring (Black)	67	C-73414	Bulb Socket
15	C-73636	Lower Clutch Pedal Ring (Black)	68	FA-3515	Light Bulb
16	C-73637	Clutch Pedal Ring Pin	69	C-76100	Bottom Plate Assembly
17	C-73638	Clutch Crank Rod Pin	70	C-76001	Bottom Plate Seal
18	C-73647	Clutch Crank Rod Ass'y (Includes Items 16-23, 30)	71	C-71010	Front Plate Wheel Pin
19	C-77049	E-Clip	72	C-71011	Front Wheel (Black)
20	C-77050	Washer	73	C-77015	Push-On Nut
21	C-77051	E-Clip	74	C-77016	Screw
22	NLA	Clutch Crank Rod Pin Holder (Order C-73647)	75	C-77017	Bottom Plate Latch Washer
23	C-73641	Pedal Frame Holder	76	C-76101	Bottom Plate
24	C-73642	Foot Pedal Complete (Gray)	77	C-77018	Bottom Plate Latch Spring
25	C-73643	Foot Pedal (Gray)	78	C-76400	Bottom Plate Latch (Black)
26	C-73782	Foot Pedal Shaft	79	C-20002	Agitator Assembly
27	C-73792	Rear Belt Cover (Gray)	80	C-20500	Agitator Core
28	C-77052	Foot Pedal Spring	81	C-20510	Rubber End Cover (Black)
29	C-73646	Pedal Frame	82	C-20512	End Cap
30	C-77046	Screw	83	C-77036	Agitator Felt Washer
31	C-77043	Screw	84	C-77037	Washer
32	C-77052	Screw	85	C-62000	Agitator Bearing
33	C-77032	Screw	86	C-20514	Agitator Bearing Holder
34	C-73500	Clutch Crank Rod Frame Complete	87	C-22000	Brush Strip
35	C-73502	Clutch Crank Rod	88	C-20524	Clutch Pulley (Large) Complete
36	C-73504	Clutch Crank Rod Frame	89	C-20525	Clutch Pulley (Large)
37	NLA	Clutch Lever Boot (Order C-73500)	90	C-77028	E-Clip
38	C-77053	E-Clip	91	C-77038	Washer
39	C-73508	Clutch Lever	92	C-20526	Clutch Pulley (Small) Complete
40	C-77054	Clutch Crank Rod Spring	93	C-20528	Clutch Pulley (Small) Cover
41	C-73501	Clutch Crank Rod Frame Shaft	94	C-20527	Clutch Pulley (Small)
42	C-77055	Washer	95	C-20522	Agitator Shaft
43	C-77056	Rod Frame Shaft Spring	96	C-73430	Hose Inlet Fitting
44	C-77037	Washer			
45	C-73512	Clutch Crank Rod			
46	C-77057	Spring Pin			
47	C-73514	Clutch Crank Rod Pin			
48	C-77032	Screw			
49	C-10000	Belt 2 Pk			
50	C-74102	Furniture Guard (Gray)			
51	C-77044	Washer			
52	C-77000	Screw			

# CIRRUS/PROGRADE Original & Replacement

Models CR79, CR89, CR99



KEY	PART NO.	DESCRIPTION
1	C-50008	Telescopic Wand Complete Metal
2	C-53000	Dusting Brush (Gray)
3	C-52000	Upholstery Tool (Gray)
4	C-54000	Crevice Tool (Gray)
5	C-75061	Wand Retainer CR79 Green
5	C-75062	Wand Retainer CR89 Blue
6	C-77000	Screw
7	C-77005	Washer
8	C-16000	Check Bag Lever (Red)
9	C-16010	Check Bag Lever Holder (Red)
10	C-77000	Screw
11	C-34050	Switch
12	C-75100	Check Bag Round Knob
13	C-77058	Check Bag Spring
14	C-75102	Check Bag Crank

KEY	PART NO.	DESCRIPTION
15	C-75104	Check Bag Cover (Green) CR79
15	C-75106	Check Bag Cover (Blue) CR89
16	C-75080	Tool Clip (Gray)
17	C-75082	Motor Cord Cover (Green) CR79
17	C-75084	Motor Cord Cover (Blue) CR89, CR99
18	C-75076	Upholstery Tool Clip (Gray)
19	C-75074	Wand Retainer Clip (Gray)
20	C-77000	Screw
21	C-74000	Warning Label
22	C-75072	Upper Wand Clip (Gray)
23	C-75070	Lower Wand Clip (Gray)
24	C-50009	Plastic Extension Wand
25	FA-5716	Air-Driven Upholstery Nozzle CR99
	RO-UTT020	Belt For Air-Driven Upholstery Tool CR99