


# CIRRUS Original & Replacement

Model Ladybug LB102



# Original & Replacement **CIRRUS** Model Ladybug LB102

KEY	PART NO.	DESCRIPTION	KEY	PART NO.	DESCRIPTION
1	C-1021	Decorative Plate	23	C-10223	Cover Latch
2	C-1022	Powercord	24	C-10224	Airflow Indicator
3	C-1023	Cord Reel	25	C-10225	Swivel
4	C-1024	Motor	26	C-10226	Swivel Supporting Board
5	C-1025	Motor Mount	27	C-10227	Swivel Seal Ring
6	C-1026	Rear Motor Mount	28	C-10228	Protective Hook Cover
7	C-1027	Circuit Board	29	C-10229	Protective Hook
8	C-1028	Outlet Grill	30	C-10230	Dust Bag Frame
9	C-1029	Outlet Filter	31	C-14050	Dust Bag W/Filter 5 Pk
10	C-10210	Rear Cover	32	C-10232	Inlet Filter
11	C-10211	Spring	33	C-10233	Body Seal Ring
12	C-10212	Cord Rewind Button	34	C-10234	Crevice Tool
13	C-10213	Power Switch	35	C-10235	Dust Brush
14	C-10214	Spring	36	C-10236	Extension Tube
15	C-10215	Switch Button	37	C-10237	Floor Brush
16	C-10216	Handle	38	C-10238	Hanging Block
17	C-10217	Switch Fixing Plate	39	C-10239	Wheel
18	C-10218	Sliding Knob	40	C-10240	Lower Body
19	C-10219	Front Cover	41	C-10241	Castor
20	C-10220	Swivel Cover	42	C-10242	Castor Fixing Block
21	C-10221	Hose			
22	C-10222	Spring			