

EXPLOSION PARTS & LIST

CT-20DXQD and CT-20DXQS

Numbers with * applies only to CT-20DXQS (Dirt Sensor) parts.

DIAGRAM #	STOCK #	DESCRIPTION
8	40713	SCREW
9	40724	MOTOR GASKET
10	40999	BELT
11	40284	MOTOR SPRING
12	41010	LOWER PLATE
13	41021	MOTOR
14	40317	MOTOR BRIDGE
15	41032	OVERLOAD PROTECTOR
16	39943	LIGHT BULB
17	41043	BULB SOCKET
18	40339	HANDLE RELEASE PEDAL
19	40350	SWIVEL
*19	41131	SWIVEL
21	40768	WIRE CONNECTOR
22	40383	SWIVEL SEAL
23	41054	WHEEL
24	40405	PEDAL EASY RELEASE
*24	41142	PEDAL EASY RELEASE
25	40416	REAR COVER
*25	41153	REAR COVER
26	40427	FRONT AXLE ASSEMBLY
27	41065	AGITATOR UNIT
28	40801	INDICATOR WINDOW
29	41076	LIGHT LENS
30	40823	EXHAUST FOAM
31	41087	WINDOW REFLECTOR
32	40460	CORD & PLUG ASSEMBLY
*32	41164	LEAD WIRE UNIT
33	41098	REFLECTOR NOZZLE
34	41109	NOZZLE HOUSING (DECO)
*34	41252	NOZZLE HOUSING (DECO)
35	40867	SWIVEL CAP
36	40878	CAM INDICATOR
*37	41186	FRONT COVER
*38	41197	PCB "B" UNIT
*39	41208	SCREW
*40	41263	PCB DIRT SENSOR
41	41120	LEAD WIRE
42	40570	INDICATOR LEVER
43	40581	PAD FOOT PEDAL
44	40592	INDICATOR BLOCK
45	40603	SPRING ASSIST
*46	41230	WINDOW DIRT SENSOR
47	40625	LIFTER
*48	41241	SCREW
*49	41274	PCB SUPPORTER
50	40889	THRUST WASHER
51	40900	CATCH INDEXING
52	40911	WASHER
53	40922	RATCHET CATCH
54	40933	INDICATOR BLOCK ASSEMBLY
55	40944	SCREW

