


EUREKA Original & Replacement

POWER PLUS UPRIGHT 2270 SERIES

Model 2271A Shown



Original & Replacement **EUREKA**

POWER PLUS UPRIGHT 2270 SERIES

Model 2271A Shown

KEY	PART NO.	DESCRIPTION	KEY	PART NO.	DESCRIPTION
1	E-61636-2	Front Handle	34	E-61643	Torsion Spring
2	E-61637	Cord	35	E-61633	Grommet
3	E-61664	Strain Relief	36	E-61634	Air Duct Assembly
4	E-61638-1	Latch	37	E-61635	Air Duct Gasket
5	E-61639-2	Bag Cover Assembly	38	E-61631-1	Height Adjustment Knob
6	E-61646	Air Inlet Gasket	39	E-61612-2	Hood
7	E-61850	HEPA Filter Style HF7	40	E-61613	Belt Cover
7	ER-1837	HEPA Filter Style HF7	41	E-61540	Brushroll
8	E-61642-2	Motor Cover	42	E-61616	Rear Wheel
9	E-61857	Lens	43	E-61615	Rear Wheel Shaft
10	E-61858	Cover	44	E-61520	Belt Style J 2 PK
11	E-61663	Thermostat	44	PR-1010	Belt Style J
12	E-61632-1	Motor	45	E-61622	Gasket
13	E-61849	Light Socket	46	E-61623	Front Wheel Ass y
14	E-61823	Light Bulb	47	E-61624	Front Wheel Axle
15	E-61641-1	Switch Pedal	48	E-61630-1	Handle Release Pedal
16	E-61530	Motor Filter	49	E-61629	Spring
17	E-61660	Rear Handle	50	E-61628	Switch Support
18	E-61659-1	Cord Hook	51	E-61614	Clamp
19	E-61658	Spring	52	E-61617-1	Bumper
20	E-61657	Dust Brush Support	53	E-61626	Clip Ring
21	E-61656	Hose Frame	54	E-61625	Base
22	E-61799	Screw	55	E-61614	Screw
23	E-61655	Clip	56	E-61621-1	Adjustment Frame
24	E-61654	Bag Cover Gasket	57	E-61627-1	Wheel Carriage
25	E-61652	Tool Caddy	58	E-61626	Spring
26	E-61653	Air Tube	59	E-61625	Spring Plate
27	E-61648	Air Tube Connector		E-61515	Paper Bag Style J 3 Pk
28	E-61650	Rear Housing		ER-1440	Paper Bag Style J 3 Pk
29	E-61644	Switch Cover		E-61535	Hose
30	E-61651	Hose Cuff		E-61531	Wand
31	E-61647	Strain Relief		E-61532	Crevice Tool
32	E-61645	Switch		E-61536	Dust Brush
33	E-61649	Compression Hose		E-61775	Turbo Nozzle