

EUREKA Original & Replacement

DREAM MACHINE EXTRACTOR Model 2450A Shown

Figure A




Figure C




Figure B





Figure D



Original & Replacement **EUREKA**

DREAM MACHINE EXTRACTOR Model 2450A Shown

Figure A

KEY	PART NO.	DESCRIPTION
1	E-15322	Upper Handle Assembly
2	E-36052-3	Rocker Switch
3	E-15317-254N	Hose Caddy
4	E-53238-27	Screw
5	E-02191A-254N	Rear Housing
6	E-59051-1	Reservoir Tubing
7	E-38928	Coupling Tee
8	E-38752-119N	Supply Cord
9	N/A	Dispense Trigger (Order E-15322)
10	E-53197-1	Screw
11	E-27769-119N	Upper Arm
12	E-38945B305N	Actuator Plunger
13	E-60207	Filter (Package of 1 Reservoir Filter and 1 Basket Filter & 1 Uph. Nozzle Filter)
14	E-38845-119N	Boot Seal
15	E-53238-27	Screw
16	E-27903	Housing Cover
17	E-38941F	Reservoir Assembly
18	E-27846-119N	Lower Arm
19	E-60219	Arm Spring
20	E-38874-119N	Rear Housing Cord
21	E-59090-1	Tubing To Water Pump (16" Long)
22	E-59092-1	Tubing To Floor Nozzle (30" Long)
	E-39017	Dispensing Valve (Not Illustrated)

Figure B

1	E-38735-119N	Tank Cap
2	E-53238-27	Screw
3	E-15316-254N	Motor Cover
4	E-53238-27	Screw
5	E-38737-254N	Axle Cover (L.H.)
6	E-53238-27	Screw
7	E-38756-254N	Axle Cover (R.H.)
8	E-60223-1	Hood & Graphics Assembly
9	E-60224	Hood Screw
10	E-60204	Suction Cover & Graphics
11	E-60622	Dispensing Tank Only
11	E-60206	Dispensing Tank Ass'y (Also Includes Key Numbers 12, 13, 14, 16, 17 In Figure A)
12	E-60226-1	Shroud & Graphics Assembly
13	E-53238-27	Screw
14	E-38741-247N	Rotor Knob
15	E-59025-1	Gasket
16	E-60202	Bare Floor Attachment
17	E-27981	Air Separator
18	E-60227	Suction Cover Screws

Figure C

1	E-58745	Wire & Terminal (Ground Wire)
2	E-60192-1	Splice Close End
3	E-60218	Motor Assembly
4	E-38853-247N	Handle Release Cover
5	E-27880-1	Handle Release
6	E-60217	Handle Spring

N/A = Not Available

NLA - No Longer Available

KEY	PART NO.	DESCRIPTION
7	E-27907A	Motor Support & Exhaust Cover
8	E-53238-8	Screw
9	E-53238-41	Screw
10	E-27782	Snap Switch
11	E-58971	Wire & Terminal
12	E-27843-254N	Rear Wheel
13	E-38392	Wheel Axle
14	NLA	Base Assembly W/Wheels
15	E-38746	Spray Tip Difuser Ass'y
16	E-46713-5	Wire Tie
17	E-53238-27	Screw
18	E-38833-316N	Horseshoe Strap
19	E-60221	Motor & Pump Assembly Complete
20	E-58738	Wire & Terminal (Term. on Both Ends)
21	E-58974	Wire & Terminal (Term. on 1 End)
22	E-27785	Valve Assembly Complete (Includes Valve Housing, Valve Rotor, Valve Cover, Screws, Gasket)
	E-58975	Wire & Terminal Assembly
23	E-54709	Wheel Retainer
24	E-58742	Wire & Terminal (Term. on Both Ends)
25	E-58739	Wire & Terminal (Term. on 1 end)
26	E-58743	Wire & Terminal (Term. on 1 end)
27	E-60129	Flat Belt
28	E-60220	Motor Assembly No Pulley
28	E-60623	Motor Assembly With Pulley
29	E-38738-254N	Belt Cover
30	E-54669-1	Screw
31	E-60203	Brushroll Ass'y
	E-38922-119N	Tubing Clip (Not Illustrated)
	E-38918	Tubing Sleeve (Not Illustrated)

Figure D

1	E-59095	Hose Clamp
2	E-60201	Upholstery Sponge Tool
3	E-60200	Upholstery Brush Tool
4	E-27765-254N	Attachment Handle
5	E-27767-324N	Attachment Nozzle
6	E-38745-254N	Nozzle Spray
7	E-38730A-254N	Pinch Trigger
8	E-38937-119N	Overflow Float
9	E-27866-119N	Float Basket
10	E-60207	Filter (Package of 1 Reservoir Filter and 1 Basket Filter & 1 Uph. Nozzle Filter)
11	E-15309-324N	Recovery Tank
12	E-59052	Hardware Package
13	E-46713-5	Wire Tie
14	N/A	Attachment Hose (Order E-15321B)
15	N/A	Tubing Included with E-15321B Only
16	E-60222	Trigger Spring
17	E-15321B	Upholstery Hose Assembly Complete
18	E-60205	Recovery Tank Assembly (Includes Gasket, Tank Lock, Tank Lid, Lid Plate, Gasket)
19	E-60170	Shampoo 64 oz. 4/Case
	E-58770A	Owners Guide