


This Owner's Manual is provided and hosted by [Appliance Factory Parts](#).



Eureka 3123A Owner's Manual

[Shop genuine replacement parts for Eureka 3123A](#)



[Find Your Eureka Vacuum Cleaner Parts - Select From 855 Models](#)

----- Manual continues below part list -----

Available Replacement Parts for Eureka 3123A

ER-1403	EUREKA STYLE C DVC PAPER BAG (3 PACK)
ER-1473	EUREKA STYLE C DVC PAPER BAGS (3 PK)
E-26197	FILTER
Fa-3400	switch â€“ step on 1 Inch Leads.

EUREKA

Original & Replacement

MIGHTY MITE

Model 3123A Shown

KEY	PART NO.	DESCRIPTION
1	E-13709-2	Tool Support
2	E-37554-6	Exhaust Cover Ass'y
3	E-55399	Pin
4	NLA	Foam Cover
5	E-54151-3	Push Switch Plastic
5	FA-3400	Push Switch Metal
6	E-37117-6	Switch Cover
7	E-37116-6	Latch Cover
8	E-42797	Spring
9	E-53197-1	Screw
10	E-53197-2	Screw
11	NLA	Body Half Set Includes*
	E-55451	*Front Cover Gasket (Not Illustrated)
13	E-55406	Castor Ass'y
13	EXR-7120	Castor Ass'y
14	E-55399	Pin
15	E-26236-6	Front Cover Ass'y
16	E-55514	Wheel W/Bearing
17	E-37115-2	Cord Release Hook
18	E-55363A	Gasket
19	E-34732-2b	Cord
19	FA-3020	Cord 20' White
19	FA-3030-1	Cord 30' White
20	E-55463	Gasket
21	E-53214-2	Wire Nut
21	SS-3270	Wire Nut
22	E-54336	Motor
22	GS-041	Motor
23	E-53228-9	Screw
24	E-26218	Motor Shield
25	E-56146	Thermostat
26	E-26190	Motor Mounting Gasket
27	E-53141	Cable Tie
28	E-55394	Gasket
29	E-13686-1	Motor Support
30	E-26197	Filter
31	E-52318	Paper Bag Style C 3 Pk
31	ER-1403	Paper Bag Style C 3 Pk
31	E-57697	Paper Bag Style C Filteraire 3 Pk
31	ER-1473	Paper Bag Style C Micro-lined DVC 3 Pk
32	ER-1230	Cloth Bag Ass'y
	E-53363-1	Hose Assembly

NLA = No Longer Available

