


This Owner's Manual is provided and hosted by Appliance Factory Parts.




Eureka 3134A Owner's Manual

[Shop genuine replacement parts for Eureka 3134A](#)




[Find Your Eureka Vacuum Cleaner Parts - Select From 855 Models](#)

----- Manual continues below -----



Ref#	Part	Description	Comments	Qty
1	13709-2	SUPPORT - TOOL		
2	14595-2	WHEEL - REAR		
3	37115-2	HOOK - CORD RELEASE		
4	37116-2	LATCH - COVER		
5	37554-2	EXHAUST COVER ASSEMBLY		
6	42797	SPRING - CARPET NOZZLE		
7	53197-1	SCREW PACKAGE		
8	53197-2	SCREW PACKAGE		
9	54152-2	SWITCH ASSEMBLY		
10	55363A	GASKET - FRONT COVER		
11	55399	PIN		
12	55406	CASTER ASSEMBLY		
13	55451	GASKET		




Ref#	Part	Description	Comments	Qty
1	26190	GASKET - MOTOR MOUNTING		
2	26197	FILTER		
3	34732-25	CORD - LOW LEAD (18 GA)		
4	52318	PAPER BAG - STYLE C		
5	53141	TIE - CABLE		
6	53214-2	WIRE SPLICE 5		
7	53228-9	SCREWS - PACKAGE 10		
8	53376	MOTOR ASSEMBLY - PACKAGED		
9	55394	GASKET		
10	55463	GASKET - MOTOR STACK		
11	56146	THERMOSTAT		

MODEL 3134A



53454-8 UPHOLSTERY NOZZLE
48188 BRUSH 145FT



53355-1 HOSE ASS'Y.
66221-3 BLENDER




48M4Y-7 DUSTING BRUSH
33787 INSERT



53356-2 CARPET NOZZLE
42797 SPRING
55087A BRUSH ASS'Y.
25876-3 BLOW
26761 BRUSH LEV.



54308-1 DEVICE TOOL



14310-2 STRAIGHT WAND

Ref#	Part	Description	Comments	Qty
1	14070-2	WAND - STRAIGHT		
2	25878-3	ELBOW		
3	33787	INSERT - HINGLOCK BRUSH		
4	42797	SPRING - CARPET NOZZLE		
5	45947-7	DUSTING BRUSH - PACKAGED		
6	46186	BRUSH		
7	53366-2	CARPET NOZZLE & ELBOW - P		
8	53363-1	HOSE ASSEMBLY - CARTONED		
9	53454-6	UPHOLSTERY NOZZLE ASSY -		
10	54308-1	TOOL - CREVICE		
11	55037A	BRUSH		
12	55221-3	BLEEDER		