


This Owner's Manual is provided and hosted by Appliance Factory Parts.




Eureka 3140D Owner's Manual

[Shop genuine replacement parts for Eureka 3140D](#)



[Find Your Eureka Vacuum Cleaner Parts - Select From 855 Models](#)

----- Manual continues below -----



PARTS1 - 3140D

Ref #	Part	Description	Comments	Qty
1	13709-2	SUPPORT - TOOL		
2	37115-2	HOOK - CORD RELEASE		
3	37116-2	LATCH - COVER		
4	37554-2	EXHAUST COVER ASSEMBLY		
5	42797	SPRING - CARPET NOZZLE		
6	53197-1	SCREW PACKAGE		
7	53197-2	SCREW PACKAGE		
8	55383A	GASKET-FR COVER (NLA)		
9	55399	PIN		
10	55406	CASTER ASSY		
11	55451	GASKET		
12	55514-1	WHEEL - REAR		
13	55538	SPACER - SWITCH		

PARTS2 - 3140D

Ref #	Part	Description	Comments	Qty
1	26190	GASKET - MOTOR MOUNTING		
2	26197	FILTER		
3	26673	MOTOR ASSEMBLY - PACKAGED		
4	36528-5	CORD & POLARIZED PLUG ASSY		
5	52318	PAPER BAG PRG ASSY (STYLE		
6	53141	TIE - CABLE (PURCHASED)		
7	53214-2	WIRE SPLICE 5		
8	53228-4	SCREWS - PACKAGE 10		
9	55394	GASKET		
10	55463	GASKET - MOTOR STACK		
11	56146	THERMOSTAT		

ACCESSORIES - 3140D

MODEL 3140D



34681-7 UPHOLSTERY NOZZLE
46186 BRUSH INSERT



13491A-9 CARPET NOZZLE
42787 SPRING
53037 BRUSH ASS'Y.
25676 3 ELBOW
46328 BRUSH LEVER



28715A-8 RADIATOR TOOL



53368-8 HOSE ASS'Y.
37668-3 BLEEDER



45947 7 DUSTING BRUSH
53787 INSERT



28002-5 FLOOR & WALL BRUSH
26378-8 ELBOW
J3405 BRISTLE STRIP
36877 INSERT
36878 INSERT



14070-2 STRAIGHT WAND

ACCESSORIES - 3140D

Ref #	Part	Description	Comments	Qty
1	13491A-9	Discontinued, use 54778		
2	14070-2	WAND - STRAIGHT		
3	23713A-8	TOOL - CREVICE		
4	25878-3	ELBOW		
5	26002-5	FLOOR & WL BRUSH & ELBOW-		
6	33405	BRISTLE STRIP-FL & WALL B		
7	33787	INSERT - RINGLOCK BRUSH (NLA)		
8	34691-7	UPHOLSTERY NOZZLE ASSY -		
9	36877	INSERT-FLOOR & WALL BRUSH		
10	36878	INSERT-FLOOR & WALL BRUSH		
11	37653-3	BLEEDER		
12	42797	SPRING - CARPET NOZZLE		
13	45947-7	DUSTING BRUSH - PACKAGED		
14	46186	BRUSH		
15	53363-3	HOSE ASSEMBLY - CARTONED		
16	55037	BRUSH INSERT		