

This Owner's Manual is provided and hosted by [Appliance Factory Parts](http://www.appliancefactoryparts.com).



Eureka 3320E Owner's Manual

[Shop genuine replacement parts for Eureka 3320E](#)



[Find Your Eureka Vacuum Cleaner Parts - Select From 855 Models](#)

----- Manual continues below part list -----

Available Replacement Parts for Eureka 3320E

[E-52015](#)

FILTER, DISK , 15PK

Ref#	Part	Description	Comments	Qty
1	13738-5	SWITCH ASSEMBLY		
2	23792-10	GUARD - FURNITURE		
3	24128A	SUPPORT - FILTER		
4	24766-4	PEDAL - SWITCH		
5	26211	MOTOR ASSY - PACKAGED		
6	34562	LOCATOR		
7	35845-1	PIN		
8	36528-3	CORD & POLARIZED PLUG ASS		
9	37028	HINGE BRACKET		
10	37423	MOTOR MOUNTING RING		
11	48756-1	CLIP - FILTER SUPPORT		
12	52015	PACKAGE 15 FILTERS		
13	52323	PAPER BAG - STYLE H		
14	52385-1	LATCH REPLACEMENT KIT		
15	53089-1	BUSHING & STRAIN RELIEF P		
16	53108	BOLT & NUT PACKAGE (5)		
17	53134	SCREW PACKAGE (10)		
18	53232-1	COTTER PINS - PACKAGE 10		
19	55056	GASKET - BAG		
20	55446	NUT - SWITCH		
21	56558-2	MOUNTING SCREW & BUSHING		
22	EW22-37	WIRE SPLICE 5		

ATTACHMENTS FOR MODEL 3320E



26201-3 HOSE ASS'Y.
55221-2 BLEEDER



14070-1 STRAIGHT WAND



29713A-7 RADIATOR TOOL



34691-6 UPHOLSTERY NOZZLE



45947-6 DUSTING BRUSH
33767 INSERT



13481A-1 CARPET NOZZLE
42797 SPRING
55037 BRUSH ASS'Y.
25876-2 ELBOW

Ref#	Part	Description	Comments	Qty
1	13491A-1	CARPET NOZZLE & ELBOW - P		
2	14070-1	WAND - STRAIGHT		
3	23713A-7	TOOL - CREVICE		
4	25878-2	ELBOW		
5	28201-3	HOSE ASSEMBLY - CARTONED		
6	33787	INSERT - RINGLOCK BRUSH		
7	34691-6	UPHOLSTERY NOZZLE ASSY -		
8	42797	SPRING - CARPET NOZZLE		
9	45947-6	DUSTING BRUSH - PACKAGED		
10	55037	BRUSH		