


This Owner's Manual is provided and hosted by [Appliance Factory Parts](http://Appliance Factory Parts).



# Eureka 3630A Owner's Manual

[Shop genuine replacement parts for Eureka 3630A](#)



[Find Your Eureka Vacuum Cleaner Parts - Select From 855 Models](#)

----- Manual continues below part list -----

## Available Replacement Parts for Eureka 3630A

<a href="#">ER-1414</a>	EUREKA STYLE N DVC PAPER BAG (3 PACK)
<a href="#">E-38333</a>	FILTER, BAG 1PK

# Original & Replacement **EUREKA**

**MIGHTY MITE II**  
Model 3630A Shown

KEY	PART NO.	DESCRIPTION
1	E-38329-2	Switch Ass'y
2	E-38280-1	Latch Cover
3	E-57867	Latch Spring
4	E-53197-1	Screw
5	E-54549-3	Bag Cover
6	E-53197-2	Screw
7	E-54553-3	Body Set
	E-55919-1	Gasket (Not Illustrated)
9	E-27281-1	Hose Coupling Plate
10	E-55406	Castor Ass'y
10	EXR-7120	Castor Ass'y
11	E-37115-4	Cord Release Hook
12	E-54550-1	Rear Wheel
13	E-27382-1	Cord Ass'y
14	E-56146	Thermostat
15	E-55463	Gasket
16	E-53141	Cable Tie
17	E-53214-2	Wire Nut
17	SS-3270	Wire Nut
18	E-54401	Motor Ass'y
18	GS-041	Motor Ass'y
19	E-26715A	Motor Mounting Gasket
20	E-14757-1	Motor Plate
21	E-38333	Filter
22	E-57988	Style N Paper Bag
22	ER-1414	Style N Paper Bag
22	E-58152	Cloth Bag
	E-58151	Carrying Strap
	E-53363-1	Hose Assembly

