


## PARTS1 - 3671A-1


Ref #	Part	Description	Comments	Qty
1	15376-5	SWITCH ASSY		
2	27964-119N	EXTENSION TUBE		
3	37409-1	WHEEL - CASTER		
4	38333	FILTER		
5	38805-1	CASTOR ASSY.		
6	38955-TSV	FRONT COVER ASSEMBLY		
7	59045-1	GASKET - FRONT COVER		
8	60296	PAPER BAG PKG ASSY 3MM FA		
9	60487-10	HOUSING ASSEMBLY - PACKAG		

8. 28008A-1 REAR HOUSING ASSY  
15409A-119 REAR WHEEL




## PARTS2 - 3671A-1

Ref #	Part	Description	Comments	Qty
1	15409A-119N	WHEEL - REAR		
2	28008A-1	REAR HOUSING ASSEMBLY		
3	28032	GASKET - MOTOR MOUNTING		
4	28052	BUSHING - MOTOR		
5	39028	SHIELD - WIRE		
6	53214-2	WIRE SPLICE 5		
7	59717	THERMOSTAT & TERMINAL ASSY.		
8	59718	SUPPLY CORD & TERMINAL AS		
9	60261-2	MOTOR ASSEMBLY - PACKAGED		
10	60610	SCREW PKG		



NOT ILLUSTRATED  
59535 OWNER'S GUIDE



- 2. 61118-1 HOSE ASSY COMPLETE
- 15355-119N HOSE COUPLING
- 26193-3 CURVED HANDLE ASSY

## ACCESSORIES - 3671A-1

Ref #	Part	Description	Comments	Qty
1	14070-3	WAND - STRAIGHT		
2	15355-119N	COUPLING - HOSE		
3	26193-3	CURVED HANDLE ASSEMBLY		
4	26708-119N	TOOL - CREVICE		
5	61037	COMBINATION TOOL - PACKAG		
6	61118-1	HOSE ASSEMBLY - CARTONED		