



**60487-1 HOUSING ASSY**  
**38805-1 CASTER ASSY**  
**37409-1 WHEEL & HUB**




**38956 FRONT COVER ASSY**  
**59046-1 FRONT COVER GASKET**  
**27964-119N EXTENSION TUBE**




## PARTS1 - 3873A

Ref #	Part	Description	Comments	Qty
1	15376-5	SWITCH ASSY		
2	27964-119N	EXTENSION TUBE		
3	37409-1	WHEEL - CASTER		
4	38333	FILTER		
5	38805-1	CASTER ASSEMBLY		
6	59046-1	GASKET - FRONT COVER		
7	59206	GASKET - FOAM		
8	60295	PAPER BAG PKG ASSY (3MM)		
9	60487-1	HOUSING ASSEMBLY - PACKAG		



## PARTS2 - 3873A

Ref #	Part	Description	Comments	Qty
1	15409-119N	Discontinued, use 15409A (NLA)		
2	27985	MOTOR BUSHING		
3	28008-1	REAR HOUSING ASSEMBLY		
4	28032	GASKET - MOTOR MOUNTING		
5	59154	SCREW PKG		
6	59190	THERMOSTAT & TERMINAL ASS		
7	59191A	CORD & TERMINAL ASSEMBLY		
8	60192-1	WIRE SPLICE 5		
9	60445	MOTOR ASSEMBLY - CARTONED		



**OWNERS GUIDE 59194A**

## ACCESSORIES - 3673A

Ref #	Part	Description	Comments	Qty
1	15355-119N	COUPLING - HOSE		
2	25878-4	ELBOW		
3	26193-3	CURVED HANDLE ASSEMBLY		
4	37653-3	BLEEDER		
5	54723	Discontinued, use 14070-3		
6	54780	TOOL - CREVICE		
7	54784	COMBINATON TOOL - PACKAG		
8	60289-1	HOSE ASSEMBLY - CARTONED		