



5401P-21 BAG COVER & GRAPHICS ASS'Y.
57471-1 GASKET



57829-18 UPPER SHELL & LATCH ASS'Y. (INCLUDES)
28651-4 CONNECTOR ASS'Y.
28855-15 BUTTON LATCH
31955 WIRING SHIELD
58807 RETAINER RING
55919-1 GASKET
55734 SPRING



53576-6 LOWER SHELL & WHEEL ASS'Y. (INCLUDES)
28440-25 REAR WHEEL ASS'Y.
37400-1 CASTER ASS'Y.
63236-22 SCREW
56576 WASHER

PARTS1 - 3977B


Ref #	Part	Description	Comments	Qty
1	14656-5	CORD REEL ASSY		
2	26440-25	WHEEL-REAR-BLACK		
3	26649A-14	BUTTON SW (26649A-18)		
4	26650-8	CORD REEL BUTTON (26650-9)		
5	26651-4	CONNECTOR ASSY (26651-3)		
6	26653-15	BTN-LATCH-BLK (26653-4)		
7	26715	GASKET - MOTOR MOUNTING		
8	36341-2	SWITCH PUSH		
9	37403-1	CASTER		
10	37657	FILTER-MOTOR		
11	37710	Discontinued, use 37710-1		
12	37761-1	BAG INDICATOR ASSY		
13	37781-1	CORD GUIDE (NLA)		
14	37966	SOUND FOAM		
15	52358	PAPER BAG PKG ASSY (STYLE		
16	53141	TIE - CABLE (PURCHASED)		
17	53197-1	SCREWS-PKG 10 (56372-1)		
18	53214-2	Discontinued, use 60192-1		
19	53238-1	SCREW PKG (EW312-6T5Z		
20	53238-22	SCREW PACKAGE		
21	53376	MOTOR ASSEMBLY - PACKAGED		
22	55446	NUT - SWITCH (155437)		
23	55794	SPRING		
24	55919-1	SHELL GASKET use 58853-1		
25	56146	THERMOSTAT		
26	56326-1	WIRE TUBE (NLA)		
27	56376	WASHER		
28	56750	Discontinued, use 56750-1		
29	57471-1	Discontinued, use 57471-2		

26074A SCALE PLATE ASS'Y
 2899G GASKET
 3668D
 5652D




53997-1 DISTURBULATOR, BRG. & PULLEY ASS'Y. (INCLUDES)

83162 FELT WASHER
 83185-1 FLAT WASHER
 26472 FELT RETAINER
 25406 BEARING ASS'Y.
 83188 LOCKNUT




37859-1 LAMP SOCKET & PLATE ASS'Y (INCLUDES)
 45215 D.U.B.



PARTS2 - 3977B

Ref #	Part	Description	Comments	Qty
1	25406	DISTURBULATOR BRNG ASSY 155315		
2	25903	GASKET - SOLE PLATE (NLA)		
3	26028-1	WINDOW - BELT (155410)		
4	26047	LENS		
5	36237A-11	FURN GUARD 30 BRT WHITE (NLA)		
6	36412	RETAINER - FELT (NLA)		
7	36660	GASKET - SOLE PLATE (NLA)		
8	36954A	COVER - GROUNDING (NLA)		
9	37114	DISTURB PULLEY		
10	37859-1	POWER HD LAMP ASSY		
11	48815	LAMP - HEADLIGHT		
12	49110A	GUARD-BELT (NLA)		
13	52201A	BELT PACKAGE ASSY - STYLE		
14	53152	FELT WASHER PKG.		
15	53158	LOCKNUTS-PKG 10 (49175)		
16	53169-1	WASHERS-PKG 10 (49591)		
17	53214-2	Discontinued, use 60192-1		
18	53238-8	SCREW PKG (15543)(EW312-8-8Z)		
19	53419-1	POWERHEAD MOTOR (155406)		
20	53997-1	DISTR ASSY (155324)		
21	54087-6	LENS HOUSING & GRAPHICS -		
22	54090-6	HOUSING & GRAPHICS ASSY -		



PARTS3 - 3977B

Ref #	Part	Description	Comments	Qty
1	12578B-1	INLET DIVIDER (155310)		
2	25789-3	HOSE		
3	35970-13	POLARIZED CORD & PLUG ASS		
4	36555-3	WHEEL - BLACK		
5	36769-10	HDLE SOCKET ASY (NLA) (1 (NLA)		
6	36879-3	STRAIGHT WAND ASSEMBLY		
7	48334	AXLE - WHEEL (155314)		
8	53190-1	BUSHING-PKG 10 (155318)		
9	53200	AXLE BEARING PK (55505 (NLA)		
10	53238-B	SCREW PKG (15543)(EW312-8-8Z)		

ATTACHMENTS FOR MODEL 3977B



53579-2 HOSE ASSEMBLY
34272-5 BLEEDER



54355-1 RADIATOR TOOL



53454-8 UPHOLSTERY NOZZLE
46136 BRUSH INSERT



53355-5 FLOOR & WALL BRUSH
33405 BRISTLE STRIP
25991-3 ELBOW
36877 INSERT (FRONT)
36878 INSERT (REAR)



53455-4 DUSTING BRUSH
33787 INSERT

ACCESSORIES - 3977B

Ref #	Part	Description	Comments	Qty
1	25991-3	ELBOW		
2	33405	BR STRIP-FL & WALL BRUSH		
3	33787	INSERT - RINGLOCK BRUSH (NLA)		
4	34272-5	BLEEDER		
5	36877	INSERT-FLOOR & WALL BRUSH		
6	36878	INSERT-FLOOR & WALL BRUSH		
7	46186	BRUSH (NLA)		
8	53355-5	FLOOR & WL BRUSH & ELBOW-		
9	53454-6	UPHOLSTERY NOZZLE ASSY -		
10	53455-4	DUSTING BRUSH - PACKAGED		
11	53579-2	HOSE ASSY		
12	54355-1	TOOL - CREVICE		