


This Owner's Manual is provided and hosted by [Appliance Factory Parts](#).



GrillPro 268744 Owner's Manual

[Shop genuine replacement parts for GrillPro 268744](#)



[Find Your GrillPro Grill Parts - Select From 131 Models](#)

----- Manual continues below -----



E-Z BILT BARBECUES

ASSEMBLY MANUAL & PARTS LIST



MANUEL DE MONTAGE & LISTE DE PIÈCES





266964
266974



268524
268564
268964
268544
268584
268744
268784



269744
269784
269984



RETAIN FOR FUTURE REFERENCE








VEUILLEZ CONSERVER POUR REFERENCE ULTERIEURE



1-800-265-2150


info@omcbbq.com


Onward
MANUFACTURING COMPANY
SINCE 1906
585 KUMPF DRIVE
WATERLOO, ONTARIO, CANADA
LIMITED

4440266 REV C


X12 	X10 	X17 	X8 
X2 	X2 	X1 	





1	(4) 
----------	--




2




3





4

(3) 





5



(4) 



6




7





8

(6)




9

(4)




10




(2)




(2)








(8)



11


(2) 



12



13



PARTS LIST/LISTE DES PIECES

ITEM	PART NUMBER	DESCRIPTION	266964	266974	268524	268527	268544	268564	268584	268744	268747	268784	268964	269744	269747	269784	269984
1	909-C600	FIREBOX-BOTTOM ASSY												1	1	1	1
1A	909-C410	FIREBOX-BOTTOM ASSY															
1B	909-C300	FIREBOX-BOTTOM ASSY	1	1													
2	473-C601	LID ASSY												1	1	1	1
2A	473-C401	LID ASSY	1	1	1	1	1	1	1	1	1	1					
3	081-C500	NAME PLATE	1	1	1	1	1	1	1	1	1	1					
4	571-C500	THERMOMETER GUAGE	1	1	1	1	1	1	1	1	1	1					
5	338-C310	HANDLE SEAT-LEFT	1	1	1	1	1	1	1	1	1	1					
6	338-C311	HANDLE SEAT-RIGHT	1	1	1	1	1	1	1	1	1	1					
7	338-C613	LID HANDLE												1	1	1	1
7A	338-C413	LID HANDLE	1	1	1	1	1	1	1	1	1	1					
8	225-C630	WARMING RACK												1	1	1	1
8A	225-C430	WARMING RACK	1	1	1	1	1	1	1	1	1	1					
9	342-C640	CHANNEL-CROSS LIGHT												1	1	1	1
9A	342-C445	CHANNEL-CROSS LIGHT															
9B	342-C345	CHANNEL-CROSS LIGHT	1	1													
10	225-C620	GRID-COOKING- CASTING														1	1
10A	225-C621	GRID-COOKING- SS												1	1		
11	225-C320	GRID-COOKING- CASTING	3	3												3	3
11A	225-C321	GRID-COOKING- SS			3	3	3	3	3	3	3	3		3	3	3	3
12	156-C651	SHIELD GREASE												1	1	1	1
12A	156-C451	SHIELD GREASE	1	1	1	1	1	1	1	1	1	1					
13	393-C500	REAR BURNER ASSY		1			1	1	1	1	1	1		1	1	1	1
14	393-C641	SHIELD WIND-REAR BURNER												1	1	1	1
14A	393-C441	SHIELD WIND-REAR BURNER	1	1	1	1	1	1	1	1	1	1					
15	342-C530	ELECTRODE ASSY-REAR BURNER		1			1	1	1	1	1	1		1	1	1	1
16	156-C620	SHIELD-HEAT												1	1	1	1
16A	156-C420	SHIELD-HEAT															
16B	156-C320	SHIELD-HEAT	1	1	1	1	1	1	1	1	1	1					
17	194-C610	COVER-CONTROL ASSY												1	1	1	1
17A	194-C410	COVER-CONTROL ASSY			1	1	1	1	1	1	1	1					
17B	194-C310	COVER-CONTROL ASSY	1	1													
18	691-C650	VALVE ASSY												1		1	1
18A	691-C651	VALVE ASSY-N.G															
18B	691-C450	VALVE ASSY			1		1	1	1	1	1	1			1		
18C	691-C451	VALVE ASSY-N.G				1		1	1	1	1	1					
18D	691-C350	VALVE ASSY									1						
19	958-C322	SIDE ASSY-L.H.-CABINET	1	1	1	1	1	1					1				
19A	958-C323	SIDE ASSY-L.H.-CABINET-SS															
20	472-C512	BEZEL-CONTROL KNOB-MAIN BURNER	3	3	4	4	4	4	4	4	4	4		6	6	6	6
21	472-C565	CONTROL KNOB-MAIN BURNER	3	3	4	4	4	4	4	4	4	4		6	6	6	6
22	472-C502	BEZEL-CONTROL KNOB-SIDE/REAR BURNER	1	1	1	1	2	1	2	2	2	2		2	2	2	2
23	472-C555	CONTROL KNOB-SIDE/REAR BURNER	1	1	1	1	2	1	2	2	2	2		2	2	2	2
24	342-C640	IGNITER-ELECTRONIC	1	1										1	1	1	1
24A	342-C540	IGNITER-ELECTRONIC			1	1	1	1	1	1	1	1					
25	711-C342	SIDE SHELF ASSY-R.H.	1	1	1	1	1	1	1	1	1	1					
25A	711-C346	SIDE SHELF ASSY-R.H.-SS															
26	711-C343	FRONT COVER-R.H.-SIDE SHELF	1	1	1	1	1	1	1	1	1	1		1	1	1	1
27	C13500	MAIN BURNER	3	3	4	4	4	4	4	4	4	4		6	6	6	6
28	342-C323	ELECTRODE ASSY-MAIN BURNER	3	3	2	2	2	2	2	2	2	2		3	3	3	3
29	222-C560	FLAVOR GUARD-PORCELAIN	3	3								4		4		6	6
29A	222-C550	FLAVOR GUARD-SS			4	4	4	4	4	4	4	4		6	6		
30	958-C321	SIDE ASSY-R.H.-CABINET	1	1	1	1	1	1	1					1			
30A	958-C324	SIDE ASSY-R.H.-CABINET-SS								1	1	1		1	1	1	1
31	711-C344	SIDE SHELF ASSY-L.H.-S.B	1	1	1	1	1	1	1								
31A	711-C347	SIDE SHELF ASSY-L.H.-S.B-SS								1	1	1		1	1	1	1
32	711-C345	FRONT COVER-L.H.-SIDE SHELF	1	1	1	1	1	1	1	1	1	1		1	1	1	1
33	390-C330	BASE-SEDE BURNER	1	1	1	1	1	1	1	1	1	1		1	1	1	1
34	390-C333	SIDE BURNER	1	1	1	1	1	1	1	1	1	1		1	1	1	1
35	342-C325	ELECTRODE ASSY-SIDE BURNER	1	1	1	1	1	1	1	1	1	1		1	1	1	1
36	440-C335	VALVE ASSY-SIDE BURNER	1	1	1	1	1	1	1	1	1	1		1	1	1	1
37	225-C353	GRATE-COOKING-SIDE BURNER	1	1	1	1	1	1	1	1	1	1		1	1	1	1
38	390-C336	COVER-SIDE BURNER	1	1	1	1	1	1	1	1	1	1		1	1	1	1
39	159-C660	TRAY ASSY-GREASE												1	1	1	1
39A	159-C460	TRAY ASSY-GREASE	1	1	1	1	1	1	1	1	1	1					
40	114-C370	HOSE REGULATOR-LP	1	1	1		1	1	1	1	1	1		1		1	1
40A	111-C375	HOSE NATURAL GAS				1											
41	C11160	SCREW - 1/4 X 20 IN-SS	8	8	8	8	8	8	8	8	8	8		8	8	8	8
42	C11163	SCREW-M4X8	8	10	10	10	12	10	12	12	12	12		16	16	16	16
43	C15511	CUP-GREASE	1	1	1	1	1	1	1	1	1	1		1	1	1	1
44	C11162	SCREW - 1/4 X 60 IN-SS	12	12	12	12	12	12	12	12	12	12		12	12	12	12
45	C11161	SCREW - 1/4 X 15 IN-SS	17	17	17	17	17	17	17	17	17	17		17	17	17	17
46	184-C670	BRACKET-DOOR CATCH-SS															
46A	184-C470	BRACKET-DOOR CATCH	1	1	1	1	1	1	1					1		1	1
46B	184-C471	BRACKET-DOOR CATCH-SS								1	1	1					
47	711-C652	SHELF-LOWER-SS												1	1	1	1
47A	711-C452	SHELF-LOWER	1	1	1	1	1	1	1								
47B	711-C352	SHELF-LOWER-SS										1					
48	958-C620L	DOOR ASSY RIGHT - SS												2	2	2	2
	958-C620R	DOOR ASSY LEFT - SS															
48A	958-C420L	DOOR ASSY RIGHT - SS	2	2	2	2	2	2	2	2	2	2					
	958-C420R	DOOR ASSY LEFT - SS															
49	892-C013	CASTOR-FRONT	2	2	2	2	2	2	2	2	2	2		2	2	2	2
50	958-C690	PANEL REAR-CABINET-SS															
50A	958-C490	PANEL REAR-CABINET	1	1	1	1	1	1	1					1	1	1	1
50B	958-C390	PANEL REAR-CABINET-SS															
51	C11225	NUT - 1/4 IN	8	8	8	8	8	8	8	8	8	8		8	8	8	8
52	958-C333	RIGHT SKIRT-CABINET-SS	1	1	1	1	1	1	1	1	1	1		1	1	1	1
53	958-C334	LEFT SKIRT-CABINET-SS	1	1	1	1	1	1	1	1	1	1		1	1	1	1
54	958-C635	FRONT SKIRT-CABINET-SS												1	1	1	1
54A	958-C435	FRONT SKIRT-CABINET-SS	1	1	1	1	1	1	1	1	1	1					
55	C11164	SCREW-M4X15-SS	4	4	4	4	4	4	4	4	4	4		4	4	4	4
56	225-631	BASKET												1	1	1	1
57	892-014	CASTOR-REAR	2	2	2	2	2	2	2	2	2	2		2	2	2	2
58	070-C600	HARDWARE PACK	1	1	1	1	1	1	1	1	1	1		1	1	1	1

