


This Owner's Manual is provided and hosted by [Appliance Factory Parts](#).



Eureka 6831A Owner's Manual

[Shop genuine replacement parts for Eureka 6831A](#)




[Find Your Eureka Vacuum Cleaner Parts - Select From 855 Models](#)


----- Manual continues below part list -----

Available Replacement Parts for Eureka 6831A

73276	4-Pk Tri Wing
ER-2017	BRUSH ROLLER ROLL 54325-1
155506	MOTOR






Ref #	Part	Description	Comments	Qty
1	39737-119N	ACCESSORY COVER		
2	73278	SPRING - ACCESSORY COVER		
3	39738-355N	SWITCH PEDAL		
4	73276	SPRING - PEDAL		
5	39736-119N	This part is obsolete and there is no substitute available.		
6	39739-355N	CORD WINDER PEDAL		
8	73267-119N	SWITCH COVER		
9	39749	ON/OFF SWITCH		
10	73270-119N	HOOK		
11	39734-119N	MIDDLE SHELL		
12	39751	BAG COMPARTMENT SEAL		
13	39747	MOTOR COMPARTMENT SEAL		
14	39744-119N	REAR WHEEL ASSEMBLY		
16	39777	MOTOR ASSEMBLY		
15	39759	MOTOR SEAL		
17	39765	MOTOR SEAT		
18	39758	CORD REEL		
19	73272	CORD WINDOW SHAFT		
20	73271-355N	CORD WINDOW		
21	73265-355N	ACCESSORY COVER BUTTON		
22	73284	BAG INDICATOR COVER		
23	73283	AIR FLOW ADJUSTER		
24	73281	BAG INDICATOR BASE		
25	39776	PC BOARD		
26	73282	BAG INDICATOR BUOY		
27	73285	BAG INDICATOR SPRING		
28	39735-119N	BAG COVER ASSEMBLY		
29	73279	BAG COVER SPRING		
30	73268-355N	BAG COVER LATCH		
31	73273-119N	BAG COVER ASSEMBLY		
32	73275	RUBBER GASKET		
33	62040	EXHAUST FILTER PKG - STYL		
34	39766	FILTER SEAL		
35	73274	WIRE HOLDER		
36	39740-119N	INLET FILTER FRAM		
37	39750	INLET FILTER		
38	39746-355N	FURNITURE GUARD		
39	39760	HANDLE PLATE		
41	39733-355N	LOWER SHELL		
40	39742-355N	FRONT WHEEL SUPPORT		
43	39743-355N	FRONT WHEEL		
42	73280	FRONT WHEEL AXLE		
44	39745-355N	REAR WHEEL TIRE		
45	39741-355N	BAG HOLDER		
46	73277	BAG HOLDER SPRING		
47	73269-355N	FLOOR TOOL BRACKET		
48	39768	SOUND FOAM		



Powerhead - 6831A

Ref #	Part	Description	Comments	Qty
2	54672-35	HOOD & GRAPHICS ASSY - PK		
1	39561	LENS		
3	59045	HEADLIGHT		
4	39559	LAMP SOCKET		
5	60192-1	WIRE SPLICE 5		
6	46713-5	TIE - CABLE (PURCHASED)		
7	39566	POWER CORD		
8	53238-8	SCREW PACKAGE		
9	72315	STRAP - MOTOR		
10	54343-1	MOTOR ASSEMBLY - PACKAGED		
11	58065A	BELT PACKAGE ASSY - STYLE		
12	60279-1	DISTURBULATOR ASSY - CTND		
27	54575-30	POWER HEAD ASSEMBLY - CAR		
26	38063	GUARD - BELT		
24	60963	FRONT WHEEL ASSEMBLY		
23	54639-5	BASE ASSEMBLY - POWER HEA		
22	56180	FELT WASHER		
21	72327-355N	WHEEL - REAR		
20	39560-355N	FOOT PEDAL		
19	39562	T-JOINT COVER ASSY		
17	57992	GASKET - FELT		
16	72326-355N	T-JOINT		
15	72325-355N	QUICK DISCONNECT PEDAL		
13	39564-119N	C-RING		
14	72324-119N	COUPLING		
26	38063	GUARD - BELT		
27	54575-30	POWER HEAD ASSEMBLY - CAR		



Accessories - 6831A

Ref #	Part	Description	Comments	Qty
5	39764-119N	CREVICE TOOL		
1	61977-1	POWERHEAD ROSE ASSY - CTN		
2	39420-1	SWITCH & CONNECTOR ASSEMB		
6	39422-1	DIRECT CONNECT WAND ASSEM	Two wands need to be ordered for one complete wand assembly.	
3	39761-119N	DUSTING BRUSH		
8	61990	PAPER BAG PKG ASSY (STYLE		
4	39763-119N	UPHOLSTERY NOZZLE		