

TROUBLESHOOTING FREQUENTLY ASKED QUESTIONS

TROUBLE	PROBABLE CAUSE	SOLUTION
Unit does not turn on	Not plugged in	Plug in unit
Mist output minimal in room	Fiber has not absorbed water	Wait 15 minutes for fiber to absorb water
Fiber turns brown	The fiber has absorbed minerals	Replace your fiber (HWF100/HF235) by calling 1-800-5-HOLMES, or visit www.holmesproducts.com

FREQUENTLY ASKED QUESTIONS

QUESTIONS	ANSWER
What are the variables that affect run time?	The estimated run time for this humidifier is based on average room conditions. The actual run time of your humidifier is dependent on numerous variables such as: <ol style="list-style-type: none"> Air exchange in the room where the humidifier is placed. Room construction where the humidifier is placed. Temperature of the room where the humidifier is placed. Humidity levels in the room where the humidifier is placed. Movement of occupants and the opening and closing of doors in the room where the humidifier is placed. Home furnishings in the room where the humidifier is placed.
How do I remove fiber on water tank?	See Daily Maintenance Instructions. Regular cleaning is recommended.
How can I extend the run time?	<ol style="list-style-type: none"> Run your unit on the lowest setting. If your unit has electronics, set it to your desired humidity level. The unit will turn on and off, which will extend the run time. Fill the tank all the way full, place it on the base, let the water empty into the base and it stops bubbling, then refill the tank full again. This reserves maximum water capacity and will extend run time.

PLEASE READ AND SAVE THESE IMPORTANT SAFETY INSTRUCTIONS

- When using electrical appliances, basic safety precautions should always be followed to reduce the risk of fire, electric shock, and injury to persons, including the following:
- Read all instructions before using the appliance.
 - To avoid fire or shock hazard, plug the appliance directly into a 120V AC electrical outlet.
 - Keep the cord out of heavy traffic areas. To avoid fire hazard, NEVER put the cord under rugs or over heat registers.
 - DO NOT place humidifier near heat sources such as stoves, radiators, and heaters. DO NOT use humidifier on any heating surface or electrical outlet. The humidifier should be at least 4" away from the wall for best results.
 - NEVER place humidifier in an area where it is accessible to children. NEVER use humidifier in a dining room, particularly where a child may be sleeping, resting, or playing (to avoid room air may result in excessive humidity).
 - WARNING: Do not attempt to refill humidifier without first unplugging the unit from its electrical outlet. Failure to heed this warning may cause personal injury. Do not use the unit by pulling on the plug and not the cord.
 - Never place anything over registers and not when the unit is running.
 - NEVER drop or insert any object into any openings.
 - DO NOT operate any appliance with a damaged cord or plug, after the appliance malfunctions, or if it has been dropped or damaged in any manner. Return appliance to manufacturer for examination, electrical or mechanical adjustment, or repair.
 - Use appliance only for intended household use as described in this manual. Any other use not recommended by the manufacturer may cause fire, electric shock, or injury to persons. The use of attachments not recommended or sold by the manufacturer may cause hazards.
 - DO NOT use outdoors.
 - Always place humidifier on a flat, dry, level surface. A waterproof mat or pad is recommended for use under the humidifier. NEVER place it on a rug or carpet, or on a finished floor that may be damaged by exposure to water or moisture.
 - DO NOT allow the Moisture Outlet to directly face the wall. Moisture could cause damage, particularly in wall paper.
 - Humidifier should be unplugged when not in use.
 - NEVER tilt, move, or attempt to empty unit while it is operating. Shut off and unplug before removing the water tank and emptying the unit.
 - This humidifier requires daily and weekly maintenance to operate appropriately. Refer to daily and weekly cleaning procedures. Use only cleaners and additives recommended by the manufacturer.
 - NEVER use detergents, gasoline, glass cleaner, furniture polish, paint thinner, or other household solvents to clean any part of the humidifier.
 - Excessive humidity in a room can cause water condensation on windows and some furniture. If this happens, turn the humidifier OFF.
 - Do not use humidifier in an area where humidity level is in excess of 50%. Use a hygrometer, available at your local retailer or through the manufacturer, to measure the humidity.
 - DO NOT attempt to repair or adjust any electrical or mechanical functions on this unit. Doing so will void your warranty. The inside of the unit contains no user serviceable parts. All servicing should be performed by qualified personnel only.
 - Never place anything over water flow or moisture in liquids.
 - Do not plug in the cord with wet hands; electric shock could result.
 - Do not pour water in any openings other than the water tank.
 - To prevent damage to surfaces, do not place humidifier under overhanging surfaces.
 - NEVER operate unit without water in the tank.
 - Do not open unit after it has been used until unit cools completely.
 - The tank handle when carrying full tank of water.

THIS PRODUCT IS EQUIPPED WITH A POLARIZED PLUG (a plug having one blade wider than the other). This plug will fit into the power outlet only one way. If the plug does not fit fully into the outlet, reverse the plug. If it still does not fit, contact qualified personnel to install the proper outlet.

DO NOT DEFEAT THE SAFETY PURPOSE OF THIS POLARIZED PLUG IN ANY WAY

STORAGE INSTRUCTIONS REPLACEMENT ACCESSORIES

STORAGE INSTRUCTIONS

- When not using your humidifier for an extended period of time:
- Drain the fiber. DO NOT leave in wet.
 - Clean, rinse and thoroughly dry the humidifier as directed in weekly maintenance. DO NOT leave any water in the unit when storing. Leaving water in the unit may render the unit inoperable for the following season.
 - Place the humidifier in the original carton and store in a cool, dry place.
 - Order your replacement filter for next year's use.

REPLACEMENT ACCESSORIES

To order the replacement accessories you can do any of the following:

- Fill out the accessories card found with the product
- Visit your local retailer
- Go to www.holmesproducts.com
- Call consumer service at 1-800-5-HOLMES

SERVICE INSTRUCTIONS

- DO NOT attempt to repair or adjust any electrical or mechanical functions on this unit. Doing so will void the Warranty.
- If you need to exchange the unit, please return it in its original carton, with a sales receipt, to the store where you purchased it. If you are returning the unit more than 30 days after the date of purchase, please see the enclosed Warranty.
- If you have any questions or comments regarding this unit's operation or believe any repair is necessary, please write to our Consumer Service Department or visit our website at www.holmesproducts.com.

THE HOLMES GROUP, INC.
CONSUMER SERVICE DEPARTMENT
13052 JIRJUM AVENUE
ROBTANA, CA 92337

For your own records, staple or attach your sales receipt to this manual. Also, please take a moment to write the store name, location and date purchased below.

STORE NAME: _____
 LOCATION: _____
 DATE PURCHASED: _____
 (STAPLE RECEIPT HERE)

Holmes®, the Holmes logo®, FiberCheck®, Cleanse Clean® and AccuSet Plus™ are trademarks of The Holmes Group, Inc.

WARRANTY INFORMATION

THREE (3) YEAR LIMITED WARRANTY

SAVE THIS WARRANTY INFORMATION

- A. This Warranty applies only to the original purchaser of this product.
- B. This Warranty applies ONLY to repair or replacement of any supplied or manufacturer parts of this product that, upon inspection by The Holmes Group, Inc. authorized personnel, is shown to have failed in normal use due to defects in material or workmanship. The Holmes Group will determine whether to repair or replace the unit. This Warranty does not apply to installation expenses.
- C. Operating this unit under conditions other than those recommended or at voltages other than the voltage indicated on the unit, or attempting to service or modify the unit, will render this WARRANTY VOID.
- D. Unless otherwise prescribed by law, The Holmes Group shall not be liable for any personal injury, property or any incidental or consequential damage of any kind resulting from malfunctions, defects, misuse, improper installation or alteration of this product.
- E. All parts of this product including fibers, which are covered under separate warranty, are guaranteed for a period of 3 years as follows:
- Within the first 28 days from date of purchase, the store from which you purchased your product should replace this product if it is defective in material or workmanship (provided the store has in-stock replacement.) If you intend to assert any claim in connection with this product, please follow the instructions in paragraph E.
 - Within the first thirty six months from date of purchase, The Holmes Group will repair or replace the product if it is defective in material or workmanship, subject to the conditions in paragraph G.
- F. If you have any other problem or claim in connection with this product, please write to our Consumer Service Department.
- G. IMPORTANT RETURN INSTRUCTIONS: Your Warranty depends on you following these instructions: If you are returning the unit to The Holmes Group, Inc.:
- Carefully pack the item in its original carton or other suitable box to avoid damage in shipping.
 - Before packing your unit for return, be sure to enclose:
 - Your name, full address with zip code and telephone number
 - A dated sales receipt or PROOF OF PURCHASE
 - Your \$7.00 check for return shipping and handling, and
 - The model number of the unit and the problem you are having. (Enclose in an envelope and tape directly to the unit before the box is sealed.)
 - The Holmes Group recommends you ship the package R.P.S. ground service for tracking purposes.
 - All shipping charges must be prepaid by you.
 - Mark the outside of your package:

THE HOLMES GROUP, INC.
13052 JIRJUM AVENUE
ROBTANA, CA 92337

SHIPPING AND HANDLING CHARGES: \$7.00 (USD)

This Warranty gives you specific legal rights, and you may have other rights, which vary from state to state. The provisions of this Warranty are in addition to, and not a replacement of, or substitution from, the statutory warranties and other rights and remedies available in any applicable legislation. To the extent that any provision of this Warranty is inconsistent with any applicable law, such provision shall be deemed voided or amended, as necessary, to comply with such law.

MODEL NUMBER

MODEL NUMBER / #13052HUM235

Printed in China

Holmes®

Owner's Guide

HM630
HM630RC

IF YOU BUY LINE X, if the cooling fan comes on, you have any problem or concern, please call 1-800-5-HOLMES and a Customer Service Representative will be happy to assist you.

FILTERS: HWF100 / HF235 (2)
 FILTER TYPE: WICK



Cool Mist Tower Humidifier

PLEASE READ AND SAVE THESE IMPORTANT INSTRUCTIONS

FEATURES - OPERATIONS

Thank you for purchasing this Holmes® product. We understand the value of quality and are committed to making superior products that stand the test of time. We trust this product will exceed your expectations of quality and reliability. We hope that you enjoy this product and will consider purchasing another Holmes® product in the future. To see our full product line, or if you have any questions or comments about this product, please visit our website at www.holmesproducts.com.

PLEASE READ AND SAVE THESE IMPORTANT SAFETY INSTRUCTIONS

- General Safety Information
- NOTE: This is an electrical appliance and requires attention when in use.
- NOTE: If registers freeze on the walls or windows of the room, turn off the humidifier. The room already has plenty of humidity and additional moisture may cause damage.
- NOTE: DO NOT block air inlet or outlet.
- Cord and Plug Installation Safety Instructions
- The length of cord used on this appliance was selected to reduce the hazards of becoming tangled in, or tripping over a longer cord. If a longer cord is necessary, an approved extension cord may be used. The electrical rating of the extension cord must be equal to or greater than the rating of the humidifier. Care must be taken to arrange the extension cord so that it will not drape over the power plug or fittings where it can be pulled on by children or accidentally tripped over.

HOW COOL MIST WORKS

Your Holmes® Cool Mist humidifier draws dry air through the top air intake grill area. This air is then passed through a moisture-fiber wick filter, which rotates the water and deposits in the water. The resulting mist air is directed back into the room from the top air grill.

NOTE: This humidification system provides a cool, invisible moisture output. It is normal not to see the mist.

NOTE: A humidity level below 20% can be unhealthy and uncomfortable. The recommended humidity level is between 40%-50%.

PRE-OPERATING INSTRUCTIONS

- Be sure the humidifier is switched to OFF and the unit is disconnected from the electrical outlet.
 - Select a location for your humidifier on a flat surface, about 4" away from the wall. DO NOT place the humidifier on a finished floor or near furniture, which can be damaged by moisture or water. Place on a moisture-resistant surface.
- FILLING THE WATER TANK
- Remove the tank from the housing of the humidifier by grasping the handle of the tank and pulling forward. Lift the tank out of the housing and bring to the faucet. Turn the tank upside down and hold off the tank cap by turning counter clockwise. Fill tank with cool, fresh tap water. DO NOT fill with warm water as this may cause leaking. Replace the cap on tank FIRMLY.
 - When full, carry the tank to the humidifier and place it into the housing. There is a floating tab located on the tank base for easy guidance. The tank holds 1.3 gallons of water. The tank will automatically begin to empty into the base.
 - Plug the power cord into a 120V AC electrical outlet.

OPERATING INSTRUCTIONS

Your humidifier is equipped with a technologically advanced AccuSet Plus™ digital thermostat. You can set the humidifier to run continuously in manual mode or set the AccuSet Plus™ digital thermostat to your desired humidity setting. The AccuSet Plus™ digital thermostat will automatically turn the humidifier ON or OFF depending on the present comfort level. The control level ranges between 25% and 65% relative humidity.



- Manual Mode Instructions:
- Plug the humidifier into a 120V AC electrical outlet.
 - The display will show the current room humidity.
 - To start the unit, push the MODE/OFF button once for the HIGH (3) manual setting.
 - Press the button again for the MEDIUM (2) manual setting and again for LOW (1). After this selection is made, the display will return to show the current room humidity.
 - To stop the unit, press and hold the button for five seconds, or keep pressing the button until the display reads OFF (0E).

AccuSet Plus™ HUMIDISTAT INSTRUCTIONS

To take advantage of the AccuSet Plus™ Digital Humidistat, press the MODE/OFF button until the speed is

FEATURES - OPERATIONS

- set in either the AUTO HIGH (A2), AUTO MEDIUM (A2) or AUTO LOW (A1) setting. Then adjust the set humidity by using the up and down buttons. Humidity will increase or decrease in increments of 5%. When the humidity level is set, the display will return to show the current room humidity. When the room humidity level rises above the set humidity, the humidifier will stop. When the humidity level drops below the set humidity, the humidifier will turn on automatically.
- NOTE: Allow up to 30 minutes for the fiber to fully absorb water and for the mist to produce moisture.
- NOTE: The AccuSet Plus™ Humidifier has memory. This means that when you turn the unit back on, it will be at the last setting the humidifier was set at.
- If you do not plan to use the humidifier for two or more days, make sure any residual water is drained from the water tank, base and wick filter to prevent algae or bacteria growth.
- Extended Run Time Settings:
- By setting your humidifier to a specific humidity level, you are actually also extending the run time. Since the unit will turn on and off to maintain the set humidity level, less water will be used, so you will need to fill the unit less often than you would in manual setting.
- USING THE PROGRAMMABLE TIMER
- AccuSet Plus™ allows the user to program the humidifier to auto-on at preset time, or turn off after a set amount of time.
- Setting the OFF Timer:
- Set the mode and/or humidity you wish the humidifier to run in.
 - While the humidifier is running, press and hold the up and down buttons simultaneously for 2 seconds. The display will flash "00".



REPLACING/CLEANING MAINTENANCE INSTRUCTIONS

- When the mode is in the CHANGE section, this means the proper amount of moisture is not getting into your air due to the excessive minerals and sediment that have become trapped on your fibers. At this point, you should replace your fiber. It is important to change your fiber as indicated to achieve stated performance level.
- To replace the fiber, follow the steps below:
- Turn the unit off and disconnect from the electrical outlet.
 - Remove the tank from the housing.
 - Block the housing from the base by turning the lock knob to the unlocked position.
 - Lift the housing straight up and place to the side.
 - Block the wick holder from the base by turning the lock knob to the unlocked position.
 - Remove the wick from the wick holder.
 - Follow the weekly cleaning instructions.
 - Insert new fibers into the wick holder and lock the wick holder back into the base.
 - Replace the housing onto the base and lock it into place.
 - Fill the tank and place back into housing.
 - Repeat Operating Instructions.
- It will take about 30 minutes for the humidifier to reach maximum output.
- You can purchase replacement fibers (model HWF100/HF235 - 2 fibers) at your local retailer by calling 1-800-5-HOLMES, filling out the necessary card, or by visiting www.holmesproducts.com. It is recommended that a replacement fiber is purchased for uninterrupted use.

CLEANING AND MAINTENANCE INSTRUCTIONS

Humidifiers provide comfort by adding moisture to dry, heated indoor air. To benefit most from the humidifier and avoid product misuse, follow all instructions carefully. Please note that this is an electrical appliance and requires attention when in use.

In addition, if you do not follow the recommended care and maintenance guidelines, micro-organisms may be able to grow in the water within the water tank. You must routinely follow the cleaning procedures that follow in order to ensure proper, efficient operation of your humidifier. Proper maintenance and cleaning is essential to the continued performance of your unit and the avoidance of algae or bacteria build-up.

- DAILY MAINTENANCE
- Be sure the unit is OFF and is disconnected from the electrical outlet.
 - Remove the housing and the tank from the humidifier and place in sink or tub.
 - Carry the base of the unit to the sink, remove the wick holder, place in sink, drain any remaining water and place thoroughly to remove any sediment or dirt. Wipe clean, and dry with a clean cloth or paper towel.
 - Drain the water from the tank into the sink and rinse tank thoroughly. Wipe down, and dry with a clean cloth or paper towel.
 - Put fibers back into wick holder making sure the rivet catches in the holder. Lock the wick holder back into place. Replace the housing and lock it into place. Refill the tank with cool tap water as indicated under the filling instructions. Do not overfill.
 - Follow Operating Instructions.
- Note: The Tray is descaler safe (TOP RACK ONLY) for easy cleaning.

- WEEKLY MAINTENANCE
- To Remove Scale:
- Repeat steps 1-4 above.
 - Clean the base by partially filling the base with one liter cup of undiluted white vinegar, or by using Cleanse Clean® (Model S1710) by the manufacturer. Leave this solution in the base for 20 minutes, while cleaning all the interior surfaces with a soft brush. Remove base scale by wiping the base with a cloth dampened with undiluted white vinegar.

- To Disinfect Humidifier Base and Tank:
- Fill humidifier tank 1/2 full with water and 1/2 tablespoon of chlorine bleach.
 - Let the solution stand for 20 minutes, switching every few minutes. Wipe all surfaces.
 - Carefully empty the tank after 20 minutes, and rinse with warm water until you can not detect any bleach smell. Dry with a clean cloth or paper towel.
 - Place fiber back into tank and refill the water tank as directed in Operating Instructions, and turn the unit on.