


Original & Replacement

EUREKA

BRAVO Soft Body
Model 9410A/AT Shown


KEY	PART NO.	DESCRIPTION
1	E-54384-1	Hood & Graphics*
2	E-27228-1	*Belt Window
3	E-14713-1	*Lens
4	E-38241-1	Knob
5	E-54377	Spring
6	E-54373-1	Attachment Cover**
	E-57627	Gasket**
7	E-27203-1	Switch Pedal
8	E-54379-44	Motor Ass'y 5.5 Amp
8	E-54379-43	Motor Ass'y 6.5 Amp
8	E-54379-42	Motor Ass'y 8.0 Amp
8	E-54379-42	Motor Ass'y 9.0 Amp
8	E-54379-45	Motor Ass'y 10.0 Amp
9	E-53238-13	Screw
10	E-38243-1	Motor Clamp
11	E-54325-1	Brushroll, 4 Row Spiral Nylon W/ Ball Bearings
11	E-54405-1	Brushroll, 2 Row Spiral Wood Dowel Only
	E-54359	Felt Washer
	E-54360	End Cap
12	E-57868-1	Snap-In Clip
13	E-54388	Headlight Ass'y
14	E-57568	Headlamp
15	E-38242	Rear Axle
16	E-38240-1	Slide
17	NLA	Base Ass'y
	E-57892-1	Gasket*
18	E-57762-1	Carriage Ass'y
19	E-57567-1	Axle
20	E-53238-10	Hood Screw
21	E-38441	Belt
21	E-54312	Belt 2 Pk
21	ER-1035	Belt
22	E-27202-1	Handle Release
23	E-53076-2	Spring
24	E-39260-288N	Rear Wheel
25	E-54376-1	Belt Cap Ass'y
26	E-38238-1	Front Wheel
	E-38063	Belt Guard (Not Shown)



EUREKA

BRAVO Soft Body
Model 9410A/AT Shown

Original & Replacement












KEY	PART NO.	DESCRIPTION
27	E-38301-4	Upper Handle Ass'y
28	E-27207-1	Handle Cap
29	E-27306-1	Hose Clip
30	E-53536-3	Snap Pin
31	E-53218-2	Screw
32	E-01928-1	Lower Handle
33	E-27195-1	Handle
34	E-53238-13	Screw
35	E-53213-5	Nut
36	E-27172-6	Cord Ass'y
36	ER-3025	Cord Ass'y 28'
37	E-01945-1	Tool Pak
38	E-54323-1	Hose Ass'y
39	E-14070-2	Straight Wand
39	FA-5005-3	Wand, Plastic Black
40	E-53455-4	Dusting Brush
40	FA-5300-3	Dusting Brush Black
41	E-54308-1	Crevice Tool
41	FA-5400-3	Crevice Tool Black
42	E-53454-6	Upholstery Nozzle
42	FA-5200-3	Upholstery Nozzle Black
43	E-54398-1	Bag Ass'y 9201
43	E-54398-2	Bag Ass'y 9202
43	E-54349-1	Bag Ass'y 9334
43	E-54349-2	Bag Ass'y 9410/9615*
	E-27194-1	Bag Cap
	E-57665	Bag Hanger
	E-38238	Bottom Insert
	E-38316-1	Lower Bag Support & Graphics
	E-54383	Push-On Nut

EUREKA

**BRAVO Hard Body
Model 9730A/AT Shown**

Original & Replacement

KEY	PART NO.	DESCRIPTION	KEY	PART NO.	DESCRIPTION	KEY	PART NO.	DESCRIPTION
1	E-54393-2	Hood & Graphics*	19	E-54376-1	Belt Cap Ass'y	38	E-53454-6	Upholstery Nozzle
	E-27339-1	*Nameplate	20	E-57762-1	Carriage Ass'y*	38	FA-5200-3	Upholstery Tool Black
2	E-27249-1	*Belt Window	21	E-57567-1	*Axle	39	E-57926-1	Latch & Graphics Ass'y
3	E-14731-1	*Lens	22	E-38238-1	*Front Wheel	40	E-57877	Latch Spring
4	E-38241-1	Knob	23	E-53238-10	Hood Screw	41	E-01973-1	Cover & Graphics
5	E-54377	Spring	24	E-54417-1	Carriage Clip	42	E-55927	Screw
6	E-54392-4	Attachment Cover**	25	E-53238-22	Screw	43	E-14902	Bag Support
	E-57627	**Gasket	26	E-01974-1	Upper Handle Ass'y**	44	E-54417-1	Carriage Clip
7	E-27251-2	Switch Pedal	27	E-27308-1	**Handle Grip	45	E-53238-22	Screw
8	E-54379-42	Motor 9.0 Amp Ass'y	28	E-36873-6	**Handle Cap	46	E-01969-1	Rear Housing
9	E-53238-13	Screw	29	E-37115-4	Cord Release Hook	47	E-57918-1	Bottom Housing & Graphics
10	E-38243-1	Motor Clamp	30	E-01984-1	Dirt Tube	48	E-54310	Disp. Bag Style U 3 Pk
11	E-54325-1	Disturbulator Ass'y	31	E-53238-26	Screw	48	ER-1421	Disp. Bag Style U 3 Pk
	E-54359	Felt Washer	32	E-27172-5	Cord Ass'y	48	E-57802	Disp. Bag Style U Filteraire 3 Pk
	E-54380	End Cap	33	E-01967-1	Tool Pak			
12	E-38441	Belt	34	E-54323-1	Hose Ass'y (not illustrated)			
12	E-54312	Belt 2 Pk	35	E-14070-2	Straight Wand			
12	ER-1035	Belt	35	FA-5005-3	Wand Plastic Black			
13	E-27202-1	Handle Release	36	E-53455-4	Dusting Btd)			
14	E-53076-2	Spring	36	FA-5300-3	Dust.Brct. ' ' ck			
15	E-38242	Rear Axle	37	E-54308-1	Crev			
16	E-38240-1	Slide	37	FA-5400-3	Crev ' ol			
17	E-27201-2	Rear Wheel			Crev			
18	E-54372-4	Base Ass'y*						
	E-57692-1	Gasket*						

		BRAVO MOTOR CHART				
		MODEL #	# AMP	MOTOR ASS'Y	*ARMATURE	**FIELD
	N/A	90012020	6.5	NLA	NLA	NLA
		90020021, 92020/D1		NLA	NLA	NLA
	ER-6220	90072021, 9202A/AT	8.0	NLA	NLA	NLA
		9301A/AT, 9201D/DT	8.0	NLA	NLA	NLA
		9202B/BT, 9202D/DT				
	E-54811 Fan Washer	9301A/AT, 9302A/AT				
		9205B/BT	6.5	NLA	NLA	NLA
	* E-27165 Fan Washer (12 AMP)	9301B/BT, 9302B/BT	8.0	NLA	NLA	NLA
		9334A/AT	6.5	NLA	NLA	NLA
	** E-54413 Fan Nut	9334B/BT, 9734A/AT	8.0	NLA	NLA	NLA
		9410A/AT, 9410A/ATX	8.0	NLA	NLA	NLA
	** E-38215-2	9615A/AT, 9615A/ATX				
		9620A/AT, 9620A/ATX				
	E-54152-3 E-54716 (12 AMP)	9410B/BT, 9615B/BT	9.0	NLA	NLA	NLA
		9615B/BTX, 9620B/BT				
	ER-7515	9730A/AT, 9740A/AT				
		9750A/ATV				
	E-27171 Fan Chamber Gasket	9730B/BT, 9740B/BT	9.5	NLA	NLA	NLA
		9750B/BT, 9750B/BTV				
		9824A/AT, 9845A/AT				
		9855A/AT, 9875A/AT				
		9731A/AT, 9741A/AT	12.0	NLA	NLA	NLA
		9751A/AT, 9875B/BT				
		9834A/AT	9.5	NLA	NLA	NLA
		9834B	12.0	E-54379-41	NLA	NLA