


This Owner's Manual is provided and hosted by [Appliance Factory Parts](#).



HOOVER F5855 Owner's Manual

[Shop genuine replacement parts for HOOVER F5855](#)



[Find Your HOOVER Vacuum Cleaner Parts - Select From 1456 Models](#)

----- Manual continues below part list -----


Available Replacement Parts for HOOVER F5855

HR-2400	Brush block Aftermarket
H-38784062	Gasket .
H-38777008	Recovery Tank without lid .
H-39383106	Lens.
H-38762010	FILTER, EXTRACTOR FOAM
H-440007360	Latch,RH steamvac recovery tank

HOOVER Original

UPRIGHT EXTRACTOR

Models F5851, F5855, F5859



Original **HOOVER**

UPRIGHT EXTRACTOR Models F5851, F5855, F5859

KEY	PART NO.	DESCRIPTION
1	H-42272111	Recovery Tank Lid Ass'y (Incl. Item 2)
2	H-38762010	Tank Filter
3	H-38661002	Duct
4	H-38777018	Recovery Tank (Incl. Item 1, 2, 3)
5	H-39383106	Lens
6	H-37257205	Door (Incl. Item 8, 9) - F5859
6	H-37257105	Door (Incl. Item 8, 9) - F5855
6	H-37257106	Door (Incl. Item 8, 9) - F5851
7	H-38351017	Spring - Access Door
8	H-38783021	Seal
9	H-21362006	Speed Nut
10	H-37271037	Hood Ass'y (Incl. 6, 7, 8, 9) - F5859
10	H-37271035	Hood Ass'y (Incl. 6, 7, 8, 9) - F5851, F5855
11	H-21447020	Screw - Self Tapping
12	H-38421093	Indicator Knob
13	H-43613009	Screen Ass'y
14	H-43582003	Pump Ass'y (Incl. Item 21)
15	H-21447217	Screw- Self Tapping (5)
16	H-43191001	Turbine and Gear Ass'y (Incl. Item 12, 20)
17	H-48437022	Brush Block Ass'y
18	H-21479438	Screw (2)
19	H-21447072	Screw - Self Tapping (2)
20	H-38333009	Spring
21	H-43523003	Quick Disconnect Ass'y
22	H-160017	Retaining Ring (2)
23	H-36131085	Trunnion Cover - RH
24	H-32434006	Rear Axle (2)
25	H-38522076	Rear Wheel (2)
26	H-38458042	Handle Release Lever
27	H-38784063	Standpipe Seal
28	H-43576163	Motor
29	H-33241001	Elbow Connector
30	H-37196141	Motor Cover
31	H-21447232	Screw - Self Tapping (4)
32	H-36151029	Tank Release Latch - LH
33	H-36151019	Tank Release Latch - RH
34	H-42272105	Solution Tank Ass'y Without Handle (Incl. Item 35, 36, 39, 40, 41, 42)
35	H-38784062	Gasket
36	H-42272002	Solution Tank Cap
37	H-39457016	Solution Tank Handle
38	H-38458031	Control Rod - Upper
39	H-38312014	Spring - Solution Tank
40	H-21312518	Washer - Brass
41	H-38784061	Valve Seal
42	H-38717009	Valve Stem - Solution Tank
43	H-38458033	Control Rod - Lower
44	H-38784060	Solution Tank Seal
45	H-43516008	Reservoir Ass'y (Incl Item 44)

KEY	PART NO.	DESCRIPTION
46	H-40309002	Tubing Ass'y (Incl. Item 29, 46, 47)
47	H-40309002	Tubing Ass'y (Incl. Item 29, 46, 47)
48	H-40201145	Handle Hardware
49	H-34113004	Motor Seal
50	H-1105586	Screw - Self Tapping
51	H-12227	Insulated Terminal
52	H-46583012	Attachment Cord - 33'
53	H-38781048	Motor Base Seal
54	H-36131086	Trunion Cover - LH
55	H-38434025	Switch Actuator Lever
56	H-28218048	Push ON/OFF Switch
57	H-36172016	Cord Retainer
58	H-37272088	Main Body
59	H-37276001	Handle Cover
60	H-39466033	Lower Handle
61	H-100192	Upper Handle Ass'y (Incl. Item 38, 63)
62	H-52313017	Nameplate - Upper Handle
63	H-39442041	Cord Wrap
64	H-38655002	Tool Converter
65	H-38671035	Hose w/Collars
66	NLA	Wand Valve Ass'y
67	H-57333016	Carpet Cleaning Solution - 16 oz.
68	H-38619011	Upholstery Nozzle
69	H-36172033	Tube Strap (6)
70	H-43513007	Connector/Coupler Sleeve Ass'y
71	NLA	Solution Tubing Ass'y (Inc. item 70)
72	H-48448001	Spot Brush Ass'y
73	H-38619018	Corner Tool
74	H-38619019	Edge Tool
75	H-39514001	Nozzle Cleanout Tool
76	H-39458005	Handle Lever Guard

OPTIONAL CHEMICALS

H-40301064	Carpet Cleaning Solution 64 oz.
H-40302016	Pre-Spotter Solution w/sprayer 16 oz.
H-40303032	Bare Floor Solution - 32 oz.

Items Not Illustrated

H-48417002	Bare Floor Cleaner Tool Ass'y
H-36433092	Hose Caddy - F5855, F5859
H-40201142	Hose Caddy Hardware - F5855, F5859
H-43412003	Sprayer - F5855, F5859
NLA	Cleaning Tool Hose Ass'y (Order H-40309044) (Inc. Items 64, 65, 66 & 68)
H-40309044	Hose Kit Including New Style Hose, Recovery Tank And Lid With Upholstery Tool

NLA = No Longer Available