


This Owner's Manual is provided and hosted by [Appliance Factory Parts](http://www.appliancefactoryparts.com).



HOOVER F6215-910 Owner's Manual

[Shop genuine replacement parts for HOOVER
F6215-910](#)



[Find Your HOOVER Vacuum Cleaner Parts - Select From 1456 Models](#)

----- Manual continues below part list -----

Available Replacement Parts for HOOVER F6215-910


[H-38613040](#)

NOZZLE BODY, WITH RELEASE TAB

HOOVER Original

AGILITY STEAM VAC

Models F6205-900, F6210-900, F6212-900, F6215-900, F6215-910



Original **HOOVER**

AGILITY STEAM VAC

Models F6205-900, F6210-900, F6212-900, F6215-900

<u>KEY</u>	<u>PART NO.</u>	<u>DESCRIPTION</u>
1	H-90001064	Handle Release Lever
2	H-90001107	Rear Wheel Axle RH
3	H-21447003	Screw
4	H-90001067	Trunnion Cover RH
5	H-90001068	Valve Door- Standpipe
6	H-36172016	Cord Retainer
7	H-90001063	Switch Actuation Pedal
8	H-90001106	Switch
9	H-90001066	Trunnion Cover LH
10	H-90001108	Rear Wheel Axle LH
11	H-90001065	Rear Wheel
12	H-90001104	Recovery Duct
13	H-90001058	Nozzle Back Plate Seal
14	H-21447242	Screw
15	H-90001103	O Ring
16	H-160017	Retaining Ring
17	H-34113004	Motor Seal
18	H-38781048	Motor Base Seal
19	H-43613018	Filter Screen
20	H-90001036	Main Body Assembly
21	H-90001102	Switch
22	H-90001062	Switch Bracket
23	H-90001105	Pump Assembly
24	H-21447236	Screw
25	H-21479438	Screw
26	H-48437029	Brush Block Assembly
27	H-90001061	Motor Cover
28	H-90001111	Seal - Motor Cover
29	H-43576197	Motor

<u>KEY</u>	<u>PART NO.</u>	<u>DESCRIPTION</u>
30	H-21447232	Screw
31	H-21447246	Screw
32	H-91001002	Turbine And Gear Assembly
33	H-38331006	Actuator Arm Spring
34	H-90001060	Turbine Actuator Arm
35	H-38421114	Indicator Knob
36	H-90001059	Recovery Duct Seal
37	H-90001085	Hood - AHF - F6215-900, F6215-910
37	H-90001086	Hood -AHD- F6205-900
37	H-90001035	Hood - AHC -F6210-900, F6212-900
38	H-90001057	Nozzle Back Plate Assembly (Includes Item 13)
39	H-90001056	Nozzle Front Plate
	H-90001109	Attachment Cord (Not Shown)
41	H-91001007	Bare Floor Cleaning Tool


Items not illustrated:

H-27479307 Cable Tie

HOOVER Original

AGILITY STEAM VAC

Models F6205-900, F6210-900, F6212-900, F6215-900, F6215-910



KEY	PART NO.	DESCRIPTION	KEY	PART NO.	DESCRIPTION
1	H-21447043	Screw	26	H-37274078	Lid Cover Assembly - AHJ - F6215-900, F6215-910
2	H-90001046	Solution Actuator For Surge	26	H-90001044	Lid Cover Assembly - AHR - F6210-900, F6212-900
3	H-90001047	Solution Actuator For Normal	26	H-90001094	Lid Cover Assembly - AHK - F6205-900
4	H-90001048	Spring	27	H-90001091	Solution Tank Assembly - AHJ - F6215-900, F6215-910
5	N/A	Control Rod Upper (Order Key 6)	27	H-90001092	Solution Tank Assembly - AHK - F6205-900
6	H-90001045	Upper Handle Complete (Includes Items 1, 2, 3, 4, & 5) F6212-900, F6215-900, F6215-960	27	H-90001043	Solution Tank Assembly - AHR - F6210-900, F6212-900
6	H-90001097	Upper Handle Complete (Includes Items 1, 3, 4, & 5) F6205-900, F6210-900	28	N/A	Label
7	H-90001089	Lid Cover Assembly - AHJ - F6215-900, F6215-910	29	H-90001074	Quick Disconnect
7	H-37274083	Lid Cover Assembly - AHR - F6210-900, F6212-900	30	H-90001110	Solution Duct
7	H-90001044	Lid Cover Assembly - AHK - F6205-900 (Includes Items 7, 9, 10, 11, and 12)	31	H-90001103	O Ring
8	H-90001087	Recovery Tank Assembly - AHJ - F6215-900, F6215-910 (Includes Items 7, 9, 10, 11, and 12)	32	H-90001076	Tubing
8	H-90001088	Recovery Tank Assembly - AHK - F6205-900 (Includes Items 7, 9, 10, 11, and 12)	33	H-90001073	Reservoir
8	H-90001038	Recovery Tank Assembly - AHR - F6210-900, F6212-900 (Includes Items 7, 9, 10, 11, and 12)	34	H-90001075	Tubing
9	H-90001040	Separator Channel	35	H-90001080	Hose Complete
10	H-90001041	Float	36	H-25411015	Hose Clamp
11	H-90001042	Float Guide	37	H-90001079	Air Hose Complete
12	H-21447231	Screw	38	H-90001069	Lower Handle Cover
13	H-39442048	Cord Wrap	39	H-90001077	Air Return Elbow
14	N/A	Label	40	H-90001052	Lower Handle Assembly Left Half - MV (Includes Items 18, 41, 42, And 46)
15	H-91001004	Cleaning Tool Hose - F6212-900, F6215-900, F6215-910	41	H-90001053	Control Rod - Lower
15	H-91001008	Cleaning Tool Hose - F6205-900, F6210-900	42	H-90001048	Spring
16	H-90001055	Tool Caddy	43	H-90001049	Lower Handle Assembly Right Half - MV (Includes Items 18, 44, And 45)
17	H-38613040	Nozzle Body Tool	44	H-90001050	Seal
18	H-90001037	Spring	45	H-90001051	Recovery Tank Release Latch
19	H-90001070	Latch - Upper Handle	46	H-90001054	Solution Tank Release Latch
20	H-90001072	Spacer	47	H-38433074	Trigger - AG
21	H-51661020	Medallion	48	H-37276006	Wand Cover
22	H-90001071	Door-Tool Port	49	H-21447239	Screw
23	H-90001078	Seal - Tool	50	H-90001006	Wand / Valve Assembly - F6210-900, F6212-900, F6215-900, F6215-910
24	H-91001003	Turbine Nozzle	50	H-90001009	Wand / Valve Assembly - F6205-900
24	H-48434006	Brush Assembly (2 Required) (Not Shown)	51	H-38312019	Spring And "O" Ring
25	H-21447003	Screw	52	N/A	O-Ring (Included With Item 51)
			53	H-43412007	Nozzle/Valve Assembly

NA = Not Available