


This Owner's Manual is provided and hosted by Appliance Factory Parts.



HOOVER S1015-031 Owner's Manual

[Shop genuine replacement parts for HOOVER
S1015-031](#)



[Find Your HOOVER Vacuum Cleaner Parts - Select From 1456 Models](#)

----- Manual continues below part list -----

Available Replacement Parts for HOOVER S1015-031

[H-43662023](#)

BAG CLOTH PORTAPOWER

Original **HOOVER**

SWINGETTE & PORTAPOWER

Models 404, 409, S1015, S1015-030, S1015-031, S1015-032, S1015-033, S1029

KEY	PART NO.	DESCRIPTION
1	H-162229 AG	Bag Door Ass'y
	H-162229 JX	Bag Door Ass'y - S1029
2	H-43662023	Bag Ass'y Comp.
3	H-162064 LL +	Housing Ass'y - R.H. - 404
	H-166982 DM +	Housing Ass'y - R.H. - 409
	H-42222028	Housing Ass'y - R.H. - JM
	H-42222030 +	Housing Ass'y - R.H. - S1029
4	H-162062 AY	Hinge Pin (2)
5	H-162483 +	Nameplate - 404
6	H-34366001	Diffuser
7	H-162059 JM	Diffuser Door - 404
	H-162059 DR	Diffuser Door - 409
	H-162059 DS	Diffuser Door
	H-162059 JX	Diffuser Door - S1029
8	H-48969 *	Solderless Connector (2)
9	H-14648 JM	Cord Protector
10	H-162066 +	Housing Muffler (2)
11	H-12062 +	Lead Wire Ass'y - Black
12	H-162075 +	Lead Wire Ass'y - Yellow
13	H-162074	Lead Wire Ass'y - White
14	H-12031	Motor Brush Ass'y (2)
15	H-12971	Switch
16	H-12029	Motor Brush Holder (2)
17	H-162083 HE	Secondary Filter
18	H-163434	Pressure Pad (3)
19	H-12022	Field Lamination Bolt (2)
20	H-21312701 *	Washer (2)
21	H-21447028 *	Screw - Self Tapping (2)
22	H-12033	Motor Brush Retainer (2)
23	H-12059	Motor Brush Housing Ass'y
24	H-12854	Compression Spring (2)
25	H-12007 *	Pin (3)
26	H-21651037 *	Nut - Special (2)
27	H-46363271	Attach. Cord Ass'y
28	H-21312700	Washer (3)
29	H-43566003	Fan Ass'y (2)
30	H-12000	Fan Nut
31		Not Applicable
32	H-12038	Motor End Cap Ass'y

KEY	PART NO.	DESCRIPTION
33	H-12089	Motor Mount - R.H.
34	H-18656	Interstage Housing
35	H-170055	Fan Spacer
36	H-12003	Fan Spacer
37	H-167673	Armature Ass'y Comp.
38	H-12050	Motor Casing
39	H-167677	Field Ass'y Comp.
40	H-12013	Spacer
41	H-43566005	Fan
42	H-12028	Nut
43	H-163426	Outerstage Housing Ass'y
44	H-163546	Retaining Ring
45	H-161957	Motor Seal Mount
46	H-162065 LL +	Housing Ass'y - L.H. - 404
	H-162065 DM	Housing Ass'y - L.H. - 409
	H-37223057	Housing Ass'y - L.H.
47	H-21447043 *	Screw - Self Tapping (2)
48	H-21479573	Screw - Self Tapping (4)
49	H-162060 AW	Tool Holder

ITEMS NOT ILLUSTRATED

H-27482227	Strain Relief Bushing (Used on Item 27, Model 404)
H-160356	Terminal (Used on Item 13)
H-161350	Terminal (Used on Item 13)
H-160532	Terminal (Used on Item 11 & 12)

PACKAGING MATERIAL

H-58152062	Carton - Portapower w/o Dolly
H-58172001	Carton - S1029
H-56512065 +	Owner Manual - S1015-030, 031, 032, 033, S1029

WHEELED DOLLY

H-160017 *	Retaining Ring
H-169242	Wheel Cover
H-43247006	Wheel (Includes Tire)
H-43248010	Dolly Comp.