


This Owner's Manual is provided and hosted by [Appliance Factory Parts](#).



# HOOVER S1223 Owner's Manual

[Shop genuine replacement parts for HOOVER S1223](#)




[Find Your HOOVER Vacuum Cleaner Parts - Select From 1456 Models](#)

----- Manual continues below part list -----

## Available Replacement Parts for HOOVER S1223

<a href="#">H-4010063R</a>	PAPER BAG R OEM HOOVER 5 PACK
<a href="#">H-43414064</a>	DUSTING BRUSH (ONE PEICE)



**Sprint/Hornet  
PortaPower I**

**Models S1211, S1215, S1221, S1223  
S1410**

Ref. No.	Part No.	Description
1	42227175	Bag Door Assem. - JM
	42227178	Bag Door Assem. - AAP - S1215, S1223
	42227179	+ Bag Door Assem. - AG - S1221, S1410
2	38426088	Latch Button - JM
	38426090	+ Latch Button - AG
3	36151025	Latch - BZ
4	21447122	+* Screw - Self Tapping (8)
5	4010063R	Disposable Bag (5 Pk.)
6	38522073	Wheel - AG
7	28181063	Switch
8	27666553	Terminal - S1410
	27666513	Terminal (Black Switch)
	27666527	+ Terminal (Gray Switch)
9	42222173	Housing Assem. - RHLH - JM
	42222172	Hsg Assem. - RH/LH - AAU - S1223
	42222177	Hsg Assem. - RH/LH - MW - S1215
	42212129	Hsg Assem. - RH/LH - ABZ - S1221
	42222179	Hsg Assem. - RH/LH - AG - S1410
10	36218020	Cord Protector - AAP
	36218021	Cord Protector AG
11	46363043	Attach. Cord Assem. - AAP
	46363307	Attach Cord Assem. - AG
12	27479307	+ Lead Wire Tie
13	12227	Insulated Terminal
	27618508	Wire Connector - S1410
14	43177061	+ Motor Assem. Comp. (P-205)
	43578068	Motor Assem. Comp. - S1215, S1223 - (P-205)
15	163434	+ Pressure Pad (3)
16	42222173	Housing Assem. - RHLH - JM
	42222172	Hsg Assem. - RH/LH - AAU - S1223
	42222177	Hsg Assem. - RH/LH - MW - S1215
	42212129	Hsg Assem. -RH/LH -ABZ - S1221
	42222179	Hsg Assem. - RH/LH - AG - S1410
17	43615054	Bulkhead Assem.
18	38521036	Wheel - AG

Ref. No.	Part No.	Description
	56512174	Owner Manual - S1221, S1410
	56512139	Owner Manual
	58142123	+ Carton
	58142127	+ Carton - S1221
	58142130	+ Carton - S1410
	58341007	+ Cleaner Support

**Cleaning Tools - S1211, S1215**

38617017	Crevice Tool - AG
43414016	Furniture Brush - AG
0M114169	Rug & Floor Nozzle - AAP
3863801P	Extension Tube - Poly - AG
43434157	Hose Assem. Comp. - AAZ/AAP

**Cleaning Tools - S1223**

38617017	Crevice Tool - AG
38614024	Furniture Nozzle - AAP
43414064	Dusting Brush - AG
0M114169	Rug & Floor Nozzle - AAP
3863801P	Extension Tube - Poly - AG
43434243	Hose Assem. Comp. - w/SC

**Cleaning Tools - S1221**


38617017	Crevice Tool - AG
43414016	Multi Purpose Brush - AG
3863801P	Extension Tube Assem. - AG
0M114169	Rug and Floor Nozzle - ABE
43434157	Hose Assem. Comp. - W/SC- ABX/AG - 8'

**Cleaning Tools - S1410**

38617017	Crevice Tool - AG
3863801P	Extension Tube - AG
43414016	Multi Purpose Brush - AG
43414172	Rug & Floor Nozzle
43434157	Hose Assem. Comp.

# Motor

S1211, S1215, S1221, S1223, S1410





43578068 Motor Assem. Comp. - S1215, S1223  
 43177061 Motor Assem. Comp. - S1211, S1221, S1410

Ref. No.	Part No.	Description
1	33426001	Nut - EF
2	21312701	* Washer (4)
3	31178007	Motor Gasket (2)
4	21434224	+* Screw - Self Tapping (4)
5	37191016	Outer stage Housing - AY
6	43568017	Fan Assem. (2)
7	43551005	Interstage Assem.
8	31742010	Fan Spacer
9	46176001	Lead Wire Assem. - Black
10	33421004	+ Field Lamination Bolt - FW (2)
11	169702BZ	* Bushing (2)
12	42937003	Motor Housing Assem. - Upper
13	38353004	Spring (2)
14	167681	Brush & Terminal Assem. (2)
15	N/A	Brush Holder (2) Use Brush Carrier Assem. 47318-008 (Incl. It. 13 - 16)
16	167696AG	Brush Carrier (2)

Ref. No.	Part No.	Description
17	21429406	* Screw - Self Tapping - EF (2)
18	45311051	Field Assem. Comp. - S1215, S1223
	45311061	+ Field Assem. Comp. - S1211, S1221 S1410
19	167721FW	Spring compression (2) - S1215, S1223
	38311023	+ Spring Compression (2) - S1211, S1221, S1410
20	44765171	Armature Assem. Comp. - S1215, S1223
	44765217	Armature Assem. Comp. - S1211, S1221, S1410
21	37191085	Motor Housing Assem. - Lower
22	31148002	Spacer
23	36322002	Interstage Mounting Plate - FW
24	167695EF	Nut - Special (2)

# Rug & Floor Nozzle



Ref. No.	Part No.	Description
1	43414121	+ Standard Rug & Floor Nozzle Assem. - AAP
	43414139	+ Standard Rug & Floor Nozzle Assem. - AAP
	43414140	Standard Rug & Floor Nozzle Assem. - ABE (S3393-020, S3521)
	0M114169	Standard Rug & Floor Nozzle - ABX - S1221, S1315, S1337, S3393-040
	43414170	+ Standard Rug & Floor Nozzle AG - S1339, S3547
	43414172	Standard Rug & Floor Nozzle - AG
2	38646039	Nozzle Tube - AG
3	38615153	+ Rug & Floor Nozzle - AAP
	38615182	Rug & Floor Nozzle - ABE S3393-020, S3521, S1339, S3547, S1221, S1315, S1337
4	38521018	Roller (2) (Nozzle 43414172 req's 4)
5	31511004	Roller Axle - AY (2) (Nozzle 43414172 req's 4)
6	36414018	Brush Housing S1221, S1315, S1337
7	166649FW	Spring (2)
8	48443003	Brush Back Assem. - AG
9	21447203	Screw - Self Tapping (2)
10	38454004	Brush Back Lever - MV
	38454006	+ Brush Back Lever - ABN S3393-020, S3521, S1221 S1339, S3547
11	21329105	+ Felt Washer

Ref. No.	Part No.	Description
1	43414101	+ Deluxe Rug & Floor Nozzle Assem. - AAP
2	38646045	Nozzle Connector - AAP
3	43244043	Wheel & Bearing Assem. (2)
4	38511016	Wheel Bearing - AAT (2)
5	38615180	Rug & Floor Nozzle - AAP
6	38521018	Roller (2)
7	31511004	Roller Axle - AY (2)
8	38451008	Slider - AG
9	36414013	+ Brush Housing - MV
10	166649FW	Spring (2)
11	48443004	Brush Back Assem. - AG
12	21447203	Screw - Self Tapping (3)
13	34122013	+ Seal (2)
14	38434015	Pedal - MV