


This Owner's Manual is provided and hosted by [Appliance Factory Parts](#).



HOOVER S3001 Owner's Manual

[Shop genuine replacement parts for HOOVER S3001](#)




[Find Your HOOVER Vacuum Cleaner Parts - Select From 1456 Models](#)

----- Manual continues below part list -----

Available Replacement Parts for HOOVER S3001

H-4010009H	PAPER BAG, 3 PK
H-43414064	DUSTING BRUSH (ONE PEICE)



Celebrity

Ref. No.	Part No.	Description
1	170367JM	Cord Reel Housing - S3001
	37215065	Cord Reel Housing - JM - S3001 -001
	170334AG	Gasket
3	19765	Screw
4	46831015	Cord Reel Comp.
5	46383303	Cord - S3001
	46363146	Attach. Cord - S3001 -001
6	170368JM	Plug Insert
7	47348007	Brush Block Comp.
8	34165002	Brush Block Insulator (2)
9	47938	Pin
10	27482227	Strain Relief (2)
11	43123AV	Ring
12	12619	Screw (4)
13	170332BZ	Secondary Filter
14	161881	Terminal Lock (2)
15	17001FW	Screw (4)
16	37196030	Motor Cover - JM
17	48969	Wire Nut (2)
18	21652003	Hex Nut (3)
19	21447014	Screw (2)
20	170331JJ	Tubing (Cover)
21	170359JJ	Rear Rest Pad
	170359FP	Rear Rest Pad
22	160108PH	Wheel (2)
23	161448AG	Tire Tread (2)
24	160017	Lock Ring (2)
25	169242	Wheel Cover (2)
26	43177001	Motor Comp.
27	169294	Motor Mount - Lower
28	170374JM	Blower Valve
29	170339	Spring
30	41421129	Bottom Pan Comp. - S3001
	41421026	Bottom Pan Comp. - ET - S3001 -001
31	23737202	Caster Wheel Assm.
32	31721004	Spacer (3)
33	31194005	Muffler
34	169293	Motor Mount - Upper
35	42213033	Intermediate Shell Comp. - S3001
	42213034	Intermediate Shell Comp. - ET - S3001 -001
36	170358AG	Bag Connector Collar
37	39457006	Handle - S3001 -001
38	170328	Tube - Bag Collar
39	48512FW	Latch Link Spring
40	16439JJ	Shell Cover Latch
	16439JX	Shell Cover Latch
41	166735EF	Screw (2)

Models S3001, S3001-001


Ref. No.	Part No.	Description
42	4010009H	Throw Away Bag - (3 Pk.)
43	37911001	Vacuum Control Panel - S3001
	37911003	Vacuum Control Panel - S3001-001
44	21479229	Screw (Control Panel) (5)
45	21447003	Screw
46	170361JM	Furniture Guard - S3001 -001
47	42211033	Upper Shell - S3001
	42211015	Upper Shell - JW - S3001-001
48	170337	Spring
49	32172002	Bag Indicator Seal
50	51151002	Full Bag Indicator Comp.
51	170344HE	Cam (2)
52	170345DN	Vacuum Control Button (Min.) - S3001
	170345AG	Vacuum Control Button (Min.) - S3001 -001
53	38422001	Vacuum Control Button (Med.) - S3001
	38422002	Vacuum Control Button (Med.) - S3001 -001
54	38422006	Vacuum Control Button (Max.) - S3001
	38422007	Vacuum Control Button (Max.) - S3001 -001
55	47538006	Switch Assm. Comp.
56	162961	Insulating Pod (Pigtail) (2)
57	163055	Terminal (Pigtail) (2)
58	38421017	Switch Button
59	170370DL	Control Panel Cover
	170370JM	Control Panel Cover
60	51481005	Control Panel
61	46312001	Pigtail Cord
62	46831076	Commutator
63	19999	Ratchet
64	38331004	Detent Spring
65	170343AY	Cord Reel Bracket
66	51661008	Medallion

PACKAGING MATERIAL

58185091	Carton
58286001	Top Support
58343002	Bottom Support
56513004	Owner Manual

ITEMS NOT ILLUSTRATED

170351AW	Hinge Leaf Upper (Upper Shell)
----------	--------------------------------



Celebrity

Models S3005, S3005-001, S3005-020, S3005-030, S3159, S3167

Ref. No.	Part No.	Description
1	47938	Pin
2	170362JM	Cord Clip
3	48123	Ring
4	42211161	Upper Shell - EW
	42211059	Upper Shell - EW - S3159
	42211048	Upper Shell - JX - S3167
5	170361JM	Furniture Guard
6	17001FW	Screw (3)
7	170377JM	Motor Cover
8	21652003	Nut - Hex (3)
9	161881	Terminal Lock (2)
10	13312	Switch Retaining Clamp (Metal)
	36131003	Switch Cover - R.H. (Plastic)
11	170333	Lead Wire - White
12	12971	Switch
13	13313	Switch Retaining Clamp (Metal)
	36131002	Switch Cover - L.H. (Plastic)
14	34353001	Switch Insulation
15	48969	Wire Nut (2)
16	46363195	Cord
17	42213038	Intermediate Shell - JJ
	42213040	Intermediate Shell - JR
18	27482227	Strain Relief Bushing
	27482120	Strain Relief Bushing - S3005-001
19	169293	Motor Mount - Upper
20	31194005	Muffler

Ref. No.	Part No.	Description
21	43177008	Motor - (P - 39)
22	169294	Motor Mount - Lower
23	37215097	Intake Pan
24	170382JM	Blower Adapter
25	41421189	Bottom Pan - JR - S3159
	41421122	Bottom Pan - JJ
26	166735EF	Screw (2)
27	39457006	Handle
28	170352AG	Bag Collar Connector
29	16439JX	Shell Cover Latch
30	4010009H	Throw Away Bag (3 Pk.)
31	170332BZ	Secondary Filter
32	13533	Screw (Cord Clip)
33	51661008	Medallion

PACKAGING MATERIAL

58177087	Carton
58259001	Top Support
58271001	Bottom Support
56513006	Owner Manual
56513109	Owner Manual - S3159

ITEMS NOT ILLUSTRATED

170351AW	Hinge Leaf Upper (Upper Shell)
----------	--------------------------------

Ref. No.	Part No.	Description
1	43414101	Rug & Floor Nozzle Comp.
2	34113001	Seal Foam
3	169241AW	Washer (2)
4	169239AG	Wheel (2)
5	13730	Lock Ring (2)
6	169242	Wheel Cover (2)
7	38615101	Nozzle - S3001
	38615086	Nozzle - JM - S3001 -001, S3015, S3015-001
8	34112001	Seal - Foam
9	34223002	Seal - Felt
10	169250AG	Brush Housing
11	169253AY	Rib Shoe (2)
12	169256	Brush Back Comp.
13	169247JM	Furniture Guard/Litter Picker
14	169251	Gasket
15	169538	Bottom Plate Comp.
16	21481464	Screw (2)
17	21481465	Screw (2)
18	169243AG	Roller
19	21312758	Washer
20	24735081	Lock Ring
21	169244AW	Roller Shaft
22	166649FW	Spring (2)
23	34513001	Seal Foam - L.H.
24	34513002	Seal Foam - R.H.
25	169240AY	Wheel Shaft (2)
26	169249JM	Connector Tube
27	34122006	Seal
28	169254JM	Suction Control Knob
	43271039	Suction Control Knob - JM
29	43434010	Hose Comp. - JM - S3001, S3001-001 (Shown above)
	43438035	Hose - S3015, S3015-001 (Not Shown)
30	43466002	Tube End Comp. - S3001, S3001-001
31	170355AJ	Thumb Button - S3001, S3001-001
32	170340	Spring - S3001, S3001-001
33	170350	Piston - S3001, S3001-001
34	170327	Tubing - S3001, S3001 -001
35	38655006	Hose Connector Tube End
36	170354BZ	Hose Connector Collar (2) - S3001, S3001 -001
37	32156010	Hose Sleeve (2) - S3001, S3001-001
38	12126	Gasket - Felt (2) - S3001, S3001-001
39	43431002	Hose Less Ends - S3001, S3001-001
40	170329	Tube - S3001, S3001-001
41	170325DM	Tube Seal - S3001, S3001 -001
42	34221001	Static Conductor - S3001, S3001 -001
43	38683003	Hose Connector - S3001, S3001 -001
44	43414057	Furniture Nozzle Assm. - S3001, S3001 -001
45	38617017	Crevice Tool
46	43458001	Extension Wand
47	113263BZ	Brush (Use w/161851JM)
48	161851JM	Dusting Brush Comp.
	43414064	Dusting Brush (One Piece)
ITEMS NOT ILLUSTRATED		Conducting Strip
	51611002	

