

**Celebrity**

**Models S3005, S3005-001, S3005-020, S3005-030, S3159, S3167**

Ref. No.	Part No.	Description
1	47938	Pin
2	170362JM	Cord Clip
3	48123	Ring
4	42211161	Upper Shell - EW
	42211059	Upper Shell - EW - S3159
	42211048	Upper Shell - JX - S3167
5	170361JM	Furniture Guard
6	17001FW	Screw (3)
7	170377JM	Motor Cover
8	21652003	Nut - Hex (3)
9	161881	Terminal Lock (2)
10	13312	Switch Retaining Clamp (Metal)
	36131003	Switch Cover - R.H. (Plastic)
11	170333	Lead Wire - White
12	12971	Switch
13	13313	Switch Retaining Clamp (Metal)
	36131002	Switch Cover - L.H. (Plastic)
14	34353001	Switch Insulation
15	48969	Wire Nut (2)
16	46363195	Cord
17	42213038	Intermediate Shell - JJ
	42213040	Intermediate Shell - JR
18	27482227	Strain Relief Bushing
	27482120	Strain Relief Bushing - S3005-001
19	169293	Motor Mount - Upper
20	31194005	Muffler

Ref. No.	Part No.	Description
21	43177008	Motor - (P - 39)
22	169294	Motor Mount - Lower
23	37215097	Intake Pan
24	170382JM	Blower Adapter
25	41421189	Bottom Pan - JR - S3159
	41421122	Bottom Pan - JJ
26	166735EF	Screw (2)
27	39457006	Handle
28	170352AG	Bag Collar Connector
29	16439JX	Shell Cover Latch
30	4010009H	Throw Away Bag (3 Pk.)
31	170332BZ	Secondary Filter
32	13533	Screw (Cord Clip)
33	51661008	Medallion


**PACKAGING MATERIAL**

58177087	Carton
58259001	Top Support
58271001	Bottom Support
56513006	Owner Manual
56613109	Owner Manual - S3159

**ITEMS NOT ILLUSTRATED**

170351AW	Hinge Leaf Upper (Upper Shell)
----------	--------------------------------


S3073, S3073-030, S3079, S3079-030, S3079-035, S3081,  
 S3083, S3083-030, S3093, S3121, S3123, S3125, S3125-030,  
 S3127, S3131, S3131-030, S3133, S3135, S3147, S3149, S3159  
 S3161, S3165, S3167, S3169, S3215



Ref. No.	Part No.	Description
1	33421004	Field Lamination Bolt
2	21429406	Screw
3	167696AG	Brush Housing - Only
4	N/A	Brush Holder - Use Brush Carrier Assem. 47318008 It. 6.
5	167681	Carbon Brush & Terminal
6	47318008	Brush Housing - Comp.
7	27666551	Terminal
8	38353004	Spring
9	169707	Motor Housing - Upper
10	168479	Armature
11	168470	Field
12	167721FW	Spring
13	169702BZ	Bushing
14	169713FW	Motor Mounting Plate
15	167695EF	Nut
16	21312774	Washer
17	43566006	Fan
18	34785004	Spring Clip
19	169714AG	Diffuser
20	33426001	Nut
21	31148002	Spacer
22	41823002	Motor Housing - Lower

# Cleaning Tools

Models S3005, S3005-001, S3005-020, S3005-030,  
S3021, S3023, S3033-030, S3159, S3167



Ref. No.	Part No.	Description	Ref. No.	Part No.	Description
1	0M114169	Rug & Floor Nozzle Comp.	19	43434213	Hose Complete - S3005, S3005-001, S3005-020, S3005-030, S3159, S3167
2	166653DM	Nozzle Tube - S3005, S3005-020	20	12615BZ	Hose Connector Collar - S3005, S3005-001, S3005-020, S3005-030, S3159, S3167
	166652JM	Nozzle Tube (See Note)	21	32855003	Hose Connector - S3005, S3005-001, S3005-020, S3005-030, S3159, S3167
3	166651	Felt Gasket	22	43434191	Hose Assem. Comp. - S3005, S3005-001, S3005-020, S3159, S3167
4	43414089	Nozzle & Lock Assm.	23	43453027	Extension Tube - S3005-030
5	166649FW	Spring (2)	24	43466044	Hose Connector Curved w/Rings - S3005-030
6	166656	Brush Back	25	36116006	Hose Connector Collar - S3005-030
7	166646	Brush Retainer Clip (2)	26	36153009	Latch Ring - S3005-030
8	166650AY	Connector Tube Clamp	27	51869006	Hose Connector Label - S3005-030
	166648AW	Screw (2)	28	38711006	Suction Control Ring - S3005-030
10	161852JM	Furniture Brush Comp.	29	43434191	Hose Assem. Comp. - S3005-030
	43414016	Furniture Brush - AG			
11	13149JM	Nozzle Connector Tube (Use w/ 161852JM)			
12	43414016	Furniture Brush - AG			
13	13254BZ	Brush Back Comp. (Use w/ 161852JM)			
14	43458001	Extension Tube Comp. (All except S3005-030)			
15	38617017	Crevice Tool			
16	43468018	Hose Tube Comp. - S3005, S3005-001, S3005-020, S3159, S3167			
17	12704BZ	Hose Grip Collar - S3005, S3005-001, S3005-020, S3159, S3167			
18	32156010	Hose Sleeve - S3005, S3005-001, S3005-020, S3005-030, S3159, S3167			
			ITEMS NOT ILLUSTRATED		
				43414073	Floor Brush - S3159
				170110	Shag Vac Rake